

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [All States](#) /

› [All States Operator's Manual for Kubota M4900, M5700, M6800, M8200, M9000 Tractors](#)

All States 125145

All States Operator's Manual for Kubota M4900, M5700, M6800, M8200, M9000 Tractors

Model: 125145

INTRODUCTION

This document serves as the operator's manual for Kubota M4900, M5700, M6800, M8200, and M9000 series tractors. It is a comprehensive guide designed to provide the owner-operator with essential information for the safe and efficient operation and maintenance of their equipment. This manual is either a new original manual from the original equipment manufacturer (OEM) or a new reproduction of a clean, used OEM manual, ensuring accuracy and completeness. The information contained herein covers various aspects, including operational instructions, shift patterns, fluid capacities, and adjustment procedures for critical components.



This image displays the cover of the operator's manual, featuring an illustration of a person in overalls holding a hoe, with the words 'OEM Operator's Manual' prominently displayed.

SETUP AND INITIAL FAMILIARIZATION

Before operating the tractor, it is crucial to familiarize yourself with the contents of this manual. Understand the layout of controls, safety warnings, and basic operational principles. Ensure all pre-operation checks are performed as outlined in the relevant sections.

- Review all safety decals and instructions on the tractor.
- Locate and understand the function of all controls, gauges, and indicators.
- Ensure all fluid levels are at their correct marks before starting the engine.

OPERATING INSTRUCTIONS

This section details the proper procedures for operating your Kubota tractor. Adherence to these instructions is vital for safe and efficient performance.

Starting and Stopping the Engine

1. Ensure the transmission is in neutral and the parking brake is engaged.
2. Turn the ignition key to the "ON" position and check indicator lights.
3. Turn the ignition key to the "START" position to engage the starter. Release the key once the engine starts.
4. To stop the engine, return the ignition key to the "OFF" position.

Shift Patterns

Refer to the specific shift pattern diagrams provided within the manual for your tractor model (M4900, M5700, M6800, M8200, M9000). Always ensure the tractor is stationary or moving at a very low speed before shifting gears to prevent damage to the transmission.

Implement Operation

Instructions for attaching, operating, and detaching various implements are covered. Pay close attention to PTO (Power Take-Off) engagement and disengagement procedures, as well as hydraulic system operation for lifting and lowering attachments.

MAINTENANCE

Regular maintenance is crucial for the longevity and optimal performance of your Kubota tractor. This section outlines routine checks, fluid capacities, and adjustment procedures.

Fluid Capacities

Fluid Type	Capacity (Refer to manual for exact model-specific values)	Recommended Type
Engine Oil	<i>Varies by model</i>	Specific API classification and viscosity
Coolant (Anti-freeze)	<i>Varies by model</i>	Ethylene Glycol based, specific concentration
Hydraulic/Transmission Fluid	<i>Varies by model</i>	Specific UDT or Super UDT fluid
Fuel Tank	<i>Varies by model</i>	Diesel Fuel

Important: Always consult the specific section in your manual for the exact capacities and recommended fluid types for your Kubota M4900, M5700, M6800, M8200, or M9000 model.

Adjustment Procedures

- **Brakes:** Instructions for checking and adjusting brake pedal free play and effectiveness.
- **Clutch:** Procedures for inspecting and adjusting clutch pedal free play to ensure proper engagement and disengagement.
- **Fan Belt Tension:** Guidelines for checking and adjusting the tension of the engine fan belt.
- **Tire Pressure:** Recommended tire pressures for various operating conditions.

TROUBLESHOOTING

This section provides guidance on identifying and resolving common operational issues. For complex problems or issues not covered, it is recommended to consult a qualified service technician.

- **Engine Fails to Start:** Check fuel level, battery charge, and ignition system.
- **Loss of Power:** Inspect air filter, fuel filter, and ensure proper engine RPM.
- **Unusual Noises:** Investigate the source of the noise immediately and cease operation if necessary.

SPECIFICATIONS

Key specifications for the All States Operator's Manual (Model 125145) are provided below:

- **Compatible Tractor Models:** Kubota M4900, M5700, M6800 (S), M8200, M9000
- **Manual Type:** Operator's Manual (Owner's Manual)
- **Origin:** New original manual from OEM or new reproduction of a clean, used OEM manual.
- **Item Weight:** 1 pound
- **Manufacturer:** All States
- **Item Model Number:** 125145

WARRANTY AND SUPPORT

For specific warranty information regarding this operator's manual or for technical support related to its content, please refer to the contact information provided by the seller or the manufacturer, All States. This manual is intended to provide guidance for the operation and maintenance of your Kubota tractor; for tractor-specific warranty details, please consult your tractor's original documentation or an authorized Kubota dealer.

