

Saved from manuals.plus.

Open the live page for links to other documents and user manuals.

[Manuals.plus](#) /

› [Septpenta](#) /

› Septpenta P40 True Wireless Earbuds User Manual

Septpenta P40

Septpenta P40 True Wireless Earbuds User Manual

Model: P40

INTRODUCTION

Thank you for choosing the Septpenta P40 True Wireless Earbuds. This manual provides essential information for the safe and efficient use of your new earbuds. Please read it thoroughly before operation and retain it for future reference.



Image: The P40 True Wireless Earbuds, featuring one earbud removed from its charging case, surrounded by musical notes, illustrating their primary function for audio playback.

PACKAGE CONTENTS

Ensure all items are present in the package:

- 2 x P40 True Wireless Earbuds (Left and Right)
- 1 x Charging Case
- 1 x USB Type-C Charging Data Cable
- 1 x User Manual



Image: A clear display of the Septpenta P40 True Wireless Earbuds package contents, including both earbuds, the charging case, and the USB charging cable.

PRODUCT OVERVIEW

The Septpenta P40 earbuds are designed for comfortable wear and high-fidelity audio, featuring advanced noise reduction and intuitive controls.

True Wireless Earbuds

Open lid connection

Just put on the headphones to start your experience

Side pressure sensitive design, accurate touchpoint

13mm Moving Coil Unit



Image: A close-up view of the P40 True Wireless Earbuds, highlighting their sleek design and the sensitive side pressure area for controls.



Image: Front and back views of the Septenta P40 earbuds, showing the speaker grille and charging contacts.

SETUP AND FIRST USE

Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case. Ensure they are correctly seated to make contact with the charging pins.

2. Connect the provided USB Type-C charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The indicator lights on the charging case will show the charging status. Once fully charged, the lights may change or turn off.



Image: The P40 earbuds securely placed within their charging case, illustrating the charging process.



Image: A close-up of the USB Type-C charging cable, used to power the earbud charging case.

Pairing with a Device

The earbuds use Bluetooth V5.2+EDR for wireless connection.

1. Open the lid of the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices and select "P40" from the list.
4. Once connected, the earbuds will indicate successful pairing (e.g., a voice prompt or indicator light change).

Note: The earbuds feature Hall effect intelligent magnetic suction for simplified connection upon opening the lid.

OPERATING INSTRUCTIONS

Wearing the Earbuds

The P40 earbuds are designed for comfortable and secure fit.

1. Identify the Left (L) and Right (R) earbuds.
2. Gently insert each earbud into the corresponding ear canal, rotating slightly until it feels snug and comfortable.



Image: A person wearing the P40 earbuds while exercising, demonstrating their comfortable and secure fit for active use.

Touch Controls


The earbuds feature a side pressure sensitive design for precise physical feedback and reduced false touches.

Action	Function
Single Tap (Left/Right Earbud)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Triple Tap (Left/Right Earbud)	Activate Voice Assistant
Long Press (Left/Right Earbud)	Reject Call

Noise Reduction (CVC+DSP)

The P40 earbuds incorporate CVC+DSP dual intelligent noise reduction technology. This feature automatically reduces

environmental noise, providing clearer sound quality for music and calls.



Three dimensional sound quality

CVC+DSP dual intelligent noise reduction

With pure sound quality and clearer voice calls



Image: Illustrates the P40 earbuds' capabilities, emphasizing three-dimensional sound quality and CVC+DSP dual intelligent noise reduction for pure sound and clearer voice calls.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Charging Contacts:** Periodically check and gently clean the charging contacts on both the earbuds and inside the case to ensure proper connection.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Avoid Moisture:** While designed for outdoor use, avoid exposing the earbuds to excessive moisture or liquids.
- **Temperature:** Do not expose the earbuds or charging case to extreme temperatures (hot or cold).

TROUBLESHOOTING

If you encounter issues with your P40 earbuds, refer to the following common solutions:

- **Earbuds not pairing:**

- Ensure both earbuds are in the charging case and fully charged.
- Open the case lid to initiate pairing mode.
- Turn off and on Bluetooth on your device.
- Forget "P40" from your device's Bluetooth list and try pairing again.

- **No sound from one earbud:**

- Ensure both earbuds are charged.
- Place both earbuds back in the case, close the lid, wait a few seconds, then open it again.
- Clean the charging contacts on the earbud and in the case.

- **Charging issues:**

- Ensure the charging cable is securely connected to both the case and the power source.
- Try a different USB port or power adapter.
- Verify the charging cable is not damaged.

- **Touch controls not responding:**

- Ensure your finger is making proper contact with the side pressure sensitive area.
- Clean the touch area to remove any dirt or debris.
- Restart the earbuds by placing them in the case and closing the lid.

SPECIFICATIONS

Feature	Detail
Model	P40
Item Type	Earphones
Material	ABS (Acrylonitrile Butadiene Styrene)
Bluetooth Version	V5.2+EDR
Frequency	2402MHz-2480MHz
Wireless Protocol	A2DP, HFP, HSP, AVRCP
Working Distance	10-15m / 33-49ft
Speaker Size	Approx. 13mm / 0.5in
Impedance	32Ω
Charging Port	Type C
Battery Type	Lithium Battery
Charging Case Battery Capacity	400mAh
Headphones Battery Capacity	45mAh
Control Type	Touch Control (Side Pressure Sensitive)

Submit question

Open the live page

<https://manuals.plus/asin/B0BJCTPCWY>

More documents and user manuals: <https://manuals.plus/>