

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WATOOR](#) /

› [WATOOR 3.5 Cu Ft Chest Freezer User Manual](#)

WATOOR BG-30007N2

WATOOR 3.5 Cu Ft Chest Freezer User Manual

Model: BG-30007N2

1. INTRODUCTION

Thank you for choosing the WATOOR 3.5 Cu Ft Chest Freezer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Designed for optimal storage and precise temperature control, this chest freezer is an ideal solution for preserving your food items at super-low temperatures.



Image: The WATOOR 3.5 Cu Ft Chest Freezer in black, showcasing its compact design and top-opening lid.

2. IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions carefully before using the appliance to prevent potential hazards

and ensure proper operation. Keep this manual for future reference.

- **Electrical Safety:** Ensure the freezer is connected to a properly grounded electrical outlet with the correct voltage (115 Volts). Do not use extension cords.
- **Ventilation:** Allow adequate space around the freezer for proper air circulation to prevent overheating.
- **Flammable Materials:** Do not store explosive substances or flammable materials inside or near the freezer.
- **Defrosting:** Use only manufacturer-recommended methods for defrosting. Do not use sharp objects to remove ice.
- **Children Safety:** Supervise children near the appliance. Ensure the lid is securely closed to prevent entrapment.
- **Placement:** This appliance is designed for indoor use. Do not install it in outdoor areas or RVs where it may be exposed to extreme temperatures or weather conditions.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove all packaging materials. Inspect the freezer for any shipping damage. The package includes: 1 x Chest Freezer, 1 x User Manual, and 2 x Baskets.

3.2 Placement

Place the freezer on a flat, stable surface away from direct sunlight or heat sources. Ensure there is sufficient clearance around the unit for proper ventilation. The freezer dimensions are approximately 21.2" (L) x 21.8" (W) x 32.9" (H).


 <p>Precise temperature control to each degree</p>	 <p>Temperature range 14 ~ -40°F</p>	 <p>Two baskets</p>
 <p>Only 3 temperature adjustment</p>	 <p>Temperature range 6.8 ~ -4°F</p>	 <p>Only one basket</p>

Image: Diagram showing the dimensions of the WATOOR Chest Freezer (Length: 21.2", Width: 21.8", Height: 32.9").

3.3 Initial Power-On

After placement, allow the freezer to stand upright for at least 2-4 hours before plugging it in. This allows the refrigerant to settle. Once plugged in, the freezer will begin to cool. It is recommended to let it run empty for a few

hours to reach the desired temperature before loading food.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

The WATOOR Chest Freezer features an intelligent digital display and electronic control for precise temperature adjustments. Temperatures can be set from 14°F to a super-low -40°F, allowing you to customize freezing for various food items. Use the external controls to adjust the temperature. An unlock function prevents accidental misadjustments.



Image: Detailed view of the digital control panel with temperature display and adjustment buttons.

4.2 Quick Freeze Function

Activate the Quick Freeze function for rapid cooling. This triple freezing power helps food retain its original flavor and stay fresher for longer storage periods.



Image: The chest freezer with a visual representation of the quick-freeze function, showing cold vapor around food items.

4.3 Storage Baskets

The freezer comes with two removable baskets for organized storage of smaller or frequently accessed items. These baskets can be easily moved or removed as needed.

Precise temp control to 1°F

Achieve precise temperature control

Avoid temperature misadjusting with unlock function



Image: The interior of the freezer, highlighting the two wire storage baskets.

4.4 Hand-Free Door Design

The steady lid is designed to stay open between 45° and 90° angles, allowing for hands-free access to the freezer's contents. The door mechanism is engineered for quiet operation.



Image: The freezer lid shown propped open at an angle, demonstrating the hands-free design.

5. MAINTENANCE

5.1 Defrosting

This deep freezer is equipped with a water drain to facilitate easy defrosting. Ensure the drain is clear for water to travel during the defrosting process. Regular defrosting helps maintain efficiency and protects your food.



Image: A close-up view of the drain outlet located inside the freezer for defrosting.

5.2 Cleaning

Clean the interior and exterior of the freezer regularly with a mild detergent and warm water. Avoid abrasive cleaners or sharp tools that could damage surfaces. Ensure the freezer is unplugged before cleaning.

5.3 Noise Level

The WATTOOR freezer features a whisper-quiet compressor, operating at approximately 38 dB, minimizing noise distractions in your home.

6. TROUBLESHOOTING

If you encounter issues with your freezer, refer to the following common problems and solutions. For more detailed troubleshooting or persistent issues, please contact customer support.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Freezer not operating	No power, tripped circuit breaker, power cord unplugged.	Check power supply, ensure plug is secure, reset circuit breaker.
Temperature not cold enough	Temperature setting too high, excessive door openings, poor ventilation, too much food loaded at once.	Adjust temperature setting, minimize door openings, ensure proper clearance, allow time for cooling after loading.
Excessive ice build-up	Door gasket not sealing properly, frequent door openings, high humidity.	Check door gasket for damage or obstruction, ensure lid is fully closed, reduce frequency of door openings.
Unusual noise	Freezer not level, objects vibrating against the unit, normal compressor operation.	Ensure freezer is level, check for loose items, note that some compressor sounds are normal.

7. SPECIFICATIONS

Brand: WATOOR

Model Name: BG-30007N2

Capacity: 3.55 Cubic Feet

Color: Black

Product Dimensions: 21.2" (L) x 21.8" (W) x 32.9" (H)

Item Weight: 58.4 pounds

Temperature Range: 14°F to -40°F

Noise Level: 38 dB

Voltage: 115 Volts

Installation Type: Freestanding

Door Hinges: Top

Included Components: 1 x Chest Freezer, 1 x User Manual, 2 x Baskets

8. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about protection plans, please refer to the documentation included with your purchase or contact WATOOR Official Store customer service. This product typically includes a 30-day easy return policy.

For further assistance, please visit the [WATOOR Brand Store on Amazon](#).