Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Auto-plaza Universal Washing Machine Drain Hose 10 Feet (B0BJFFMWKG)

Auto-plaza Universal Washing Machine Drain Hose 10 Feet Instruction Manual

1. Product Overview

This manual provides instructions for the Auto-plaza 10-foot universal washing machine drain hose. This flexible, corrugated hose is designed for draining water from various appliances, including washing machines, dishwashers, portable washers, and sinks. It features multiple connection head sizes for broad compatibility and is constructed from durable PP material to prevent kinking, pinching, and leaking.



Figure 1: Auto-plaza 10-foot Universal Washing Machine Drain Hose.

2. Product Features

- **Universal Compatibility:** Features 4 different sizes of connection heads (7/8", 1", 1-1/4", 1-1/2") to fit most washer brands including LG, GE, Samsung, Whirlpool, Haier, and suitable for dishwashers, portable washers, sinks, dryers, and most front-loading washing machines.
- **Durable Material:** Constructed from PP (Polypropylene) material, ensuring the hose returns to its original shape after compression for unobstructed draining.
- **Kink and Leak Resistant:** The thick-walled, corrugated design prevents kinking, pinching, blocking, and leaking, ensuring reliable performance.
- **Complete Kit:** Includes a 10-foot (3-meter) hose, 1x white extension adapter, 2x hose clamps, and 1x U-bend washer drain hose holder for comprehensive installation needs.
- **Easy Installation:** Designed for straightforward installation without specialized tools.

3. Package Contents

Verify that all components are present in the package:

- 1x 10-foot (3-meter) Corrugated Drain Hose
- 1x White Extension Adapter
- 2x Hose Clamps
- 1x U-Bend Holder




Figure 2: Included components: drain hose, extension adapter, hose clamps, and U-bend holder.

4. Installation Instructions

4.1. Preparing the Hose

The drain hose features a flared end with multiple diameter sections to fit various appliance outlets. Identify the correct diameter for your appliance's drain outlet.



Figure 3: Flared end with multiple diameter options for connection.

If necessary, trim the flared end of the hose to match the exact diameter of your washing machine's drain spout. Use sharp scissors or a utility knife for a clean cut. Ensure the cut is straight to provide a secure connection.

4.2. Direct Connection to Appliance

1. Slide one of the provided hose clamps onto the trimmed end of the drain hose.
2. Firmly insert the trimmed end of the drain hose onto the drain outlet of your washing machine or dishwasher. Ensure it is pushed on as far as possible for a tight fit.
3. Position the hose clamp over the connection point and tighten it securely by hand. This prevents leaks during operation.

4.3. Using as an Extension Hose

If you need to extend an existing drain hose, use the white extension adapter and the additional hose clamps provided.

1. Slide a hose clamp onto each end of the hoses to be connected (your original hose and the new Auto-plaza hose).
2. Insert the white extension adapter into one end of your original drain hose.

3. Connect the other end of the Auto-plaza drain hose to the opposite side of the white extension adapter.
4. Position the hose clamps over each connection point on the adapter and tighten them securely. Ensure both connections are watertight to prevent leaks.

4.4. Using the U-Bend Holder

The U-bend holder is used to position the drain hose securely into a standpipe or laundry tub, preventing it from slipping out during the drain cycle.

1. Slide the U-bend holder onto the discharge end of the drain hose.
2. Position the hose with the U-bend holder into the standpipe or over the edge of the laundry tub. Ensure the hose is deep enough to prevent splashing but not so deep that it creates a siphon effect.

4.5. Installation Videos

Video 1: Jmlwlzx Washing Machine Drain Hose Details and Installation

This video demonstrates the flexibility of the hose, its various connection head sizes, and the process of extending the hose using the adapter and clamps.

Video 2: MyLifeUNIT Washing Machine Drain Hose Installation

This video illustrates the material quality, elasticity, and two methods for hose installation: direct replacement and extension using the connector.

Video 3: Lyplus Two Steps to Install Washing Machine Drain Hose

This video provides a concise guide on how to cut the hose to fit the original spout and connect it securely.

5. Operating Instructions

Once properly installed, the Auto-plaza universal drain hose operates automatically with your washing machine's or dishwasher's drain cycle. No manual intervention is required during operation.

6. Maintenance

To ensure optimal performance and longevity of your drain hose:

- **Regular Inspection:** Periodically inspect the entire length of the hose for any signs of wear, kinks, cracks, punctures, or leaks.
- **Check Connections:** Ensure all hose clamps and connections remain tight and secure. Re-tighten if necessary.
- **Clear Blockages:** If you notice slow drainage or water backup, check the hose for any internal blockages from lint or debris. Disconnect the hose and clear any obstructions.
- **Avoid Harsh Chemicals:** Do not use harsh chemicals or abrasive cleaners on the hose, as this may degrade the material.

7. Troubleshooting

- **Leakage at Connections:**
  - Ensure hose clamps are tightened sufficiently.
  - Verify that the hose is fully seated onto the appliance drain outlet or extension adapter.
  - Check for any damage to the hose ends or adapter that might prevent a watertight seal.

- **Slow or No Drainage:**
  - Inspect the hose for kinks or sharp bends that could restrict water flow.
  - Check for blockages inside the hose, especially at the connection points or within the U-bend.
  - Ensure the appliance's drain pump is functioning correctly.
- **Hose Disconnects from Drain:**
  - Ensure the hose clamp is securely tightened.
  - Verify that the hose is pushed far enough onto the drain outlet.
  - Use the U-bend holder to secure the hose in the standpipe or laundry tub.

8. Specifications

Brand	Auto-plaza
Model	Universal Washing Machine Drain Hose 10 Feet (B0BJFFMWKG)
Material	Polypropylene (PP)
Color	White (Hose is grey, but product description mentions white adapter)
Item Length	10 Feet (3 Meters)
Product Dimensions (L x W)	3.05L x 0.04W Meters
Inner Diameter (Connection Heads)	7/8", 1", 1-1/4", 1-1/2"
UPC	774829679975
Manufacturer	Auto_plaza

9. Warranty and Support

Warranty information for this product is not specified in the provided details. For specific warranty terms, conditions, and customer support, please refer to the manufacturer's official website or contact the seller directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BJFFMWKG

More documents and user manuals: **https://manuals.plus/**