

[Manuals.plus](#) /

› [KXAITO](#) /

› KXAITO Model 6092 Men's Sports Watch Instruction Manual

KXAITO 6092

KXAITO Model 6092 Men's Sports Watch Instruction Manual

INTRODUCTION

Thank you for choosing the KXAITO Model 6092 Men's Sports Watch. This manual provides detailed instructions for setting up, operating, and maintaining your watch. Please read this manual carefully to ensure proper use and to fully utilize all its features.



Image: Front view of the KXAUTO Model 6092 Sports Watch, showcasing its robust design and dual analog-digital display.

PRODUCT OVERVIEW

The KXAUTO Model 6092 is a multi-functional sports watch designed for outdoor activities, featuring a durable construction and a range of practical functions. It combines both analog and digital time displays, offering versatility and convenience.

Key Features:

- **Dual Display:** Analog and digital time display for two different time zones.
- **Multi-Functionality:** Includes alarm, LED backlight, date display, stopwatch, and 12/24-hour format options.
- **Durable Design:** Military-style outlook with a reinforced resin band and shock-resistant construction.
- **Water Resistance:** Rated for 3 ATM, suitable for everyday use like splashes and rain.
- **Precision Movement:** Equipped with an imported Japan quartz movement for accurate timekeeping.



Image: The KXAUTO Model 6092 Sports Watch displayed on a tactical background, highlighting its rugged aesthetic.

UNDERSTANDING YOUR WATCH

Familiarize yourself with the buttons and display elements of your KXAUTO Model 6092 watch. The following diagram illustrates the main components:

FUNCTION IS INTRODUCED

53mm

Total length of watch:
262mm
circumference:
(max)236mm
(min)180mm



Model: KXAITO Watch Store

Case material: zinc alloy

Style: Sport watch with
double display

Watch strap material: TPU

Watch movement: Original movement
imported from Japan

Weight:80g

Battery: Maxell Japan battery

Thickness: 17mm

Mirror: high hardness tempered mirror

Waterproof: 50 meters waterproof

Image: Detailed diagram showing the location and function of each button and display element on the KXAITO Model 6092 watch, including LIGHT, MODE, START, RESET buttons, and indicators for time, date, week, and alarm.

Button Functions:

- **LIGHT Button (Top Left):** Activates the LED backlight for visibility in low-light conditions.
- **MODE Button (Bottom Left):** Cycles through different modes: Time Display, Alarm Setting, Stopwatch, and potentially Dual Time.
- **START Button (Top Right):** Used to start/stop the stopwatch, and to increase or adjust values during setting operations.
- **RESET Button (Bottom Right):** Used to reset the stopwatch, and to select or switch between different setting parameters (e.g., hours, minutes, date).

SETUP INSTRUCTIONS

1. Setting Digital Time and Date:

1. From the normal time display, press the **MODE** button three times to enter the time setting mode. The seconds digits will begin to flash.
2. Press the **RESET** button to cycle through the setting parameters: Seconds → Hours → Minutes → Month → Date → Day of Week.
3. While a parameter is flashing, press the **START** button to adjust its value.
4. Once all settings are adjusted, press the **MODE** button to exit the setting mode and return to the normal time display.

2. Setting Analog Time:

The analog hands on your KXAUTO Model 6092 watch are synchronized with the digital time. Once the digital time is set, the analog hands will automatically adjust to match it. No separate manual adjustment for the analog hands is required.

3. Setting the Alarm:

1. From the normal time display, press the **MODE** button once to enter the Alarm mode.
2. Press the **RESET** button to select the hour digits. Press the **START** button to adjust the hour.
3. Press the **RESET** button again to select the minute digits. Press the **START** button to adjust the minutes.
4. Press the **MODE** button to exit the alarm setting mode.
5. To activate or deactivate the alarm, press the **START** button while in Alarm mode. An alarm icon will appear/disappear on the display.

4. 12/24 Hour Format:

In the normal time display mode, press the **START** button to toggle between 12-hour (with AM/PM indicator) and 24-hour formats.

OPERATING FUNCTIONS

1. Using the Stopwatch:

1. From the normal time display, press the **MODE** button twice to enter the Stopwatch mode. The display will show '00:00:00'.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to reset the stopwatch to '00:00:00'.
5. To resume timing after pausing, press the **START** button.
6. Press the **MODE** button to exit Stopwatch mode.

2. Activating the LED Backlight:

Press the **LIGHT** button (top left) at any time to illuminate the digital display for a few seconds.

3. Dual Time Display:

The watch supports displaying two different time zones. While in normal time display, you can set a second time zone by following similar steps to setting the main time, typically accessed by pressing the MODE button multiple times until a secondary time display is shown. Refer to the digital time setting instructions for adjusting the second time zone.

MAINTENANCE

Water Resistance (3 ATM):

Your KXAUTO Model 6092 watch is water-resistant up to 3 ATM (30 meters), making it suitable for everyday use such as splashes, rain, and accidental exposure to water. However, it is **not** suitable for swimming, diving, or showering with hot water.

- **Important:** Do not press any buttons while the watch is submerged in water.
- Avoid exposing the watch to steam or hot water, as this can damage the waterproof seals.

Battery:

The watch uses a Japanese original battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and functionality.

Cleaning:

To clean your watch, wipe it gently with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using chemical cleaners or solvents.

TROUBLESHOOTING

- **Watch not displaying time or functions:** Check if the battery needs replacement. If the display is blank, the battery may be depleted.
- **Time is inaccurate:** Re-set the digital time following the instructions in the 'Setup Instructions' section. Ensure the 12/24-hour format is correctly set.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model does not feature a lock). If the issue persists, a reset may be required (consult support).
- **Alarm not sounding:** Verify that the alarm is activated (alarm icon visible on display) and that the alarm time is correctly set.

SPECIFICATIONS



FUNCTION INTRODUCTION



Funciton Overview



Give the correct time



Night Light



Second chronograph



Weeks/calendar




50meters waterproof



Shock resistant to fall



Japanese original battery



12/24 hourly



Alarm clock mode



Image: Diagram illustrating the dimensions and material specifications of the KXAITO Model 6092 watch, including case diameter, band width, and thickness.

Feature	Specification
Model Number	6092
Case Material	Zinc Alloy
Watch Strap Material	TPU (Thermoplastic Polyurethane)
Watch Movement	Original imported Japan quartz movement
Battery	Maxell Japan battery
Mirror Material	High hardness tempered mirror (Acrylic Crystal Glass)
Water Resistance	3 ATM (30 meters)
Case Diameter	57.82 Millimetres (approx. 2 inches / 50mm dial)
Case Thickness	17 Millimetres
Band Width	22 Millimetres
Total Length of Watch	262 Millimetres
Circumference (Max/Min)	236mm (Max) / 180mm (Min)
Item Weight	100 grams (Watch only: 80 grams)

WARRANTY AND SUPPORT

KXAITO is committed to customer satisfaction. While specific warranty details are not provided in this manual, we offer comprehensive after-sale support. If you have any questions, encounter issues with your watch, or require assistance, please do not hesitate to contact our customer service team. We will endeavor to resolve any concerns promptly. Please retain your purchase receipt as proof of purchase for any support inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question