ALLIMITY QYSY-N2QAYB000428-QYSY

ALLIMITY N2QAYB000428 Replacement Remote Control User Manual

Model: QYSY-N2QAYB000428-QYSY | Brand: ALLIMITY

Introduction

This user manual provides comprehensive instructions for the ALLIMITY N2QAYB000428 Replacement Remote Control. Designed to cover all functions of your original remote, this device offers a seamless replacement experience. No complex programming is required; simply insert the batteries, and it is ready for immediate use with compatible Panasonic Plasma Viera TV models.
Compatible TV Models:

- TX-L32G10B
- TX-L37G10B
- TX-P46G10B
- TX-P42G10B
- TX-P50G10B
- N2QAYB000428 (Original Remote Model)

Setup and Battery Installation

The ALLIMITY N2QAYB000428 remote control is designed for ease of use, requiring no programming. Follow these simple steps to begin operation:

1. **Locate the Battery Compartment:** Turn the remote control over. The battery compartment is located on the back of the unit.
2. **Open the Compartment:** Gently slide the battery cover downwards or press the latch (if present) and lift the cover to open.
3. **Insert Batteries:** Insert two new AAA alkaline batteries (not included) into the compartment. Ensure the positive (+) and negative (-) terminals of the batteries align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.

4. **Close the Compartment:** Replace the battery cover by sliding it back into place until it clicks securely.
5. **Test the Remote:** Point the remote control towards your compatible Panasonic TV and press the Power button. The TV should respond. If not, double-check battery orientation and ensure the batteries are fresh.






Figure 1: Rear view of the remote control, highlighting the battery compartment.

Operating Instructions

The ALLIMITY N2QAYB000428 remote control operates via infrared (IR) technology and has a maximum effective range of 10 meters (approximately 33 feet). Ensure a clear line of sight between the remote's IR emitter and your TV's IR receiver for optimal performance.





Figure 2: Front view of the remote control, displaying all buttons and their layout.

Key Functions:

Button/Section	Function
Power (Red Button)	Turns the TV on or off.
Input / TV / AV	Selects video input sources (e.g., HDMI, AV, Component).
Aspect	Adjusts the screen aspect ratio.
Menu	Accesses the TV's main menu.
Navigation (Arrow Keys & OK)	Navigates through menus and confirms selections.
Viera Tools	Accesses Panasonic Viera specific smart features and tools.
Volume (+/-)	Increases or decreases the volume level.
Channel (Up/Down)	Changes TV channels.
Number Pad (0-9)	Direct channel entry.
Text / STTL / Index / Hold	Functions related to teletext, subtitles, and other display options.

Button/Section	Function
REC / Playback Controls	Controls for recording and media playback (e.g., Play, Pause, Stop, Rewind, Fast Forward).



Figure 3: Angled view of the remote control, illustrating its form factor.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new alkaline batteries of the same type (AAA). Do not mix old and new batteries, or different types of batteries.
- **Cleaning:** Use a soft, dry cloth to clean the surface of the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.
- **Storage:** Store the remote control in a clean, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage and potential damage.
- **Handling:** Avoid dropping the remote control or subjecting it to strong impacts, as this can damage internal circuitry.

Troubleshooting

If you encounter issues with your ALLIMITY N2QAYB000428 remote control, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Remote is not responding.	◦ **Batteries are dead or low:** Replace with fresh alkaline batteries. ◦ **Batteries inserted incorrectly:** Check the positive (+) and negative (-) orientation. ◦ **No clear line of sight:** Ensure nothing is blocking the path between the remote and the TV's IR receiver. ◦ **Remote is too far:** Move closer to the TV (within 10 meters).
Some buttons are not working.	◦ **Dirty contacts:** Clean the remote's surface and buttons as described in the Maintenance section. ◦ **Internal damage:** If cleaning and battery replacement do not resolve the issue, the remote may be damaged. Consider replacement.
Remote works intermittently.	◦ **Low batteries:** Replace batteries. ◦ **Interference:** Ensure no strong light sources (like direct sunlight or certain energy-saving lamps) are interfering with the IR signal.

Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	QYSY-N2QAYB000428-QYSY
Connectivity Technology	Infrared (IR)
Special Features	No programming required
Compatible Devices	Panasonic Plasma Viera TV models: TX-L32G10B, TX-L37G10B, TX-P46G10B, TX-P42G10B, TX-P50G10B, N2QAYB000428 (original remote)
Maximum Supported Devices	10 (referring to the number of devices the original remote could control, though this replacement is specific to one TV type)
Number of Buttons	15 (main functional buttons)
Controller Type	Remote Control
Maximum Range	10 Meters (approx. 33 feet)
Battery Description	Alkaline (AAA, not included)
Manufacturer	ALLIMITYQYSY
Country of Origin	China
ASIN	B0BJJ38H62

Warranty and Support

While specific warranty details are not provided, the product typically adheres to standard return policies. For this product, a **30-day refund/replacement policy** is generally available from the date of purchase.
For any issues, questions, or support inquiries regarding your ALLIMITY N2QAYB000428 remote control, please contact the seller, **ZHICHENGMAO**, through the platform where the purchase was made. Ensure you have your order details readily available for faster assistance.
Manufacturer: ALLIMITYQYSY

© 2024 ALLIMITY. All rights reserved.