

- Manuals.plus /
- › Andis /
 - › Andis inEDGE 42315 Lithium-Ion Cordless All-in-One Wet/Dry Trimmer Instruction Manual

Andis 42315

Andis inEDGE 42315 Lithium-Ion Cordless All-in-One Wet/Dry Trimmer Instruction Manual

Model: 42315

- Overview
- Safety Information
- What's Included
- Product
- Features
- Operation
- Maintenance
- Troubleshooting
- Specifications
- Warranty & Support

1. OVERVIEW

The Andis inEDGE 42315 Trimmer is a versatile grooming tool designed for comprehensive hair removal and trimming across the face, body, ears, and nose. This cordless, wet/dry capable device features a long-lasting Lithium-Ion battery and multiple interchangeable heads to cater to various grooming needs.



Image 1.1: The Andis inEDGE 42315 Trimmer, showcasing its sleek design.

2. SAFETY INFORMATION

Please read and understand all safety instructions before using the Andis inEDGE 42315 Trimmer. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug or turn off the shaver before cleaning.
- Do not use the shaver while charging.
- Keep the shaver away from water while charging.
- Clean the shaver after each use to prevent bacterial growth.
- Be cautious when using the shaver on the face or neck to avoid cuts or skin irritation.
- Do not immerse the charging adapter in water.
- Keep out of reach of children.

3. WHAT'S INCLUDED

Your Andis inEDGE 42315 Trimmer kit includes the following components:

- Andis inEDGE Trimmer Unit
- Charging Adapter
- Custom Storage Case
- Cleaning Brush
- Dual Bladed Face & Body Attachment
- 1.5mm Guide Comb (for Dual Bladed Attachment)
- 3mm Guide Comb (for Dual Bladed Attachment)
- 5mm Guide Comb (for Dual Bladed Attachment)
- Nose/Ear/Eyebrow Attachment
- 3mm Guide Comb (for Nose/Ear/Eyebrow Attachment)
- 6mm Guide Comb (for Nose/Ear/Eyebrow Attachment)
- Foil Shaver with Protective Cap



Image 3.1: All components included in the Andis inEDGE 42315 Trimmer kit.



Image 3.2: The Andis inEDGE 42315 Trimmer and accessories neatly organized in its custom storage case.

Video 3.1: An overview of the Andis inEDGE Lithium-Ion Cordless All-In-One Wet/Dry Trimmer and its components.

4. PRODUCT FEATURES

- **Dual-Sided Trimmer Head:** Cuts longer hair like a traditional trimmer but provides a closer shave similar to a shaver.
- **Wet/Dry Capability:** Allows for convenient use in the shower and easy cleaning under running water.
- **Lithium-Ion Battery:** Delivers consistent, fade-free power with up to 60 minutes of run time on a single charge.
- **Interchangeable Heads:** Includes a multi-function head (dual-sided blade), foil shaver, and nose/ear/eyebrow trimmer for various grooming tasks.
- **Custom Storage Case:** Designed to securely hold all attachments, ideal for travel and organization.



Image 4.1: Close-up view of the dual-sided trimmer blade.



Image 4.2: The charging port located at the base of the trimmer.

5. OPERATING INSTRUCTIONS

5.1. Charging the Trimmer

1. Ensure the trimmer is turned off.
2. Connect the charging adapter to the charging port at the bottom of the trimmer.
3. Plug the adapter into a suitable electrical outlet.
4. The battery indicator (if present) will show charging status. A full charge provides up to 60 minutes of run time.

5.2. Attaching and Changing Heads

1. To remove a head, gently twist it counter-clockwise and pull upwards.
2. To attach a head, align the head with the trimmer body and twist clockwise until it locks into place.

5.3. Using the Trimmer

Select the appropriate attachment and guide comb for your desired grooming task.

- **For Face and Body Hair (Dual-Sided Blade):** Use the dual-sided blade attachment. Attach the desired guide comb (1.5mm, 3mm, or 5mm) for specific lengths. Move the trimmer against the direction of hair growth for optimal results.
- **For Nose, Ear, and Eyebrow Hair:** Use the specialized nose/ear/eyebrow attachment. This attachment is designed for safe and precise trimming in delicate areas.
- **For a Close Shave (Foil Shaver):** Use the foil shaver attachment for a smooth finish on smaller areas.



Image 5.1: Using the trimmer for facial hair.



Image 5.2: Using the trimmer for body hair.



Image 5.3: Using the trimmer for nose hair.

Video 5.1: Demonstration of the Andis inEDGE Trimmer in use for various grooming tasks.

6. MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and extend the life of your trimmer.

1. **Cleaning the Blades:** After each use, remove the attachment head and use the provided cleaning brush to remove any trapped hairs. For wet/dry models, rinse the blades under running water.
2. **Oiling the Blades:** Periodically apply a small drop of clipper oil (not included in this kit, but recommended for blade longevity) to the blades to keep them lubricated and sharp.
3. **Storage:** Store the trimmer and all accessories in the custom storage case when not in use to protect them from damage.

7. TROUBLESHOOTING

If you encounter issues with your Andis inEDGE 42315 Trimmer, please refer to the following common solutions:

- **Trimmer not turning on:** Ensure the trimmer is fully charged. If it's a new unit, it may require an initial charge.
- **Reduced cutting performance:** Clean the blades thoroughly to remove any hair buildup. Apply clipper oil to lubricate the blades. Ensure the attachment head is securely fastened.
- **Skin irritation/pulling:** Ensure blades are clean and oiled. Use the correct attachment and guide comb for the hair type and area. Trim against the direction of hair growth.
- **Battery not holding charge:** Ensure the charging adapter is properly connected to both the trimmer and the power outlet. If issues persist, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	42315
Power Source	Battery Powered (Lithium Ion)
Run Time	Up to 60 minutes
Wet/Dry Use	Yes
Interchangeable Heads	Multi-function (Dual-Sided), Foil Shaver, Nose/Ear/Eyebrow Trimmer
Included Guide Combs	1.5mm, 3mm, 5mm (for Dual-Sided); 3mm, 6mm (for Nose/Ear/Eyebrow)
Dimensions	8.74 x 4.65 x 2.8 inches
Weight	14 ounces
UPC	040102423154

9. WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please visit the official Andis website or refer to the documentation included in your product packaging. Keep your purchase receipt as proof of purchase for any warranty claims.

You can visit the Andis Store for more information:[Andis Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BJJ4729Q>

More documents and user manuals: <https://manuals.plus/>