Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

reMarkable RM114

reMarkable 2 Digital Paper Tablet User Manual

Model: RM114

Introduction

The reMarkable 2 is a digital paper tablet designed to provide a paper-like writing and reading experience without digital distractions. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your reMarkable 2 device, Marker Plus, and Book Folio.



Image: The reMarkable 2 tablet, Marker Plus pen, and the gray Book Folio cover, illustrating the complete bundle.

What's in the Box

Your reMarkable 2 bundle includes the following components:

- **reMarkable 2 Digital Paper Tablet:** The main device with a 10.3-inch CANVAS display.
- **Marker Plus:** The reMarkable pen with an integrated eraser for precise writing and drawing.
- **9 Replacement Marker Tips:** Spare tips for your Marker Plus to ensure continuous use.
- **Book Folio (Polymer Weave, Gray):** A protective cover designed to house and protect your reMarkable 2.
- **USB-A to USB-C Cable:** For charging and data transfer.
- **1-Year Connect Subscription:** Provides cloud storage and synchronization features.



Image: An illustration showing the reMarkable 2 tablet, Marker Plus pen, and the Book Folio, highlighting the components of the Essentials bundle.

Setup

1. Initial Charging

Before first use, fully charge your reMarkable 2 tablet using the provided USB-A to USB-C cable and a compatible power adapter (not included). The charging port is located on the bottom edge of the device.

2. Attaching the Book Folio

The Book Folio attaches magnetically to the left side of your reMarkable 2 tablet. Align the tablet with the folio's magnetic strip until it snaps securely into place. This provides protection and a comfortable grip.



Image: A reMarkable 2 tablet placed inside its Book Folio, demonstrating the protective cover in use.



Image: A close-up view showing the magnetic connection point where the Book Folio attaches to the reMarkable 2 tablet.

3. Initial Setup and Wi-Fi Connection

Upon first power-on, follow the on-screen prompts to complete the initial setup. This includes connecting to a Wi-Fi network to enable cloud synchronization and software updates. Ensure you have your Wi-Fi password ready.

4. Activating Connect Subscription

Your bundle includes a 1-year Connect subscription. Follow the instructions provided with your device or visit the reMarkable website to activate your subscription. This enables unlimited cloud storage and synchronization across devices.

Operating the reMarkable 2

1. Power On/Off and Sleep Mode

- To **power on**, press and hold the power button (top left edge) for a few seconds.
- To put the device into **sleep mode**, briefly press the power button.

- To **power off**, press and hold the power button until the power-off menu appears, then select "Power off".

2. Navigation and Interface

The reMarkable 2 features a minimalist interface. Navigate using touch gestures: swipe to scroll, tap to select, and use the sidebar menu for options like creating new notebooks, importing documents, and accessing settings.

3. Note-Taking and Drawing

Use the Marker Plus to write and draw directly on the reMarkable 2's screen. The textured surface provides a friction similar to paper. The Marker Plus offers pressure sensitivity for varied line thickness.

- **Tool Selection:** Tap the pen icon in the sidebar to choose different pens, pencils, brushes, and colors (grayscale representation on screen).
- **Eraser:** Use the integrated eraser on the top of the Marker Plus to quickly correct mistakes. Alternatively, select the eraser tool from the sidebar.
- **Layers:** Organize complex drawings or notes using layers, accessible from the drawing tools menu.



Image: A person intently writing on a reMarkable 2 tablet, illustrating its design for focused work.



Image: A close-up of a hand writing on the reMarkable 2's textured screen with the Marker Plus, emphasizing the paper-like feel.

4. Reading Documents and PDFs

Import PDFs and e-books (EPUB format) to your reMarkable 2 for reading. You can annotate directly on PDFs using the Marker Plus, highlight text, and add notes.

5. Organizing Your Work

Keep your notes and documents organized using folders and tags. This allows for easy retrieval of your content.

- **Folders:** Create new folders to categorize your notebooks and documents.
- **Tags:** Assign tags to items for cross-referencing and quick searching.
- **Search:** Use the search function to find specific notes or documents by title or content.

6. Converting Handwriting to Text

The reMarkable 2 can convert your handwritten notes into typed text. Select the desired handwritten section and choose the "Convert to text" option. This feature is particularly useful for sharing notes digitally.



Image: A split screen view on the reMarkable 2, demonstrating the conversion of handwritten notes into typed text.

7. Cloud Synchronization and Apps

With an active Connect subscription, your notes and documents are automatically synchronized to the reMarkable cloud. You can access, review, and edit your content across your other devices using the reMarkable desktop and mobile applications.




Image: A reMarkable 2 tablet, laptop, and smartphone displaying synchronized notes, illustrating the cloud sync feature.

Maintenance

1. Cleaning the Device

To clean your reMarkable 2 screen and body, use a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive materials, or excessive moisture.

2. Marker Tip Replacement

The Marker Plus tips will wear down over time, similar to a pencil. When the tip becomes too short or writing performance degrades, replace it with one of the provided spare tips. Use the tip removal tool (often found in the Marker Plus packaging) to gently pull out the old tip and insert a new one until it clicks into place.

3. Battery Care

To maximize battery life, avoid fully discharging the device frequently. Charge it regularly, especially if storing it for extended periods. The reMarkable 2 offers up to 2 weeks of battery life with typical use.

Troubleshooting

Device Not Responding

- **Restart:** Press and hold the power button for about 15 seconds to force a restart.
- **Charge:** Ensure the device is charged. Connect it to a power source and wait a few minutes before attempting to power on again.

Marker Not Writing

- **Check Tip:** Ensure the Marker tip is properly inserted and not overly worn. Replace if necessary.
- **Restart Device:** A device restart can sometimes resolve connectivity issues with the Marker.

Wi-Fi Connectivity Issues

- **Re-enter Password:** Go to Settings > Wi-Fi and re-enter your network password.
- **Router Restart:** Try restarting your Wi-Fi router.
- **Distance:** Ensure the device is within range of your Wi-Fi router.

Synchronization Problems

- **Internet Connection:** Verify your reMarkable 2 has an active internet connection.
- **Connect Subscription:** Ensure your Connect subscription is active and not expired.
- **Account Login:** Confirm you are logged into the correct reMarkable account on all devices.

Specifications

Feature	Detail
Model Number	RM114
Brand	reMarkable
Screen Size	10.3 Inches
Screen Resolution	1872 x 1404 Pixels
Operating System	Linux
Connectivity	Wi-Fi (802.11ac), USB Type-C
Pressure Sensitivity (Marker)	4096 Levels
Battery Life	Up to 2 weeks (average use)
Dimensions (L x W x H)	24.6 x 18.8 x 0.5 cm
Weight	1.4 Kilograms
Special Feature	Portable, Paper-like writing experience



Image: A side profile view of the reMarkable 2 tablet, highlighting its thin design.

Warranty and Support

Warranty Information

reMarkable products typically come with a limited warranty covering manufacturing defects. Please refer to the warranty card included with your product or visit the official reMarkable website for the most up-to-date warranty terms and conditions specific to your region.

Customer Support

For further assistance, technical support, or to report issues not covered in this manual, please contact reMarkable customer support through their official website. You can usually find support resources, FAQs, and contact forms at support.remarkable.com.

© 2024 reMarkable. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BJJ5FJ6H

More documents and user manuals: **https://manuals.plus/**