

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UPBRIGHT 50.4V AC/DC Adapter Instruction Manual for CleanMax Zoom ZM-800 Series Vacuums

UPBRIGHT 50.4V AC/DC Adapter

UPBRIGHT 50.4V AC/DC Adapter Instruction Manual

For CleanMax Zoom ZM-800, ZM-800.2, ZM-800.4, ZM-800.6 Cordless Upright Vacuums

1. INTRODUCTION

This manual provides essential instructions for the safe and effective use of your UPBRIGHT 50.4V AC/DC Adapter. This adapter is designed to provide power and charge the 44V Li-ion battery packs of compatible CleanMax Zoom cordless upright vacuum models, including ZM-800, ZM-800.2, ZM-800.4, ZM-800.6, Item CLH-6, C223-1800, and C223-2000.



This image shows the UpBright AC Adapter Power Supply and its compatibility with CleanMax Zoom cordless vacuums, including models ZM-800, ZM-800.2, ZM-800.4, and ZM-800.6. It also displays an owner's manual for the CleanMax Zoom Cordless vacuum.

2. IMPORTANT SAFETY INFORMATION

- **Voltage Compatibility:** The 44V rating often refers to the vacuum's battery voltage, **NOT** the charger's output voltage. This adapter provides 50.4V DC output, which is specifically designed for 44V Li-ion battery packs. Always verify compatibility with your specific vacuum model before use.
- **Battery Condition:** Rechargeable batteries have a limited lifespan, typically 1 to 3 years. If your vacuum's battery is old or faulty, it may not accept a charge, which is a battery issue, not a charger malfunction.
- **Power Input:** The adapter supports a worldwide input voltage range of 100-240VAC, 50/60Hz.
- **Protection Features:** This adapter includes Over Voltage Output Protection (OVP), Over Current Output Protection (OCP), and Short Circuit Output Protection (SCP) to ensure safe operation.
- **Indoor Use Only:** Use the adapter in dry, indoor environments only. Avoid exposure to moisture or extreme temperatures.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x UPBRIGHT 50.4V AC/DC Adapter

4. SETUP INSTRUCTIONS


1. **Inspect the Adapter:** Before connecting, visually inspect the adapter and cables for any signs of damage. Do not use if damaged.
2. **Connect to Vacuum:** Insert the barrel connector of the adapter's output cable firmly into the charging port of your CleanMax Zoom cordless upright vacuum.



This image presents the UpBright 50.4V AC/DC adapter connected to its output cable with a barrel connector, ready for use.

3. **Connect to Power Outlet:** Plug the AC power cord into a standard wall outlet (100-240VAC). Ensure the power cord is appropriate for your region.

Come With A Suitable AC Power Cord (Only One)
to Fit Your Country/Area



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY



This image illustrates various AC power cord plug types (US, EU, UK, AU) that may be included with the adapter, along with a

5. OPERATING INSTRUCTIONS

Once connected, the adapter will begin charging the vacuum's battery. Refer to your CleanMax Zoom vacuum's user manual for specific charging indicators and expected charging times. Disconnect the adapter from the wall outlet and the vacuum once charging is complete or when the vacuum is not in use for extended periods.

6. MAINTENANCE

- **Cleaning:** Disconnect the adapter from power before cleaning. Use a dry, soft cloth to wipe the adapter. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use. Avoid wrapping the cable too tightly around the adapter to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cables excessively. Ensure cables are not pinched or placed under heavy objects.

7. TROUBLESHOOTING

- **Vacuum Not Charging:**
 - Ensure the adapter is securely plugged into both the vacuum and a working wall outlet.
 - Check the wall outlet by plugging in another device.
 - Verify that the vacuum's battery is not at the end of its lifespan (typically 1-3 years). An old or faulty battery may not accept a charge.
 - Confirm the adapter model is correct for your vacuum's battery specifications.
- **Adapter Feels Warm:** It is normal for the adapter to feel slightly warm during operation. If it becomes excessively hot, disconnect it immediately and contact customer support.

8. SPECIFICATIONS

Feature	Specification
Model	UPBRIGHT 50.4V AC/DC Adapter
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	50.4V DC
Output Current	1.5A (1500mA)
Output Power	75.6W
Protection Features	OVP, OCP, SCP

Feature	Specification
Product Dimensions	9 x 6 x 2 inches
Item Weight	1.25 pounds
Compatible Devices	CleanMax Zoom ZM-800, ZM-800.2, ZM-800.4, ZM-800.6, Item CLH-6, 44 Volt Li-ion Battery C223-1800, C223-2000 Cordless Upright Vacuums

9. WARRANTY INFORMATION

This UPBRIGHT product typically comes with a 30-day refund policy and a 24-month exchange warranty. Please refer to the warranty certificate included with your product for specific terms and conditions. Keep your proof of purchase for warranty claims.

10. CUSTOMER SUPPORT

For any questions, technical assistance, or warranty claims, please contact UPBRIGHT customer support through the retailer where the product was purchased or visit the official UPBRIGHT website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BJJBWBH>

More documents and user manuals: <https://manuals.plus/>