

[Manuals.plus](#) /

> [Cozy Castle](#) /

> Cozy Castle TV Stand (Model B0BJKMWF83) Instruction Manual

Cozy Castle B0BJKMWF83

Cozy Castle TV Stand Instruction Manual

Model: B0BJKMWF83

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Assembly may require two people to avoid injury.
- Always secure the TV stand to the wall using appropriate wall anchors (not included) to prevent tip-over, especially in households with children or pets.
- Do not place objects exceeding the maximum weight limit of 110 pounds (50 kg) on the top surface.
- Ensure the TV stand is placed on a flat, stable surface.
- Avoid exposing the product to direct sunlight or extreme temperatures.

2. PRODUCT OVERVIEW

The Cozy Castle TV Stand is a mid-century modern entertainment center designed to accommodate TVs up to 48 inches. It features a storage cabinet, open shelving, integrated power outlets, and cable management solutions.



Figure 2.1: Cozy Castle TV Stand, Oak finish.

Key Features:

- **Mid-Century Modern Design:** Enhances living room or bedroom aesthetics.
- **TV Compatibility:** Supports most flat screen/curved TVs up to 48 inches.
- **Integrated Charging Station:** Equipped with 3 AC power outlets (125V/12A) and a 6.6-foot power cord.
- **Cable Management:** Two pre-drilled holes in the back panel help organize wires.
- **Ample Storage:** Features open shelves and a cabinet with adjustable shelving.
- **Soft-Close Hinges:** Ensures quiet and safe cabinet door operation.

Adjustable Shelf



Figure 2.2: Integrated power outlets for convenient charging.



Figure 2.3: Cable management holes for organized wiring.

3. SETUP AND ASSEMBLY

The Cozy Castle TV Stand is designed for straightforward assembly. All necessary screws and tools are included. Assembly typically takes approximately 30 minutes with the help of the provided instructions and video.

Before You Begin:

- Clear a spacious area for assembly.
- Verify all parts and hardware are present against the packing list.
- Have a screwdriver ready (though one may be included).

Assembly Video Guide:

Your browser does not support the video tag.

Video 3.1: Step-by-step assembly instructions for the Cozy Castle TV Stand.

Key Assembly Steps:

1. **Attach Legs:** Secure the solid rubberwood legs to the base of the TV stand using the provided hardware. Ensure they are firmly tightened for stability.
2. **Assemble Frame:** Connect the side panels and central divider to the top and bottom boards.
3. **Install Shelves:** Insert the adjustable shelves into the desired height positions. The board has 6 corresponding hole positions of 3 heights, which can be adjusted when installing adjust buckle.
4. **Mount Cabinet Door:** Attach the soft-close hinges to the cabinet door and then to the main frame. Adjust as needed for proper alignment.
5. **Install Power Strip:** Secure the integrated power strip into its designated slot.



Figure 3.1: Adjustable shelf for customized storage.

Soft Close Hinge



Figure 3.2: Soft-close hinges for quiet operation.

4. OPERATING INSTRUCTIONS

Once assembled, the TV stand is ready for use.

- **Placing Your TV:** Carefully place your television on the top surface. Ensure it is centered and stable. The stand is designed for TVs up to 48 inches and a maximum weight of 110 pounds.
- **Using the Charging Station:** Plug the TV stand's power cord into a wall outlet. Use the three AC outlets to power your TV, Wi-Fi router, gaming consoles, or other electronic devices.
- **Cable Management:** Route all power and signal cables through the designated cable holes in the back panel to maintain a tidy appearance and prevent tangles.
- **Storage:** Utilize the open shelves and the cabinet with its adjustable shelf to store media devices, books, remote controls, and other items.

Your browser does not support the video tag.

Video 4.1: Overview of the Cozy Castle TV Stand features and usage.

5. MAINTENANCE

Regular maintenance will help preserve the appearance and longevity of your TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or polishes that may damage the finish.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Avoid Moisture:** Protect the stand from excessive moisture and spills. Wipe up any liquids immediately.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight may cause fading or discoloration.

6. TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Wobbly Stand:** Ensure all screws are securely tightened. Check that the stand is on a level surface. Adjust the feet if applicable.
- **Cabinet Door Misalignment:** The hinges are adjustable. Loosen the hinge screws slightly, adjust the door position, and then re-tighten. Refer to the assembly video for hinge adjustment details.
- **Power Outlets Not Working:** Check if the TV stand's main power cord is securely plugged into a functional wall outlet. Ensure the devices plugged into the stand are properly connected and powered on.
- **Missing Parts:** If any parts are missing or damaged upon arrival, please contact customer support immediately.

7. SPECIFICATIONS

Feature	Detail
Brand	Cozy Castle
Model	B0BJKMWF83
Color	Oak
Product Dimensions (D x W x H)	15.7" x 43.3" x 19.5" (40cm x 110cm x 49.5cm)
Item Weight	40 Pounds (18.1 kg)
Weight Limit (Top Surface)	110 Pounds (50 kg)
Material	Wood (Oak finish)
Power Outlets	3 AC outlets (125V/12A)
Power Cord Length	6.6 Feet
Number of Shelves	3 (1 adjustable)
Assembly Required	Yes



Figure 7.1: Product dimensions and weight capacity.

8. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact Cozy Castle directly through their official website or the retailer where the product was purchased.

Please have your model number (B0BJKMWF83) and purchase date available when contacting support.