

[manuals.plus](#) /› [Apple](#) /› [Apple iPad Pro 11-inch \(4th Generation\) User Manual](#)

## Apple iPad Pro 11-inch (4th Generation)

# Apple iPad Pro 11-inch (4th Generation) User Manual

This manual provides detailed instructions for setting up, operating, and maintaining your Apple iPad Pro 11-inch (4th Generation) with M2 chip.

## 1. GETTING STARTED

---

### 1.1. What's in the Box

Verify that all components are present in your iPad Pro package:

- 11-inch iPad Pro
- USB-C Charge Cable (1 meter)
- 20W USB-C Power Adapter

# What's in the Box



**USB-C  
Charge Cable**



**USB-C  
Power Adapter**



Image: The iPad Pro, USB-C charge cable, and 20W USB-C power adapter as found in the product packaging.

## 1.2. Device Overview

Familiarize yourself with the physical features of your iPad Pro.




Image: Front view of the iPad Pro, highlighting the Liquid Retina display.





Image: Side view of the iPad Pro, illustrating its thin profile and camera bump.

## 2. SETUP

### 2.1. Charging Your iPad Pro

Before initial use, fully charge your iPad Pro using the included USB-C Charge Cable and 20W USB-C Power Adapter. Connect the USB-C cable to the iPad's USB-C port and the power adapter, then plug the adapter into a power outlet. The battery icon on the screen will indicate charging status.

## 2.2. Powering On and Off

- **To Power On:** Press and hold the top button until the Apple logo appears.
- **To Power Off:** Press and hold the top button and either volume button simultaneously until the power off slider appears. Drag the slider to shut down the device.

## 2.3. First-Time Configuration

Upon first power-on, follow the on-screen instructions to set up your iPad Pro:

1. Select your language and region.
2. Connect to a Wi-Fi network.
3. Set up Face ID for secure authentication.
4. Create a passcode.
5. Restore data from a backup or set up as a new iPad.
6. Sign in with your Apple ID or create a new one.
7. Configure location services, Siri, and other settings.

## 2.4. Cellular Data Setup (Wi-Fi + Cellular models only)

If you have a Wi-Fi + Cellular model, you can set up cellular data through an eSIM or a physical nano-SIM card. Consult your carrier for activation details.

# 3. BASIC OPERATION

---

## 3.1. Navigating iPadOS

iPadOS offers an intuitive interface primarily controlled by touch gestures.

- **Tap:** Select an item or activate a button.
- **Swipe:** Navigate through pages, scroll content, or access Control Center/Notification Center.
- **Pinch:** Zoom in or out on photos and web pages.
- **Home Gesture:** Swipe up from the bottom edge of the screen to return to the Home Screen.

## 3.2. Multitasking with Stage Manager

Stage Manager allows for resizable, overlapping app windows and external display support, enhancing productivity.



Image: The iPad Pro demonstrating Stage Manager with multiple applications open simultaneously.

### 3.3. Using Accessories

The iPad Pro supports the Apple Pencil (2nd Generation) and Magic Keyboard (both sold separately) for enhanced functionality.

- **Apple Pencil:** Attach magnetically to the side of your iPad Pro for pairing and charging. Use for drawing, note-taking, and precise interaction.
- **Magic Keyboard:** Connects magnetically and provides a full-size keyboard, trackpad, and protective cover.



Image: A user interacting with the iPad Pro using an Apple Pencil.

## iPadOS




Image: Visual representation of the iPad Pro's core features including M2 chip, 5G, Apple Pencil, and Magic Keyboard.

### 3.4. Camera Functions

The iPad Pro features advanced cameras for photography, video recording, and augmented reality.

- **Rear Cameras:** 12MP Wide and 10MP Ultra Wide cameras with True Tone flash for high-quality photos and 4K video recording.
- **Front Camera:** 12MP Ultra Wide front camera with Center Stage, which keeps you centered during video calls.



Image: Comparison of two iPad displays, showcasing the visual quality.

## 4. CONNECTIVITY

### 4.1. Wi-Fi and Cellular

Your iPad Pro supports Wi-Fi 6E for fast wireless connections and 5G cellular for connectivity in more locations (on Wi-Fi + Cellular models).

- **Connecting to Wi-Fi:** Go to Settings > Wi-Fi, select your network, and enter the password.
- **Using Cellular Data:** Ensure your cellular plan is active. Manage cellular settings in Settings > Cellular Data.

### 4.2. Bluetooth

Connect wireless accessories like headphones, keyboards, and game controllers via Bluetooth. Go to Settings > Bluetooth to pair devices.

## 5. MAINTENANCE AND CARE

### 5.1. Cleaning Your Device

Use a soft, lint-free cloth to clean your iPad Pro. Avoid abrasive materials, aerosols, or harsh cleaning solutions. Disconnect all cables and power off the device before cleaning.

### 5.2. Battery Management

To optimize battery life:

- Keep iPadOS updated to the latest version.

- Adjust screen brightness.
- Enable Low Power Mode when battery is low.
- Avoid extreme ambient temperatures.

## 5.3. Software Updates

Regularly update iPadOS to ensure optimal performance, security, and access to new features. Go to Settings > General > Software Update.

# 6. TROUBLESHOOTING

---

## 6.1. Common Issues and Solutions

- **Device unresponsive:** Force restart your iPad Pro.
- **Wi-Fi connection issues:** Restart your Wi-Fi router and your iPad Pro. Verify network password.
- **App not responding:** Close the app from the App Switcher and reopen it.

## 6.2. Restarting Your iPad Pro

If your iPad Pro is not responding, perform a force restart:

1. Press and quickly release the Volume Up button.
2. Press and quickly release the Volume Down button.
3. Press and hold the Top button until the Apple logo appears.

## 6.3. Restoring Factory Settings

As a last resort for persistent issues, you can erase all content and settings. This will return your iPad Pro to its factory state. Ensure you have a backup before proceeding. Go to Settings > General > Transfer or Reset iPad > Erase All Content and Settings.

# 7. SPECIFICATIONS

---

## 7.1. Technical Specifications

Feature	Detail
Model Number	MP563LL/A
Display	11-inch Liquid Retina display with ProMotion technology and True Tone
Display Resolution	2388 x 1668 Pixels
Chip	Apple M2 chip (8-core CPU, 10-core GPU, 16-core Neural Engine)
Memory Storage Capacity	128 GB (Configurable up to 2TB)
Rear Cameras	12MP Wide and 10MP Ultra Wide with Smart HDR 4, 4K video recording

Feature	Detail
Front Camera	12MP Ultra Wide TrueDepth camera with Center Stage, Smart HDR 4
Battery Life	Up to 10 hours (Wi-Fi), Up to 9 hours (cellular data)
Connector	USB-C with support for Thunderbolt / USB 4
Dimensions (H x W x D)	9.74 x 7.02 x 0.23 inches (247.6 x 178.5 x 5.9 mm)
Weight	1.03 pounds (466 grams) Wi-Fi model; 1.04 pounds (470 grams) Wi-Fi + Cellular model
Compatible Accessories	Apple Pencil (2nd Generation), Magic Keyboard (sold separately)

## 8. SAFETY AND REGULATORY INFORMATION

For detailed safety, handling, recycling, and regulatory information, please refer to the official Apple support documentation available online. Always use your iPad Pro in accordance with the provided guidelines to prevent injury or damage.

## 9. WARRANTY AND SUPPORT

Your Apple iPad Pro is covered by a limited warranty. For specific warranty terms and conditions, please visit the official Apple website or contact Apple Support. Technical support and service options are available through Apple's customer service channels.

For further assistance, visit the official Apple Support website: [support.apple.com/ipad](https://support.apple.com/ipad)

### Related Documents - iPad Pro 11-inch (4th Generation)

 <b>iPad</b> 使用手册 适用于 iOS 7 (2014 年 9 月)	<b>iPad (iOS 7)</b> iPad iPad iOS 7 Siri App Store iCloud
 Apple iPad Pro 12.9-inch (4th Gen) Recycler Guide	<a href="#">Apple iPad Pro 12.9-inch (4th Gen) Recycler Guide: Disassembly and Material Recovery</a> Comprehensive recycler guide for the Apple iPad Pro 12.9-inch (4th generation) Wi-Fi and Wi-Fi + Cellular models. Provides step-by-step disassembly instructions, safety precautions, tool recommendations, and material categorization for efficient resource recovery.

 <p>© 2023 Apple Inc. All rights reserved.</p>	<p><a href="#"><u>Apple iPad Recycler Guide: Disassembly and Material Recovery for 6th, 7th, and 8th Generation Models</u></a></p> <p>This guide provides electronics recyclers with step-by-step instructions for disassembling Apple iPad models (6th, 7th, and 8th generations) to maximize resource recovery. It includes essential safety considerations, recommended tools, and detailed material categorization for proper downstream processing, adhering to environmental regulations.</p>
 <p>© 2023 Apple Inc. All rights reserved.</p>	<p><a href="#"><u>Apple iPad Pro (4th &amp; 6th Gen) Recycler Guide: Disassembly and Material Recovery</u></a></p> <p>Comprehensive recycler guide for Apple iPad Pro 11-inch (4th generation) and 12.9-inch (6th generation) models. Provides detailed step-by-step disassembly instructions and material categorization for efficient resource recovery.</p>
 <p>© 2023 Apple Inc. All rights reserved.</p>	<p><a href="#"><u>Apple Recycler Guide for iPad Pro (M4)</u></a></p> <p>A guide for electronics recyclers on how to disassemble Apple iPad Pro models (11-inch and 13-inch, WiFi and WiFi + Cellular with M4 chip) to maximize resource recovery. Includes safety considerations, disassembly instructions, and product component identification.</p>
 <p>© 2023 Apple Inc. All rights reserved.</p>	<p><a href="#"><u>Apple iPad Pro (M4) Recycling Guide</u></a></p> <p>A comprehensive guide for recycling Apple iPad Pro models with M4 chip, detailing disassembly procedures, safety precautions, and component identification for responsible electronic waste management.</p>