

manuals.plus /

- › [Apple](#) /
- › [Apple iPad Pro 11-inch \(4th Generation\) User Manual](#)

Apple iPad Pro 11-inch (4th Generation)

Apple iPad Pro 11-inch (4th Generation) User Manual

Model: MNXF3LL/A

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your Apple iPad Pro 11-inch (4th Generation). The iPad Pro features the powerful M2 chip, a stunning Liquid Retina Display, and advanced camera systems, designed for high performance and versatility.



Image 1.1: Apple iPad Pro 11-inch (4th Generation) device overview.

Key features include Wi-Fi 6E for fast wireless connectivity, 12MP front and 12MP/10MP back cameras, Face ID for secure authentication, and all-day battery life. The device runs on iPadOS, offering a productive and intuitive user experience with support for a wide range of applications.





Image 1.2: Overview of core technologies and compatible accessories.

2. SETUP

2.1 What's in the Box

What's in the Box



USB-C Charge Cable



USB-C Power Adapter



Image 2.1: Included items with your iPad Pro.

Upon unboxing your iPad Pro, verify that the following items are present:

- 11-inch iPad Pro
- USB-C Charge Cable (1 meter)
- 20W USB-C Power Adapter

2.2 Initial Power On and Charging

To power on your iPad Pro, press and hold the top button until the Apple logo appears. If the device does not power on, it may require charging. Connect the USB-C Charge Cable to the iPad Pro's USB-C port and the 20W USB-C Power Adapter, then plug the adapter into a power outlet. Allow the device to charge for a few minutes before attempting to power it on again.

2.3 First-Time Setup

Follow the on-screen instructions to complete the initial setup process. This typically includes:

1. Selecting your language and region.
2. Connecting to a Wi-Fi network.
3. Setting up Face ID for secure unlocking and authentication.

4. Creating or signing in with your Apple ID.
5. Restoring data from a backup or setting up as a new iPad.

2.4 Optional Accessories

The iPad Pro is compatible with several accessories (sold separately) that enhance its functionality:

- **Apple Pencil (2nd Generation):** For drawing, note-taking, and precise interaction.
- **Magic Keyboard:** Provides a comfortable typing experience, a built-in trackpad, and acts as a protective cover.

3. OPERATING INSTRUCTIONS

3.1 iPadOS Navigation

iPadOS offers intuitive gesture-based navigation:

- **Home Screen:** Swipe up from the bottom edge of the screen.
- **App Switcher:** Swipe up from the bottom edge and pause in the middle of the screen.
- **Control Center:** Swipe down from the top-right corner of the screen.
- **Notifications:** Swipe down from the top-left corner or center of the screen.

3.2 Multitasking with Stage Manager

Stage Manager allows you to resize and overlap apps, providing a flexible multitasking experience. To activate, open Control Center and tap the Stage Manager icon. You can drag app windows to rearrange them or connect an external display for extended workspace.



3.3 Using Apple Pencil (2nd Generation)

If you have an Apple Pencil (2nd Generation), attach it magnetically to the side of your iPad Pro to pair and charge it. The Apple Pencil allows for precise drawing, writing, and annotation. Double-tap the side of the Pencil to switch between tools in supported apps.



Image 3.2: User interacting with iPad Pro using Apple Pencil.

3.4 Camera Functionality

The iPad Pro features advanced cameras:

- **Rear Cameras:** 12MP Wide and 10MP Ultra Wide cameras with Smart HDR 4. Supports 4K video recording at various frame rates (24, 25, 30, or 60 fps) with ProRes support.
- **Front Camera:** 12MP Ultra Wide TrueDepth camera with Center Stage, Portrait mode, Portrait Lighting, and Smart HDR 4. Center Stage automatically keeps you in the frame during video calls.

3.5 Face ID

Face ID allows you to securely unlock your iPad Pro, authenticate purchases in the App Store, iTunes Store, and Apple Books, and sign in to apps with a glance. Ensure your face is clear of obstructions and positioned correctly

in front of the TrueDepth camera.

4. MAINTENANCE

4.1 Battery Care

The iPad Pro offers up to 10 hours of web surfing on Wi-Fi or video playback, and up to 9 hours using a cellular data network. To maximize battery life:

- Keep iPadOS updated to the latest version.
- Adjust screen brightness.
- Use Wi-Fi instead of cellular data when possible.
- Limit background app refresh.

4.2 Cleaning Your iPad Pro

To clean your iPad Pro, use a soft, lint-free cloth. Avoid abrasive materials, aerosols, solvents, or ammonia-based cleaners. For the screen, a slightly damp cloth with water is generally sufficient. Disconnect all cables and power off the device before cleaning.

4.3 Software Updates

Regularly update your iPad Pro to the latest version of iPadOS to ensure optimal performance, security, and access to new features. Updates can be found in **Settings > General > Software Update**.

4.4 Storage Management

Your iPad Pro comes with 256GB of storage, with options up to 2TB. To manage storage, go to **Settings > General > iPad Storage**. Here you can identify apps and data consuming the most space and offload or delete unnecessary content.

5. TROUBLESHOOTING

If you encounter issues with your iPad Pro, try the following basic troubleshooting steps:

- **Device Unresponsive:** Press and quickly release the Volume Up button. Press and quickly release the Volume Down button. Then, press and hold the Top button until the Apple logo appears.
- **App Not Responding:** Force quit the app by swiping up from the bottom of the screen, pausing in the middle, then swiping the problematic app's preview upwards. Reopen the app.
- **Wi-Fi Connectivity Issues:** Go to **Settings > Wi-Fi** and turn Wi-Fi off and then on again. If the issue persists, restart your Wi-Fi router.
- **Charging Problems:** Ensure the USB-C cable and power adapter are securely connected and free from damage. Try a different power outlet.

For more complex issues, refer to the official Apple Support website or contact Apple Support directly.

6. SPECIFICATIONS

Feature	Detail
Model Name	iPad Pro

Feature	Detail
Item Model Number	MNXF3LL/A
Product Dimensions	0.23 x 7.03 x 9.75 inches (5.9 x 178.5 x 247.6 mm)
Item Weight	1.03 pounds (466 grams) Wi-Fi model
Display	11-inch Liquid Retina display with ProMotion technology and True Tone (2388 x 1668 Pixels)
Chip	Apple M2 chip (8-core CPU, 10-core GPU, 16-core Neural Engine)
Memory Storage Capacity	256 GB (Configurable up to 2TB)
Rear Cameras	12MP Wide and 10MP Ultra Wide with Smart HDR 4, 4K video (24, 25, 30, or 60 fps)
Front Camera	12MP Ultra Wide TrueDepth camera with Center Stage, Portrait mode, Portrait Lighting, Smart HDR 4
Battery Life	Up to 10 hours (Wi-Fi), Up to 9 hours (cellular data)
Connector	USB-C with support for Thunderbolt / USB 4
Batteries	1 Lithium Ion battery (included)
Date First Available	October 18, 2022

7. WARRANTY INFORMATION

Your Apple iPad Pro is covered by a limited warranty. Specific terms and conditions, including warranty duration and coverage details, are provided at the time of purchase and are available on the official Apple website. Please retain your proof of purchase for warranty claims.

8. SUPPORT

For additional support, technical assistance, or to access comprehensive user guides and FAQs, please visit the official Apple Support website:

support.apple.com/ipad

You can also contact Apple Support directly through their website for personalized assistance.