

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Ingenuity](#) /

› **Ingenuity Full Course 6-in-1 High Chair - Baby to 5 Years Old, 6 Convertible Modes, 2 Dishwasher Safe Trays - Astro, 13108 User Manual**

Ingenuity 13108

Ingenuity Full Course 6-in-1 High Chair

INSTRUCTION MANUAL - MODEL 13108

Introduction

Thank you for choosing the Ingenuity Full Course 6-in-1 High Chair. This versatile product is designed to adapt to your child's growth, offering six different modes from infancy through toddlerhood. Its easy-to-clean design ensures mealtime convenience, while robust safety features provide peace of mind. Please read this manual thoroughly before assembly and use to ensure proper operation and safety.

Safety Information

- Always use the safety harness to secure your child in the high chair.
- Never leave your child unattended in the high chair.
- Ensure the high chair is placed on a flat, stable surface.
- Keep children away from moving parts during assembly and adjustment.
- Do not use the high chair if any parts are broken, torn, or missing.
- Maximum weight capacity: 50 lbs (22.7 kg).
- Recommended age range: 6 months to 5 years.

Package Contents

Please verify that all components are present before beginning assembly:

- High Chair Frame (legs, seat support)
- Seat Pad with Harness
- Main Tray
- Feed Easy Mini Tray
- Wheels (pre-attached or separate)
- Instruction Manual

Setup and Assembly

Follow these steps to assemble your Ingenuity Full Course 6-in-1 High Chair:

- 1. Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
- 2. Assemble Frame:** Connect the leg sections as indicated in the diagrams, ensuring they click securely into place. The frame provides the base for all configurations.
- 3. Attach Seat Unit:** Align the seat unit with the frame's attachment points and push down firmly until it locks. Verify it is securely fastened.
- 4. Install Seat Pad:** Drape the fabric seat pad over the seat unit, threading the harness straps through the designated slots. Ensure the pad is smooth and wrinkle-free.
- 5. Attach Trays:** Slide the main tray onto the armrests until it clicks into position. The Feed Easy mini tray can be placed on top of the main tray for smaller portions.



Image: The fully assembled Ingenuity Full Course 6-in-1 High Chair in its standard high chair configuration.

Operating the High Chair (6 Modes)

The Ingenuity Full Course High Chair offers six versatile modes to accommodate your child's developmental stages:

1. **Infant High Chair:** For babies learning to eat solids. Use with the full seat and tray.
2. **Traditional High Chair:** Standard upright high chair for feeding.
3. **Chair Top Booster:** The seat unit detaches to strap securely onto a dining chair, allowing your child to join the family at the table.
4. **Dining Chair:** The high chair can be configured to allow an older child to sit at the table without the tray, using the chair's height.
5. **Toddler Seat:** The frame can be used as a standalone toddler chair.
6. **Two Kids at Once:** The booster seat and toddler seat can be used simultaneously to accommodate two children.

Key Features:

- **Tray Removal:** Both the main tray and the Feed Easy mini tray can be easily removed by pinching the release levers, making cleanup simple.
- **Harness System:** The 5-point safety harness ensures your child is securely fastened. Adjust straps for a snug fit and press the center button to release.
- **Recline Positions:** The seat offers 2 recline positions for optimal comfort during feeding or resting.
- **Mobility:** Equipped with 2 wheels for easy movement around your home.

6 grow with me feeding stages

1



2



3



4



5



6



Image: Visual representation of the six different configurations of the high chair, demonstrating its adaptability from infant to toddler stages.



Image: A close-up view of the secure 5-point safety harness buckle, highlighting the green release button for quick and easy unfastening.



Image: The main feeding tray with its integrated cup holder and the smaller Feed Easy mini tray, both designed for easy cleaning and convenience.

Maintenance and Cleaning

Proper maintenance ensures the longevity and hygiene of your high chair:

- **Fabric Seat Pad and Harness Straps:** These components are machine washable. Use cold water on a gentle cycle. Do not bleach. Air dry or tumble dry on low heat.
- **Trays:** Both the main tray and the Feed Easy mini tray are dishwasher safe. For manual cleaning, wash with mild soap and warm water.
- **Frame and Plastic Parts:** Wipe clean with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- **Regular Inspection:** Periodically check all screws, bolts, and fasteners to ensure they are tight and secure. Inspect for any signs of wear or damage.

Troubleshooting

Problem	Possible Cause	Solution
Tray does not attach securely.	Misalignment or debris in track.	Ensure tray is aligned with grooves; clear any food particles. Push firmly until it clicks.
Harness straps are too tight/loose.	Incorrect adjustment.	Adjust the strap length using the buckles until a snug, comfortable fit is achieved.
High chair feels unstable.	Not on a flat surface or loose connections.	Move to a flat, level surface. Check all frame connections and tighten if necessary.
Wheels not rolling smoothly.	Debris in wheels or locked.	Clear any hair or debris from wheel axles. Ensure wheel locks are disengaged.

Specifications

- **Brand:** Ingenuity
- **Model:** 13108
- **Color:** Astro
- **Material:** Plastic
- **Product Dimensions (Assembled):** 38.2"D x 21.7"W x 40.9"H (97.03 cm D x 55.12 cm W x 103.89 cm H)
- **Item Weight:** 18.77 Pounds (8.51 kg)
- **Recommended Age:** 6 months to 60 months (5 years)
- **Recommended Weight:** 6-20 lbs (3-9 kg) for infant use; up to 50 lbs (22.7 kg) for toddler use.



Image: A diagram illustrating the key dimensions (height, width, depth) of the high chair, along with its recommended weight and age ranges for safe use.

Warranty and Support

For warranty information, please refer to the documentation included with your purchase or visit the official Ingenuity website. If you require further assistance, have questions about assembly, or need to order replacement parts, please contact Ingenuity customer support through their official channels. Keep your purchase receipt for warranty claims. Additional protection plans may be available for purchase from retailers. Please inquire at the point of sale for details on extended coverage options.

