VGEBY Nouveau

VGEBY Electric Scooter Thumb Throttle User Manual

Model: Nouveau

1. Introduction

Thank you for choosing the VGEBY Electric Scooter Thumb Throttle. This manual provides essential information for the proper installation, operation, and maintenance of your new throttle. Designed for electric scooters, this thumb throttle offers precise speed control with a durable ABS construction.

Key Features:

- **Premium ABS Material:** Constructed from high-grade ABS plastic for durability and comfort.
- **Single-Button Design:** Simplifies operation for quick and easy speed adjustments.
- **Sensitive Control:** Provides responsive speed adjustment with a gentle push.
- **Raised Stripes:** Enhances grip and control, even in challenging conditions.
- **Easy Installation:** Designed for straightforward installation and removal.



Image: The VGEBY Electric Scooter Thumb Throttle highlighting its single-button operation and easy plug-and-play connector for installation.

2. Setup and Installation

The VGEBY Electric Scooter Thumb Throttle is designed for easy installation. Follow these steps to replace your old throttle or install a new one.

1. **Preparation:** Ensure your electric scooter is powered off and disconnected from any power source before beginning installation.
2. **Remove Old Throttle (if applicable):** Carefully disconnect the wiring of your existing throttle and unmount it from the handlebar. Note the wiring configuration if possible.
3. **Mount New Throttle:** Slide the VGEBY thumb throttle onto the handlebar in a comfortable and accessible position. Secure it firmly using any provided fasteners.
4. **Connect Wiring:** Connect the throttle's multi-pin connector to the corresponding port on your electric scooter's control system. Ensure the connection is secure and properly aligned. The standard connector allows for tool-free installation.
5. **Test Functionality:** After installation, power on your scooter and perform a low-speed test in a safe environment to ensure the throttle responds correctly.



Image: The multi-colored wiring connector of the VGEBY thumb throttle, indicating its plug-and-play design for easy connection.

3. Operating Instructions

The VGEBY Electric Scooter Thumb Throttle provides intuitive speed control for your electric scooter.

1. **Power On:** Ensure your electric scooter is powered on according to its manufacturer's instructions.
2. **Engage Throttle:** Gently press the thumb lever with your thumb to accelerate. The throttle is highly sensitive, allowing for fine adjustments to your speed.
3. **Speed Control:** Increase pressure on the thumb lever to increase speed, and release pressure to decrease speed. The raised stripes on the thumb pad provide a non-slip grip for better control.
4. **Braking:** To slow down or stop, release the thumb throttle and apply your scooter's brakes as needed.



Image: A hand demonstrating the operation of the VGEBY thumb throttle, showing the ergonomic design and single button for speed control.

Your browser does not support the video tag.

Video: A demonstration of the VGEBY Electric Scooter Thumb Throttle in use, showcasing its responsive speed control and ease of operation.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your VGEBY Electric Scooter Thumb Throttle.

- **Cleaning:** Wipe the throttle regularly with a soft, damp cloth to remove dust and dirt. Avoid using harsh chemicals or abrasive cleaners, as these can damage the ABS material.
- **Inspection:** Periodically check the throttle for any signs of wear, cracks, or damage to the housing or wiring. Ensure the thumb lever moves smoothly without obstruction.
- **Connections:** Verify that the electrical connections remain secure and free from corrosion.
- **Storage:** When not in use for extended periods, store your scooter in a dry, cool place away from direct sunlight and extreme temperatures.

5. Troubleshooting

If you encounter issues with your VGEBY Electric Scooter Thumb Throttle, refer to the following common troubleshooting

steps:

- **Throttle Not Responding:**
  - Check if the scooter is powered on.
  - Ensure all wiring connections are secure and properly seated.
  - Inspect the wiring for any visible damage or cuts.
- **Intermittent Operation:**
  - Verify that the connector is not loose.
  - Check for any debris or obstruction around the thumb lever mechanism.
- **Stiff or Sticky Lever:**
  - Clean the area around the thumb lever to remove any dirt or grime.
  - Ensure no external objects are impeding its movement.

If these steps do not resolve the issue, please contact customer support.

6. Specifications

Feature	Detail
Model Number	Nouveau
Material	Premium ABS
Item Weight	1.76 ounces
Package Dimensions	5.94 x 2.87 x 1.81 inches
Control Type	Single Button Thumb Throttle

7. Warranty and Support

For warranty information or technical support regarding your VGEBY Electric Scooter Thumb Throttle, please refer to the documentation provided with your purchase or contact the seller directly. Keep your proof of purchase for any warranty claims.

If you have questions about installation, operation, or troubleshooting that are not covered in this manual, please reach out to VGEBY customer service or the retailer from whom you purchased the product.

© 2023 VGEBY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question