

[manuals.plus](#) /› [Olayks](#) /› [Olayks 3L Portable Electric Hot Pot Instruction Manual](#)

## Olayks OLK-electric hot pot

# Olayks 3L Portable Electric Hot Pot Instruction Manual

Model: OLK-electric hot pot

## INTRODUCTION

The Olayks 3L Portable Electric Hot Pot is a versatile multi-functional cooker designed for various cooking methods, including hot pot, ramen, steak, and pasta. Its compact size and dual power settings make it ideal for dorms, homes, camping, travel, and office use. This manual provides essential information for safe and efficient operation, maintenance, and troubleshooting.

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions carefully before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the electric pot body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended household use.
- This appliance has overheating protection and boil-dry protection. If the pot runs dry or overheats, it will automatically shut off.

## PRODUCT OVERVIEW

The Olayks Electric Hot Pot features a compact design with a 3L capacity, suitable for 2-5 people. It includes a ceramic non-stick coating for easy cooking and cleaning, and a transparent lid for monitoring your food.



Figure 1: Olayks 3L Portable Electric Hot Pot with transparent lid and control knob.

## Key Components:

- **Main Pot Body:** Houses the heating element and cooking surface.
- **Transparent Lid:** Allows for easy monitoring of cooking progress.
- **Control Knob:** Used to select power settings (OFF, LOW, HIGH).
- **Power Cord:** Detachable for easy storage.
- **Handles:** Integrated on the sides for safe handling.

## SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Check the hot pot and accessories for any signs of damage. Do not use if damaged.
3. **Clean Before First Use:** Wipe the interior of the pot with a soft, damp cloth and mild detergent. Rinse thoroughly and dry completely. Do not immerse the main body in water.
4. **Placement:** Place the electric hot pot on a stable, flat, heat-resistant surface, away from flammable materials.
5. **Connect Power:** Ensure the control knob is in the "OFF" position before plugging the power cord into the pot and then into a suitable electrical outlet (110V).

# SUITABLE SIZE & DURABLE TO USE



High Quality Tempered Glass Lid



Multi-hole Heat Dissipation



Multi-hole Heat Dissipation

Figure 2: The hot pot's compact size and design for efficient heat dissipation.

## OPERATING INSTRUCTIONS

The Olayks Electric Hot Pot offers dual power settings for versatile cooking.

### Dual Power Adjustment:

- **LOW (500W):** Ideal for gentle cooking, simmering, or keeping food warm. Suitable for dishes like spaghetti, ramen, pancakes, and eggs.
- **HIGH (1000W):** Provides rapid heating for boiling, searing, or cooking larger quantities. Perfect for steak, soup, or hot pot.



Figure 3: The control knob allows selection between LOW (500W) and HIGH (1000W) power settings.

### General Cooking Steps:

1. Add desired ingredients and liquid to the pot. Do not overfill beyond the MAX fill line.
2. Place the transparent lid securely on the pot.
3. Turn the control knob to either "LOW" or "HIGH" depending on your cooking needs. The indicator light will illuminate.
4. Monitor cooking progress through the transparent lid.
5. Once cooking is complete, turn the control knob to "OFF" and unplug the appliance from the wall outlet.
6. Carefully serve the food. Use caution as the pot and its contents will be hot.

### Cooking Examples:

- **Hot Pot:** Add broth and desired ingredients (meats, vegetables, noodles). Use HIGH setting to bring to a boil, then LOW to simmer.
- **Ramen/Pasta:** Add water and bring to a boil on HIGH. Add noodles and cook until desired tenderness.
- **Steak/Sauté:** Add a small amount of oil, set to HIGH. Sear meat or sauté vegetables.

- **Eggs/Pancakes:** Use LOW setting for gentle cooking.



**Saute pan**



**Deep Fryer**



**Slower Cooker**



**Hot pot**



**Steamer**

Figure 4: The multi-use electric cooker can function as a sauté pan, deep fryer, slower cooker, hot pot, and steamer.

Your browser does not support the video tag.

Video 1: Official Olayks demonstration of the electric hot pot's various cooking capabilities, including deep frying, steaming, and preparing different meals.

## MAINTENANCE & CLEANING

Proper cleaning and maintenance will extend the life of your Olayks Electric Hot Pot.

- **Always unplug** the appliance and allow it to cool completely before cleaning.
- **Ceramic Non-Stick Coating:** The interior surface is made of a healthy, food-grade ceramic non-stick coating. This ensures food does not stick and makes cleaning easy.
- **Cleaning the Interior:** After use, rinse the electric pot with water. For stubborn stains, use a soft scouring pad or sponge with mild dish soap. Avoid abrasive cleaners or metal wire brushes as they can scratch the ceramic coating.

- **Cleaning the Exterior:** Wipe the exterior of the pot with a damp cloth. Do not immerse the main electric pot body, power cord, or plug in water or any other liquid.
- **Lid Cleaning:** The transparent lid can be washed with warm soapy water and rinsed thoroughly.
- **Storage:** Ensure the pot is completely dry before storing. Store in a cool, dry place.

## FOOD-GRADE NONSTICK POT FOR HEALTH COOKING



### Ceramic Glaze Non-stick Coating

Keeps food from sticking, environmentally friendly and safer.



### 8H ceramic glaze interior, can be clean with wire brush.

Just rinse the electric pot with water to make you easy to complete the cleaning.

**Tips:** Wipe the stain gently in the cleaning process.

Do not immerse the bottom into the water.



Figure 5: The ceramic non-stick interior allows for easy food release and simplifies cleaning with a soft cloth.

## TROUBLESHOOTING

If you encounter issues with your Olays Electric Hot Pot, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; control knob not set.	Ensure power cord is securely plugged into both the pot and a working wall outlet. Turn the control knob to "LOW" or "HIGH".

Problem	Possible Cause	Solution
Food is not heating or heating slowly.	Incorrect power setting; insufficient power; too much food/liquid.	Ensure the control knob is set to the appropriate power (HIGH for faster heating). Reduce the amount of food/liquid if necessary.
Pot automatically shuts off during use.	Overheating protection or boil-dry protection activated.	Unplug the pot and allow it to cool down. Check if there is enough liquid in the pot. Add more liquid if needed before restarting.
Food sticks to the bottom.	Insufficient oil/liquid; cooking at too high a temperature for too long without stirring.	Ensure adequate oil or liquid is used. Stir food regularly. Adjust power setting if necessary.

If the problem persists after attempting these solutions, please contact Olayks customer service for assistance.

## SPECIFICATIONS

Feature	Detail
Brand	Olayks
Model Number	OLK-electric hot pot
Capacity	3 Liters (3.2 Quarts)
Wattage	1000 watts (Dual power: 500W & 1000W)
Voltage	110V
Material (Inner Surface)	Ceramic Non-stick Coating
Product Dimensions	11.02"D x 11.02"W x 6.89"H
Item Weight	3.94 pounds
Control Method	Touch (Control Knob)
Safety Features	Overheating Protection, Boil Dry Protection

## WARRANTY AND SUPPORT

Olayks provides professional after-sales support for your product.

- Warranty:** This product comes with a one-year warranty from the date of purchase.
- Refund Policy:** A 30-day refund policy is available.
- Contact Support:** For any questions, concerns, or warranty claims, please contact the Olayks customer service team through the Amazon buyer center. Our team aims to provide a satisfactory solution within 24 hours.