

Heymell Voyage203

Heymell Remote Control User Manual for Soundbar Voyage203

Model: Voyage203 Remote Control

INTRODUCTION

This manual provides comprehensive instructions for the operation and maintenance of your Heymell Remote Control, specifically designed for the Heymell Soundbar Voyage203. Please read this manual carefully before use to ensure proper functionality and to maximize your product experience.

PRODUCT OVERVIEW



Figure 1: Heymell Remote Control for Voyage203 Soundbar. This image displays the remote control with its various buttons for power, input selection, volume, playback, and sound modes.

The Heymell Remote Control is an infrared (IR) remote designed to control the Heymell Soundbar Voyage203. It provides access to all essential functions of the soundbar, including power, volume, input selection, and various sound modes.

Button Functions

- **Power Button** (): Turns the soundbar on or off.
- **Mute Button** (): Mutes or unmutes the soundbar audio.
- **Input Selection Buttons:**
 - **BT**: Selects Bluetooth input.
 - **OPTICAL**: Selects Optical input.
 - **ARC/COA**: Selects ARC (Audio Return Channel) or Coaxial input.
 - **AUX/USB**: Selects Auxiliary or USB input.
- **Volume Up (+)**: Increases the volume level.

- **Volume Down (-)**: Decreases the volume level.
- **Previous Track ()**: Skips to the previous track (for compatible inputs like Bluetooth/USB).
- **Next Track ()**: Skips to the next track (for compatible inputs like Bluetooth/USB).
- **Play/Pause ()**: Plays or pauses media playback (for compatible inputs like Bluetooth/USB).
- **S1/S2**: Selects a specific sound mode or input preset.
- **MUSIC**: Activates Music sound mode.
- **MOVIE**: Activates Movie sound mode.
- **S-BASS**: Activates Super Bass mode for enhanced low frequencies.
- **NEWS/GAME**: Activates News or Game sound mode.
- **LOWER**: Adjusts a specific audio parameter, possibly related to bass or treble reduction.
- **BASS+**: Increases the bass level.
- **BASS-**: Decreases the bass level.
- **3D/LED OFF**: Activates 3D surround sound mode or turns off the soundbar's LED display.

SETUP

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals match the markings inside the compartment.
4. Close the battery cover securely.
5. **Note:** The remote control requires 2 AAA batteries (not included).

Initial Use

The Heymell Remote Control operates using infrared (IR) technology and typically does not require pairing. Once batteries are installed, point the remote directly at the Heymell Soundbar Voyage203 to control it.

OPERATING INSTRUCTIONS

Basic Functions

- **Power On/Off**: Press the **Power Button**.
- **Volume Adjustment**: Use the **Volume Up (+)** and **Volume Down (-)** buttons.
- **Mute/Unmute**: Press the **Mute Button**.
- **Input Selection**: Press the corresponding input button (**BT, OPTICAL, ARC/COA, AUX/USB**) to switch audio sources.

Sound Mode Selection

The Voyage203 Soundbar offers various sound modes to optimize your listening experience. According to product specifications, the Voyage203 has five distinct sound modes. Press the following buttons to select a desired mode:

- **MUSIC**: Ideal for listening to music.
- **MOVIE**: Enhances audio for movies.
- **NEWS/GAME**: Optimizes dialogue clarity for news or provides immersive sound for gaming.

- **S1/S2**: Selects additional sound presets.
- **S-BASS**: Engages a special bass enhancement mode.
- **BASS+ / BASS-**: Fine-tune the bass level to your preference.
- **3D/LED OFF**: Activates 3D surround sound or toggles the soundbar's LED display.

Note: The specific mapping of the five sound modes to the S1/S2 and NEWS/GAME buttons may require referring to your Heymell Soundbar Voyage203's main user manual for detailed functionality. The NEWS/GAME button may also function as a RESET button for certain settings.

MAINTENANCE

Battery Replacement

If the remote control's range decreases or buttons become unresponsive, it may be time to replace the batteries. Follow the battery installation steps outlined in the [Setup](#) section.

- Always replace both batteries at the same time.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the surface or internal components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries. Obstruction between remote and soundbar. Remote is too far from the soundbar.	Replace batteries, ensuring correct polarity. Remove any objects blocking the line of sight. Move closer to the soundbar.
Soundbar not responding to specific buttons.	Incorrect input selected. Feature not available for current input.	Ensure the correct input source is selected on the soundbar. Refer to the soundbar's manual for feature compatibility.
Intermittent control.	Low battery power. Interference from other devices.	Replace batteries. Ensure no strong light sources (e.g., direct sunlight, fluorescent lights) are interfering with the IR signal.

SPECIFICATIONS

- **Model**: Heymell Remote Control for Voyage203 Soundbar
- **Connectivity Technology**: Infrared (IR)
- **Compatible Devices**: Heymell Soundbar Voyage203 (and Voyage201 with minor button text differences)
- **Power Source**: 2 x AAA Batteries (not included)
- **Product Dimensions**: 5.71 x 1.77 x 0.79 inches (14.5 x 4.5 x 2 cm)
- **Item Weight**: 3.2 ounces (90.7 grams)

- **Manufacturer:** Heymell Tech

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your Heymell Soundbar Voyage203 or visit the official Heymell website. You may also contact Heymell customer service directly for assistance with your remote control.


Please note that this remote control is specifically designed for the Heymell Soundbar Voyage203. Compatibility with other models is not guaranteed, though it may function with the Voyage201 with some button label differences as noted in the product description.




© 2023 Heymell. All rights reserved.

Related Documents - Voyage203

<div>HEYMELL</div> <div>USER MANUAL</div> <div>Voyage 202 (White Noise Version) Voyage 203 (Standard Version, without White Noise) 2.0 Channel Soundbar</div> <div></div> <div>REVISIONEN/REVIZIONES REVISIONS/REVISIONS REVISIONES DEL DISEÑO MANUAL/USERMANUAL USERMANUAL</div>	<p>Heymell Voyage 202 & 203 2.0 Channel Soundbar User Manual</p> <p>User manual for the Heymell Voyage 202 (White Noise Version) and Voyage 203 (Standard Version) 2.0 Channel Soundbars. Provides setup, operation, remote control functions, connectivity options, and safety guidelines.</p>
<div>HEYMELL</div> <div>USER MANUAL</div> <div>Voyage 201 2.0 Channel Soundbar</div> <div></div> <div>01</div>	<p>Heymell Voyage 201 2.0 Channel Soundbar User Manual</p> <p>Comprehensive user manual for the Heymell Voyage 201 2.0 Channel Soundbar, covering setup, connections, remote control operation, TV settings, and specifications for optimal audio experience.</p>
<div>HEYMELL</div> <div>TroubleShooting</div> <div>How to Use Heymell Soundbar Fourth Version: 19/07/2022</div> <div>Design By Linghuijin (Shenzhen) Co., Ltd.</div>	<p>Heymell Soundbar Troubleshooting Guide</p> <p>A comprehensive troubleshooting guide for Heymell Soundbars, covering common issues such as no sound, connection problems, and audio quality.</p>
<div>HEYMELL</div> <div>USER MANUAL</div> <div>Voyage 202 (White Noise Version) Voyage 203 (Standard Version, without White Noise) 2.0 Channel Soundbar</div> <div></div> <div>REVISIONEN/REVIZIONES REVISIONS/REVISIONS REVISIONES DEL DISEÑO MANUAL/USERMANUAL USERMANUAL</div>	<p>Heymell Voyage 202 & 203 2.0 Channel Soundbar User Manual</p> <p>User manual for the Heymell Voyage 202 (White Noise Version) and Voyage 203 (Standard Version) 2.0 Channel Soundbars. Provides setup, operation, remote control functions, connectivity options, and safety guidelines.</p>

<div>HEYMELL</div> <div>USER MANUAL</div> <div>Voyage 201</div> <div>2.0 Channel Soundbar</div> <div></div>	<div>Heymell Voyage 201 2.0 Channel Soundbar User Manual</div> <div>Comprehensive user manual for the Heymell Voyage 201 2.0 Channel Soundbar, covering setup, connections, remote control operation, TV settings, and specifications for optimal audio experience.</div>
<div>HEYMELL</div> <div>TroubleShooting</div> <div>How to Use Heymell Soundbar</div> <div>Fourth Version: 19/07/2022</div> <div>Design By Linghuiyin (Shenzhen) Co., Ltd.</div>	<div>Heymell Soundbar Troubleshooting Guide</div> <div>A comprehensive troubleshooting guide for Heymell Soundbars, covering common issues such as no sound, connection problems, and audio quality.</div>

Documents - Heymell – Voyage203



[pdf] User Manual

Remote Control User Manual for Heymell Voyage203 Administrator Short press the key AUX USB to enter stereo connection if there is an U Disk in port hold it about 3 seconds be mode you can listen the A1er4c3j15Lm media amazon images I A1er4c3j15L ref dp product quick view |||

...

lang: score:20 filesize: 1.25 M page_count: 16 document date: 2024-12-02