

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Vente-unique](#) /
- › [Vente-unique YUKON Chandelier with 6 Glass Globes, Brushed Brass Finish - Instruction Manual](#)

Vente-unique YUKON

Vente-unique YUKON Chandelier with 6 Glass Globes, Brushed Brass Finish

Instruction Manual

1. INTRODUCTION

Thank you for purchasing the Vente-unique YUKON Chandelier. This elegant lighting fixture features a brushed brass finish and six clear glass globes, designed to enhance the aesthetic of your living space. This manual provides essential information for safe installation, operation, and maintenance of your new chandelier. Please read these instructions carefully before beginning installation and retain them for future reference.



Figure 1: Overview of the Vente-unique YUKON Chandelier.

2. SAFETY INFORMATION

WARNING: To avoid electric shock, always turn off the power at the main circuit breaker or fuse box before installation, servicing, or changing bulbs. Consult a qualified electrician if you are unsure about the installation process.

- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electrical Code (NEC).
- This fixture is designed for indoor use only.
- Do not exceed the maximum wattage specified for each bulb (25W E27).
- Handle glass components with care to prevent breakage.
- Keep flammable materials away from the light fixture.
- Always wear safety glasses during installation.

3. PACKAGE CONTENTS

Carefully unpack all components and check for any damage. Keep all packaging materials until you are satisfied with the product. The package should contain:

- Chandelier main body (brushed brass bar with bulb sockets)
- 6 Glass globes
- Mounting bracket and hardware (screws, wire nuts)
- Instruction Manual

Note: E27 light bulbs (max 25W each) are **not included** and must be purchased separately.

4. SETUP AND INSTALLATION

Before installation, ensure the power is turned off at the circuit breaker.

1. **Prepare for Installation:** Turn off the electricity at the main fuse box or circuit breaker. Clear the work area and gather necessary tools (screwdriver, wire strippers, electrical tape, ladder).
2. **Attach Mounting Bracket:** Secure the mounting bracket to the junction box in the ceiling using the provided screws. Ensure it is firmly attached.
3. **Wire the Fixture:** Connect the chandelier's wires to the house electrical wires. Match the black wire (live) from the fixture to the black wire from the ceiling, the white wire (neutral) from the fixture to the white wire from the ceiling, and the ground wire (green or bare copper) from the fixture to the ground wire from the ceiling. Secure connections with wire nuts and electrical tape.
4. **Mount the Chandelier:** Carefully lift the chandelier body and attach it to the mounting bracket, securing it with the canopy screws. Ensure all wires are tucked neatly into the junction box.
5. **Install Light Bulbs:** Screw six E27 bulbs (max 25W each, not included) into the sockets. Do not overtighten.
6. **Attach Glass Globes:** Carefully place each glass globe over its respective bulb and secure it according to the fixture's design (e.g., by screwing it onto a threaded ring or using retaining clips).



Figure 2: Detail of a glass globe and bulb installation.

5. OPERATING INSTRUCTIONS

Once the chandelier is fully installed and all connections are secure, restore power at the main circuit breaker. Operate the chandelier using your wall switch. The fixture is designed for standard on/off

functionality.



Figure 3: YUKON Chandelier installed in a dining room setting.

6. MAINTENANCE

- **Cleaning:** To clean the fixture, turn off the power and allow it to cool. Wipe the brushed brass finish with a soft, dry cloth. For glass globes, use a mild glass cleaner on a soft cloth. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Always turn off the power at the circuit breaker before replacing bulbs. Allow bulbs to cool completely before touching them. Unscrew the old bulb and replace it with a new E27 bulb (max 25W).
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on	<ul style="list-style-type: none">• Power is off at the circuit breaker• Loose wire connection• Faulty bulb	<ul style="list-style-type: none">• Check circuit breaker and wall switch• Verify all wire connections are secure (with power off)• Replace bulb

Problem	Possible Cause	Solution
Light flickers	<ul style="list-style-type: none">Loose bulbLoose wire connectionIncompatible dimmer switch (if applicable)	<ul style="list-style-type: none">Tighten bulbCheck wire connections (with power off)Ensure dimmer switch is compatible with LED bulbs (if using LED)
Glass globe is loose	Improperly secured globe	Carefully re-secure the glass globe.

8. SPECIFICATIONS

- Brand:** Vente-unique
- Model:** YUKON
- Material:** Brushed Brass, Glass
- Color:** Gold
- Dimensions (L x W x H):** 98 cm x 32 cm x 66.5 cm (38.6 in x 12.6 in x 26.2 in)
- Base Diameter:** 12 cm (4.7 in)
- Globe Diameter:** 15 cm (5.9 in)
- Weight:** 1.9 kg (4.2 lbs)
- Number of Bulbs:** 6
- Bulb Type:** E27 (not included)
- Max Wattage per Bulb:** 25W
- IP Rating:** IP20 (Indoor use only)

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the Vente-unique official website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

Vente-unique Customer Service: Please visit www.vente-unique.com for contact details and support resources.