**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## OLIGHT O-STATIV-GD-DE

# Olight Tripod Instruction Manual

Model: O-STATIV-GD-DE

## 1. Introduction

Thank you for choosing the Olight Tripod. This product is engineered to provide stable support for your Olight Olantern Classic Mini, Haloop, and Odiance devices, enhancing their versatility in various environments. Constructed from high-quality Lu-alloy with robust features, this tripod ensures reliable performance and ease of use. Please read this manual thoroughly before operation to ensure proper use and maintenance.

## 2. Safety Information

- Do not exceed the maximum load capacity of the tripod.
- Ensure all locking mechanisms are securely fastened before placing a device on the tripod.
- Avoid placing the tripod on unstable or uneven surfaces.
- Keep the tripod away from extreme temperatures and corrosive materials.
- Do not attempt to disassemble or modify the tripod, as this may void the warranty and cause damage.

## 3. Package Contents

Please check the package for the following items:

- Olight Tripod for Haloop (1 unit)



Figure 3.1: The Olight Tripod in its compact, folded configuration, ready for storage or transport.

## 4. Setup

### 4.1 Unfolding the Tripod

1. Gently pull the three legs outwards from the central body until they are fully extended.
2. Ensure each leg clicks into place, indicating it is securely locked in the open position.



Figure 4.1: The Olight Tripod with its legs folded, showing its compact form factor.

## 4.2 Attaching Your Device

1. Locate the 1/4-inch screw on the top of the tripod.
2. Align the corresponding 1/4-inch nut on your Olight Olantern Classic Mini, Haloop, or Odiance device with the tripod's screw.
3. Carefully screw your device onto the tripod until it is firmly secured. Do not overtighten.



Figure 4.2: The Olight Tripod with its legs extended, highlighting the 1/4-inch screw at the top for device attachment.

## 5. Operating

### 5.1 Adjusting Height and Angle

The Olight Tripod features a four-gear adjustment system for varying heights and angles:

- **Height Settings:** The tripod can be adjusted to heights of 150mm, 120mm, 80mm, and 27mm. To change the height, gently press the release buttons on each leg (if applicable, or simply adjust the leg angle) and reposition the legs to the desired setting. Ensure all legs are set to the same height for stability.
- **Ball Head:** The tripod is equipped with a ball head type mechanism, allowing for flexible adjustment of the attached

device's angle. Loosen the locking knob on the ball head, position your device as desired, and then tighten the knob to secure it.




Figure 5.1: An Olight Haloop lantern securely mounted on the tripod, demonstrating its practical application.

## 6. Maintenance

- Clean the tripod regularly with a soft, dry cloth.
- Avoid using abrasive cleaners or solvents, as these can damage the finish.
- Store the tripod in a dry, cool place when not in use.
- Periodically check all screws and joints for tightness and re-tighten if necessary.

## 7. Troubleshooting

### 7.1 Tripod Instability

- **Issue:** The tripod feels wobbly or unstable.
- **Solution:** Ensure all three legs are fully extended and locked into their respective positions. Verify that the tripod is placed on a flat, stable surface. Check that your device is securely attached to the 1/4-inch screw.

### 7.2 Difficulty Adjusting Legs

- **Issue:** Legs are stiff or difficult to adjust between height settings.
- **Solution:** Check for any debris or obstruction in the leg mechanisms. Clean the joints if necessary. Avoid forcing the adjustment; ensure the release mechanism is properly engaged.

## 8. Specifications

| Feature | Specification |
|---|---|
| Model Name | Tripod |
| Model Number | O-STATIV-GD-DE |
| Material | Metal (Lu-alloy) |
| Weight | 262 g |
| Maximum Height | 345 mm |
| Minimum Height | 27 mm |

| Feature | Specification |
|---|---|
| Adjustable Heights | 150mm, 120mm, 80mm, 27mm |
| Tripod Head Type | Ball Head |
| Mounting Screw | 1/4-inch |
| Compatible Devices | Olight Olantern Classic Mini, Haloop, Odiance |
| Package Dimensions | 16.6 x 5.9 x 5.2 cm |

## 9. Warranty and Support

### 9.1 Product Warranty

The Olight Tripod comes with a **1-year product warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

### 9.2 Customer Support

For technical support, warranty claims, or any questions regarding your Olight Tripod, please visit the official Olight website or contact Olight customer service through the details provided on their official channels. You can also visit the OLIGHT Store on Amazon for more information.

© 2025 OLIGHT. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0BJTDKCG6**

More documents and user manuals: **https://manuals.plus/**