

[Manuals.plus](#) /

> [Tajsoon](#) /

> Tajsoon Laundry Cart with Hanging Garment Rack, 4 Removable Laundry Bags, and Lockable Wheels (Model LCR74B)

Tajsoon LCR74B

Tajsoon Laundry Cart with Hanging Garment Rack

Model: LCR74B

INTRODUCTION

Thank you for choosing the Tajsoon Laundry Cart with Hanging Garment Rack. This manual provides essential information for the safe assembly, operation, and maintenance of your new laundry sorter. Please read these instructions carefully before use and retain them for future reference.

SAFETY INSTRUCTIONS

- Ensure all parts are securely fastened before use.
- Do not overload the garment rack or laundry bags beyond their stated capacity. The garment rack supports up to 44 lbs (20 kg). Each laundry bag has a capacity of 13 gallons (45 liters).
- Keep children and pets away from the product during assembly.
- Use the lockable wheels to secure the cart in place when not in motion.
- Avoid placing the cart in damp environments for extended periods to prevent rust.
- Do not climb on or hang from the garment rack.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Main Frame Components (various metal tubes and connectors)
- 4 Removable Laundry Bags
- 4 Swivel Casters (2 with locking mechanism)
- Assembly Hardware (screws, wrench)
- Instruction Manual

2-In-1 Laundry Sorter

Efficient all-in-one solutions to meet all your laundry needs



Image: Overview of the laundry cart's components, illustrating the 2-in-1 design with the hanging rack and the four-section sorter.

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps for proper assembly. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Identify each part using the provided parts list.
2. **Attach Casters:** Insert the four swivel casters into the designated holes at the bottom of the base frame. Ensure the two lockable casters are positioned at the front for easy access.
3. **Assemble Base Frame:** Connect the horizontal and vertical bars of the lower frame using the provided screws and wrench. Ensure all connections are tight.
4. **Install Laundry Bag Supports:** Attach the support bars for the laundry bags to the lower frame.
5. **Assemble Garment Rack:** Connect the vertical poles for the garment rack to the base frame. Then, attach the horizontal hanging bar to the top of the vertical poles. Ensure the extendable ends of the hanging bar are facing outwards.
6. **Insert Laundry Bags:** Place the four removable laundry bags into their respective compartments on the

frame. The bags feature metal handles for easy removal.

7. **Final Check:** Verify that all screws are tightened and the frame is stable.



Image: Details of the extendable hanging bar, robust frame connections, and convenient side pockets on the laundry bags.

OPERATING INSTRUCTIONS

Using the Garment Rack

The top bar serves as a hanging garment rack. It is ideal for air-drying clothes, hanging items directly from the dryer to prevent wrinkles, or temporarily storing garments. The bar is extendable on both sides, providing additional hanging space. Do not exceed the maximum weight capacity of 44 lbs (20 kg).

Using the Laundry Bags

The cart includes four individual laundry bags, each with a capacity of 13 gallons (45 liters). These bags are designed for sorting laundry by color or type (e.g., colors, towels, lights, darks). Each bag can be individually removed from the frame using its metal handles, making transport to the laundry room convenient. Some bags may include side pockets for storing small laundry accessories.



Laundry Sorter 4 Sections

- Clothes can be sorted by color or type



...

Image: The four-section laundry sorter with bags labeled for different laundry types, demonstrating its sorting capability.


Using the Wheels

The cart is equipped with four 360-degree swivel casters for easy mobility. Two of these wheels are lockable. To move the cart, unlock the wheels. To secure the cart in a stationary position, press down on the locking levers of the two lockable wheels until they click into place.

Enhance Your Laundry Experience



- Lockable Wheels



- High Density Non-Woven Fabric



Image: Detailed view of the lockable wheels and the high-density non-woven fabric used for the laundry bags.

MAINTENANCE

Frame Care

The metal frame features an anti-rust lacquered finish. To clean, wipe with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. Ensure the frame is dry after cleaning to prevent rust.

Laundry Bag Care

The laundry bags are made from durable polyester fabric. They can be spot cleaned with a mild detergent and water. For deeper cleaning, the bags may be hand washed or machine washed on a gentle cycle with cold water. Air dry only; do not tumble dry, as this may damage the fabric or lining. Ensure bags are completely dry before returning them to the frame.

TROUBLESHOOTING

- **Cart is wobbly:** Check all screw connections on the frame. Tighten any loose screws. Ensure the cart is on a flat, even surface.

- **Wheels not rolling smoothly:** Check for any debris or lint caught in the wheel mechanisms. Clean as necessary. Ensure wheels are unlocked if you intend to move the cart.
- **Laundry bag lining separating:** This can occur from improper washing or excessive force. Follow the laundry bag care instructions carefully.
- **Difficulty with assembly:** Review the assembly instructions carefully, paying close attention to the orientation of parts and attachment points. All parts are numbered for easy identification.

SPECIFICATIONS

Model Number	LCR74B
Dimensions (L x W x H)	94.5 cm x 39.9 cm x 169.9 cm (37.2 in x 15.7 in x 66.9 in)
Weight	6.45 kg (14.2 lbs)
Material	Polyester Fabric, Iron
Laundry Bag Capacity (each)	45 Liters (13 Gallons)
Number of Laundry Bags	4
Garment Rack Weight Capacity	20 kg (44 lbs)
Special Features	Lockable Wheels, Removable Bags, Extendable Garment Rack, Side Pockets

Product Size

● Unti: inch



32.4"




Image: Visual representation of the product's dimensions and capacities.

WARRANTY INFORMATION

Tajsoon products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or contact Tajsoon customer support. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Tajsoon customer support through the retailer where you purchased the product or visit our official website for contact information.

