

RG15B1/E

Instruction Manual for Generic RG15B1/E Infrared Remote Control

For Midea Room Air Conditioners (Models: MAW05M1BWT, MAW08R1BWT, MAW10R1BWT, MAW05R1BWT, MAW06R1BWT, MAW12R1BWT, MAW15R1BWT, MAW08V1DWT, MAW10V1DWT, MAW12V1DWT)

1. INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Generic RG15B1/E infrared replacement remote control. This remote is designed to be compatible with various Midea room air conditioner models as listed above. Please ensure your original remote matches the appearance of this replacement for full compatibility.

2. SETUP

2.1 Battery Installation

The remote control requires two (2) CR2 batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the release tab (if present) to open the compartment.
3. Insert two CR2 batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Back of the remote control with battery compartment. Note the separate wall mount bracket.

2.2 Initial Use

This replacement remote control does not require any programming or code setup. Once batteries are correctly installed, it is ready for use with compatible Midea air conditioner models.

3. OPERATING INSTRUCTIONS

Point the remote control directly towards the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the unit.

We Sell

Replace

- NOT Easy Broken
- Easy Hold
- NOT Easy Lost
- Easy to Operate
- Cheap Battery
- Reliable Quality
- Long Life

The black remote on the left has buttons for: ON/OFF (red), ECO, MODE, FAN+, TEMP, FAN-, LED, ENERGY SAVER, FAN/SPEED, SLEEP, AUTO, TIMER, and ONE TOUCH. The grey remote on the right has buttons for: ON/OFF, TIMER, FAN, MODE, TEMP., ECO, AUTO, LED, and SLEEP.

Figure 2: Front view of the remote control with button layout.

3.1 Button Functions

- **ON/OFF (Red Button):** Powers the air conditioner on or off.
- **MODE:** Cycles through operating modes (e.g., Cool, Fan, Dry, Heat, Auto).
- **TEMP ▲ / ▼:** Adjusts the temperature setting up or down.
- **FAN SPEED:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TIMER:** Sets the timer for automatic power on/off.
- **SLEEP:** Activates or deactivates the sleep mode for comfortable nighttime operation.
- **ECO:** Engages energy-saving mode.
- **LED:** Turns the display light on the air conditioner unit on or off.
- **AUTO:** Selects automatic operation mode based on room temperature.
- **ONE TOUCH:** Activates a pre-set comfort setting.

4. MAINTENANCE

4.1 Battery Replacement

Replace batteries when the remote control's range decreases or if the air conditioner does not respond to commands. Always replace both batteries simultaneously with new CR2 batteries. Do not mix old and new batteries or different types of batteries.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

5. TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are installed correctly with the correct polarity.
 - Replace old batteries with new ones.
 - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
 - Confirm the remote is pointed directly at the air conditioner.
- **Air conditioner functions incorrectly:**
 - Verify that your Midea air conditioner model is listed as compatible with this remote control.
 - Refer to your air conditioner's original manual for specific function details.

6. SPECIFICATIONS

- **Model:** RG15B1/E
- **Compatible Devices:** Midea Room Air Conditioners (specific models listed in title)
- **Connectivity Technology:** Infrared
- **Power Source:** 2 x CR2 Batteries (not included)

- **Special Feature:** Ergonomic design, direct replacement, no setup required.

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the seller or the original product documentation provided at the time of purchase. As a replacement part, specific warranty terms may vary.