Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OTOUCH E0043

OTOUCH E0043 Male Masturbator Cup Instruction Manual

Model: E0043

Introduction

This manual provides essential information for the safe and effective use, maintenance, and care of your OTOUCH E0043 Male Masturbator Cup. Please read this manual thoroughly before first use and retain it for future reference.



Figure 1: Main view of the OTOUCH E0043 Male Masturbator Cup, showcasing its sleek, white, cylindrical design with a textured exterior and a detailed view of the internal structure.

Safety Information

- **For adult use only.** Keep out of reach of children.
- Inspect the product for any damage before each use. Do not use if damaged.
- Clean the product thoroughly before and after each use as per the Maintenance section.
- Use only water-based lubricants with this product. Oil-based lubricants may damage the TPE material.
- Discontinue use immediately if any discomfort or irritation occurs.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

Product Overview

The OTOUCH E0043 is an accessory part designed for use with the DECOR2 system, featuring a unique internal texture for enhanced sensation. It is crafted from high-quality, skin-friendly Thermoplastic Elastomer (TPE).

Key Features:

- **Geometric 3D Texture:** The internal design features a grainy spiral 3D texture, engineered to provide a realistic and stimulating experience.
- **Skin-Friendly TPE Material:** Made from high-quality TPE, the cup is soft, highly elastic, and designed to mimic the feel of skin. This material is also easy to clean.
- **Discreet Design:** The product boasts an artistic appearance that makes it less identifiable as a masturbator, allowing for easier and more discreet storage.
- **Flexible Sizing:** The highly elastic material accommodates various sizes, with an insertable tunnel length of 12.8 cm, extendable up to 16.5 cm.




Figure 2: Detailed view of the internal 3D simulation tunnel, highlighting the granular silicone texture designed for enhanced sensation.




Figure 3: Illustration showing the dimensions of the OTOUCH E0043 (5 inches length, 2.6 inches width, 4.5 inches internal tunnel length, 2 inches internal tunnel width) and demonstrating its super stretchy TPE material, extending up to 17 inches.



Figure 4: Image emphasizing the medical-grade silicone material of the OTOUCH E0043, illustrating its soft, skin-like texture and hygienic properties.

Setup

1. **Unpack:** Carefully remove the OTOUCH E0043 from its packaging.
2. **Initial Cleaning:** Before first use, thoroughly wash the product with warm water and a mild, toy-safe soap. Rinse completely to remove all soap residue.
3. **Dry:** Allow the product to air dry completely or gently pat dry with a lint-free cloth.
4. **Lubricate:** Apply a generous amount of water-based lubricant to the entrance and internal tunnel of the masturbator cup for comfortable insertion.

Operating Instructions

The OTOUCH E0043 is designed for manual use and provides a unique tactile experience through its internal textures.

1. Ensure the product is clean and properly lubricated as per the Setup section.
2. Position the masturbator cup at the desired angle.

3. Slowly insert into the opening, allowing the flexible TPE material to conform.
4. Adjust grip and movement as desired to explore the internal textures and achieve preferred sensation.
5. After use, proceed to the Maintenance section for cleaning.

Maintenance

Proper cleaning and storage are crucial for the longevity and hygiene of your OTOUCH E0043.

1. **Immediate Cleaning:** Immediately after each use, rinse the product thoroughly under warm running water.
2. **Soap Application:** Apply a small amount of mild, toy-safe soap to the product. Gently rub the exterior and interior surfaces to remove any residue.
3. **Rinsing:** Rinse the product completely under warm running water until all soap and residue are gone. Ensure water flows through the entire internal tunnel.
4. **Drying:** Gently pat the product dry with a clean, lint-free cloth or allow it to air dry completely. Ensure no moisture remains, especially in the internal areas, to prevent bacterial growth.
5. **Storage:** Store the clean and dry product in a cool, dry, and discreet place, away from direct sunlight, extreme temperatures, and other toys made of different materials (especially silicone-based products, as TPE can react with some silicones).



Figure 5: Visual demonstration of cleaning the OTOUCH E0043 under running water, illustrating the ease of maintenance for this TPE product.

Troubleshooting

Problem	Possible Cause	Solution
Product feels sticky or oily after cleaning.	Residue from lubricant or insufficient rinsing.	Rinse thoroughly with warm water and mild soap. Ensure all lubricant is water-based.
Product feels too tight or uncomfortable.	Insufficient lubrication.	Apply more water-based lubricant to the entrance and internal tunnel.
Product shows signs of degradation (e.g., cracking, hardening).	Exposure to oil-based lubricants, harsh chemicals, or improper storage.	Discontinue use. Ensure only water-based lubricants are used and store properly.

Specifications

Attribute	Detail
Brand	OTOUCH
Model Number	E0043
Material	Thermoplastic Elastomer (TPE)
Colour	White
Product Dimensions (L x W x H)	6.3 x 6.3 x 12.7 cm (2.5 x 2.5 x 5 inches)
Internal Tunnel Length	12.8 cm (expandable up to 16.5 cm)
Weight	Approximately 340 grams
Date First Available	1 November 2022

Warranty and Support

For information regarding warranty coverage, product support, or to report any issues, please refer to the official OTOUCH website or contact the retailer from whom you purchased the product. Please have your model number (E0043) and purchase details ready when contacting support.
Note: Specific warranty terms and conditions may vary by region and retailer.

© 2024 OTOUCH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BJVFQFHZ

More documents and user manuals: **https://manuals.plus/**