

ROMP M0402691

ROMP Vibrating Bullet User Manual

Model: M0402691

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your ROMP Vibrating Bullet. Please read this manual thoroughly before first use and retain it for future reference.

The ROMP Vibrating Bullet is designed for personal use. It features a compact design and multiple vibration settings.

2. SAFETY INFORMATION

- Do not use if the product appears damaged.
- Discontinue use immediately if you experience any discomfort or pain.
- Keep out of reach of children.
- This product is for external use only.
- Consult a healthcare professional if you have any medical conditions or concerns before use.
- Do not immerse the product in water for extended periods, despite its water-resistant design.
- Use only the charging cable provided or a compatible charger.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x ROMP Vibrating Bullet (Model M0402691)
- 1 x USB Charging Cable
- 1 x User Manual (this document)

4. SETUP

4.1 Initial Charging

Your ROMP Vibrating Bullet contains a built-in Lithium Ion battery. For optimal performance, fully charge the

device before its first use.

1. Locate the charging port on the device.
2. Connect the provided USB charging cable to the device.
3. Plug the other end of the USB cable into a standard USB power adapter (not included) or a computer's USB port.
4. The indicator light will illuminate or flash during charging. Refer to the device's specific light patterns for charging status (e.g., solid light for fully charged, flashing for charging).
5. Charging typically takes approximately 1-2 hours. Disconnect the charger once fully charged.



Image: The ROMP Vibrating Bullet, showing its compact design and a typical charging port location. A USB charging cable is depicted connected to the device.

4.2 First Use Preparation

Before first use, clean the device as described in the "Maintenance" section.

5. OPERATING INSTRUCTIONS

The ROMP Vibrating Bullet is designed for intuitive operation.

5.1 Power On/Off

- To power on: Press and hold the power button (usually located on the base or side) for 2-3 seconds until the device vibrates or an indicator light illuminates.
- To power off: Press and hold the power button again for 2-3 seconds until the device stops vibrating and the indicator light turns off.

5.2 Changing Vibration Modes

Once powered on, short presses of the power button (or a dedicated mode button, if present) will cycle through the available vibration patterns and intensities. Experiment to find your preferred setting.

6. MAINTENANCE

6.1 Cleaning

Proper cleaning ensures hygiene and extends the product's lifespan. The manufacturer specifies "Hand Wash" for product care.

1. Always clean the device before and after each use.
2. Wash the device with warm water and a mild, toy-friendly soap.
3. Rinse thoroughly to remove all soap residue.
4. Dry completely with a lint-free cloth or allow to air dry before storing.
5. Do not use harsh chemicals, alcohol-based cleaners, or abrasive materials, as these can damage the product's surface.

6.2 Storage

Store the ROMP Vibrating Bullet in a clean, dry, and cool place, away from direct sunlight and extreme temperatures. Keep it separate from other toys or objects that could cause damage.

7. TROUBLESHOOTING

If you encounter issues with your ROMP Vibrating Bullet, refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided USB cable.
Device does not charge.	Faulty cable or power source.	Try a different USB port or power adapter. Ensure the cable is securely connected.
Vibrations are weak or inconsistent.	Low battery.	Recharge the device.
Device stops working unexpectedly.	Internal malfunction or low battery.	Ensure the device is fully charged. If the problem persists, contact customer support.

If these solutions do not resolve the issue, please contact ROMP customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	M0402691
Product Dimensions	2.95 x 2.36 x 5.12 inches
Item Weight	9.52 ounces
Battery Type	1 Lithium Ion battery (included)
Manufacturer	Lovehoney
Product Care	Hand Wash

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official ROMP website or contact the retailer from whom you purchased the product. Keep your proof of purchase for any warranty claims.

Manufacturer: Lovehoney

For further assistance, visit the [ROMP Store on Amazon](#).