Nine West NW/2098CHGB

Nine West Women's Crystal Accented Bracelet Watch Gold User Manual

Introduction Setup Operating Maintenance Warranty & Support Troubleshooting Specifications

1. Introduction

This manual provides instructions for the Nine West Women's Crystal Accented Bracelet Watch, Model NW/2098CHGB. This timepiece features a gold-tone finish, a domed mineral crystal lens, a light champagne dial with gold-tone hands, and crystal-accented markers. It is powered by Japanese quartz movement and designed for reliable timekeeping.



Front view of the Nine West Women's Crystal Accented Bracelet Watch in Gold.

2. Setup

2.1 Setting the Time

1. Locate the crown on the right side of the watch case.
2. Gently pull the crown outwards until you feel a click. This is the time-setting position.

3. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position to engage the movement and start the watch.





Side view of the watch, highlighting the crown for time adjustment.

2.2 Bracelet Adjustment

The watch features an adjustable link bracelet with a fold-over clasp and double push-button safety. The inner band circumference is approximately 7 inches. If the bracelet requires resizing (adding or removing links) for a comfortable fit, it is recommended to consult a professional jeweler or watch repair service. Attempting to adjust the bracelet without proper tools or experience may cause damage.

3. Operating Your Watch

Your Nine West watch is designed for simple and reliable timekeeping. Once the time is set as described in Section 2.1, the Japanese quartz movement will accurately display the current time. No further regular adjustments are typically needed unless the time zone changes or the battery needs replacement.

4. Maintenance

4.1 Cleaning

To maintain the appearance of your watch, wipe the case and bracelet periodically with a soft, dry cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the finish or crystal.

4.2 Water Resistance

This watch is rated as **Splash-resistant**, meaning it can withstand minor splashes or brief exposure to moisture. However, it is officially classified as **Not Water Resistant** for prolonged exposure. Do not submerge the watch in water, wear it while swimming, showering, or engaging in water sports. Exposure to excessive moisture can damage the internal components.

4.3 Battery Replacement

The watch requires one D battery (included). When the watch stops running, it indicates that the battery needs to be replaced. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.





Back view of the watch, showing the case back where the battery is housed.

5. Troubleshooting

5.1 Watch Not Running

- Ensure the crown is fully pushed in against the watch case. If it is pulled out, the watch will not run.

- If the watch still does not run, the battery may need replacement. Refer to Section 4.3 for battery replacement information.

5.2 Dust or Moisture Inside Watch Face

If you observe dust, condensation, or moisture inside the watch face, it indicates a potential issue with the watch's seal. Discontinue use immediately and seek professional watch repair to prevent further damage.

5.3 Bracelet Too Loose or Too Tight

For optimal comfort and fit, the bracelet may need adjustment. If the adjustable links are insufficient, professional link removal or addition may be required. Consult a jeweler for this service.

6. Specifications

Model Number	NW/2098CHGB
Brand	Nine West
Case Diameter	36 millimeters
Case Thickness	8 millimeters
Band Width	14 millimeters
Band Length	11 inches
Band Material Type	Metal
Crystal Type	Mineral
Watch Movement Type	Japanese Quartz
Display Type	Analog
Clasp Type	Push Button Foldover Clasp With Safety
Water Resistance Level	Not Water Resistant (Splash-resistant)
Power Source	Battery Powered (1 D battery included)
Item Weight	4 ounces
Product Dimensions	3.94 x 0.79 x 1.06 inches

7. Warranty & Support

This Nine West watch is covered by a manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your purchase or visit the official Nine West website. For product support, service, or inquiries, please contact Nine West customer service through their official channels.

8. Product Video

Your browser does not support the video tag.

Official manufacturer video showcasing the Nine West Women's Crystal Accented Gold-Tone Bracelet Watch.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question