

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [iHome](#) /

> [iHome PlayGlow+ Waterproof Bluetooth Speaker \(Model iBT820B\) User Manual](#)

## iHome iBT820B

# iHome PlayGlow+ Waterproof Bluetooth Speaker (Model iBT820B)

User Manual

## INTRODUCTION

The iHome PlayGlow+ iBT820B is a versatile waterproof Bluetooth speaker designed for portable audio enjoyment. Featuring dynamic 360° LED color modes, a robust IP67 waterproof and sandproof rating, and a long-lasting rechargeable battery, this speaker is ideal for various environments, from outdoor adventures to poolside relaxation. This manual provides essential information for setting up, operating, and maintaining your speaker.



Image: The iHome PlayGlow+ speaker illuminated with vibrant colors next to a swimming pool at night, showcasing its ambient lighting capabilities.

## WHAT'S IN THE BOX

Carefully unpack your iHome PlayGlow+ speaker. The package should contain the following items:

- iHome PlayGlow+ Waterproof Bluetooth Speaker (Model iBT820B)
- USB-C Charging Cable



Image: The iHome PlayGlow+ speaker in its retail packaging, highlighting key features such as Bluetooth range, battery life, and waterproof rating.

## CONTROLS AND FEATURES

---

The iHome PlayGlow+ speaker is equipped with intuitive controls and features for an enhanced user experience:

- **Power Button:** Located on the bottom of the speaker. Press and hold to power on/off.
- **Volume Controls (-/+):** Adjust the audio volume.
- **Play/Pause Button:** Control music playback.
- **Mode Button:** Cycle through various LED light modes.
- **Bluetooth Connectivity:** Wireless audio streaming up to 100 feet.
- **IP67 Waterproof & Sandproof:** Certified to withstand immersion in water and exposure to sand. The speaker is also floatable when the jack cover is fully closed.
- **Rechargeable Battery:** Provides up to 32 hours of wireless audio playback on a full charge.
- **USB-C Charging Port:** For convenient and fast charging.



## 360° LED COLOR MODES

---

- Slow Fade
- Color Change
- Favorite Color
- Pulse to Music
- Preset Pulse

Image: A collection of iHome PlayGlow+ speakers, each showcasing a different 360° LED color mode, illustrating the variety of lighting options available.



**Bluetooth  
Speaker**  
100ft Range

**32HR**

Rechargeable  
Mega Battery



**IP67**  
Waterproof  
& Sandproof

iHome



# PLAYGLOW+

## Waterproof Portable Speaker

Image: The iHome PlayGlow+ speaker partially submerged in water, demonstrating its IP67 waterproof and sandproof certification and floatable design.



**IP67 Certified**  
Waterproof  
and sandproof



**Floatable**  
In water with jack  
cover fully closed



Image: A hand holding the iHome PlayGlow+ speaker, with icons indicating its Bluetooth streaming capability and long-lasting rechargeable battery.

## SETUP

### Charging the Speaker

Before initial use, fully charge your iHome PlayGlow+ speaker. Use the provided USB-C charging cable to connect the speaker to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will show the charging status. A full charge can take several hours.

### Bluetooth Pairing

To connect your speaker to a Bluetooth-enabled device:

1. Ensure the speaker is powered off.
2. Press and hold the Power button (located on the bottom) until the speaker powers on and enters Bluetooth pairing mode. The Bluetooth indicator light will flash, indicating it is ready to pair.
3. On your audio device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "iHome PlayGlow+" from the list of devices.

5. Once paired, the Bluetooth indicator light on the speaker will turn solid, and you will hear an audible confirmation.

The speaker will automatically attempt to re-pair with the last connected device when powered on.

## OPERATING

---

### Power On/Off

- To power on: Press and hold the Power button until the speaker activates.
- To power off: Press and hold the Power button until the speaker deactivates.

### Music Playback

- **Play/Pause:** Press the Play/Pause button once to play or pause audio.
- **Volume Up:** Press the '+' button to increase volume.
- **Volume Down:** Press the '-' button to decrease volume.

### LED Light Modes

Press the Mode button (often indicated by a sun or flower icon) to cycle through the available 360° LED color modes:

- **No Color:** Lights are off, only audio plays.
- **Slow Fade:** Colors slowly transition from one to the next with smooth gradients.
- **Color Change:** The speaker cycles through 7 distinct solid colors.
- **Favorite Color:** To select a static color, cycle to the 'Color Change' mode, wait for your desired color to appear, then press the Mode button again. The speaker will hold that color.
- **Pulse to Music:** Lights change and pulse in sync with the rhythm of the music.
- **Preset Pulse:** A pre-programmed light show with changing gradients and patterns.

# iHome



**Bluetooth®**  
Stream audio wirelessly  
from up to 100 feet\*



**Rechargeable  
Battery**  
Up to **32** hours  
of wireless audio  
playback

Image: The iHome PlayGlow+ speaker displaying its diverse light modes, accompanied by icons representing Bluetooth connectivity, 360° LED color, and rechargeable battery.

## MAINTENANCE

To ensure the longevity and optimal performance of your iHome PlayGlow+ speaker:

- Always ensure the USB-C charging port cover is securely closed when using the speaker near water or sand to maintain its IP67 rating.
- Clean the speaker with a soft, damp cloth. Avoid using abrasive cleaners or solvents.
- Do not expose the speaker to extreme temperatures (hot or cold) for extended periods.
- Store the speaker in a cool, dry place when not in use.

## TROUBLESHOOTING

If you encounter issues with your iHome PlayGlow+ speaker, refer to the following common problems and solutions:

Problem	Solution
---------	----------

Problem	Solution
Speaker will not turn on.	Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable.
Cannot pair via Bluetooth.	Make sure the speaker is in pairing mode (flashing Bluetooth indicator). Ensure your device's Bluetooth is enabled and within range. Forget the device on your phone and try pairing again.
No sound or low volume.	Check the volume levels on both the speaker and your connected device. Ensure the speaker is properly paired.
LED lights are not working.	Press the Mode button to cycle through the light modes. Ensure the speaker is powered on.

## SPECIFICATIONS

---

- **Brand:** iHome
- **Model Number:** iBT820B
- **Connectivity:** Bluetooth, USB
- **Water Resistance:** IP67 Certified Waterproof & Sandproof
- **Battery Life:** Up to 32 hours
- **Bluetooth Range:** Up to 100 feet
- **Speaker Type:** Outdoor, Portable
- **Control Method:** Touch buttons
- **Charging Port:** USB-C

## WARRANTY AND SUPPORT

---

The iHome PlayGlow+ speaker comes with a limited warranty. For detailed warranty information or technical support, please refer to the warranty card included with your product or visit the official iHome website. Keep your purchase receipt as proof of purchase for warranty claims.