

[Manuals.plus](#) /

› [Oragerju](#) /

› Oragerju BG573 Portable 2-in-1 Handheld Steamer and Iron User Manual

## Oragerju BG573

# Oragerju BG573 Portable 2-in-1 Handheld Steamer and Iron User Manual

Model: BG573

## INTRODUCTION

---

This manual provides essential instructions for the safe and efficient operation of your Oragerju BG573 Portable 2-in-1 Handheld Steamer and Iron. Please read this manual thoroughly before first use and retain it for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

---

- Always ensure the voltage matches your power supply.
- Do not immerse the steamer in water or other liquids.
- Keep out of reach of children and pets.
- Use only distilled or purified water to prevent mineral buildup.
- Do not touch the hot steam outlet or soleplate during operation or immediately after use.
- Unplug the appliance when not in use and before cleaning.
- Never pull the cord to disconnect from the outlet. Grasp the plug.
- Do not operate with a damaged cord or plug.
- Do not direct steam at people, animals, or electrical appliances.
- Ensure the water tank is securely attached before use.
- The steamer has an auto shut-off feature for safety; however, always unplug after use.

## PACKAGE CONTENTS

---

- 1x Oragerju BG573 Portable Steamer for Clothes
- 1x User Manual (this document)
- 1x Measuring Cup

## PRODUCT OVERVIEW

Familiarize yourself with the components of your Oragerju BG573 steamer:



Figure 1: Key components of the Oragerju BG573 Portable Steamer.

### Components:

- **Preheat Indicator:** Shows the heating status.
- **Steam Outlet Nozzle:** Emits steam for wrinkle removal.
- **170ML Detachable Water Tank:** Holds water for steaming.
- **Foldable Handle:** Allows for compact storage and travel.
- **5.9ft Cable:** Power cord.
- **Power Button:** For standby and adjusting steam modes.
- **Steam Button:** Activates steam; press twice for intermittent, long press for continuous.

## SETUP AND FIRST USE

1. **Remove Water Tank:** Gently pull out the detachable water tank from the main unit.
2. **Fill Water Tank:** Using the provided measuring cup, fill the water tank with distilled or purified water up to the 170ml MAX line. Do not overfill.
3. **Reattach Water Tank:** Securely insert the filled water tank back into the steamer until you hear a click.
4. **Plug In:** Connect the power cord to a standard electrical outlet. The preheat indicator light will flash red.
5. **Power On:** Press the Power Button. The steamer will enter standby mode, and the red light will flash.



Figure 2: Visual guide for preparing and using the steamer.

## OPERATING INSTRUCTIONS

### Preheating and Steam Modes

After plugging in and powering on, the steamer will begin preheating. This takes approximately 15 seconds. The indicator light will change color to show readiness and selected steam mode.

- **Red Light (Flashing):** Power on, standby, or auto shut-off state.
- **Blue Light (Solid):** High steam mode selected. Ideal for thicker fabrics and stubborn wrinkles (20g/min steam flow).
- **Green Light (Solid):** Low steam mode selected. Suitable for thin fabrics and delicate materials (12g/min steam flow).

To switch between steam modes, press the Power Button. The default mode upon boot-up is high steam (blue light).

# Why Choose our Garment Steamer



VS



## OURS

1200W

15S Heating Time

2 Steam Modes

170ml Detachable Water Tank, Foldable Handle

Flat & Hanging Ironing

No Tipping & No Spitting

Automatic power off

## OTHERS

700W

130S Heating Time

One Steam Mode

120ml Tank, Non-foldable

Flating Ironing

Spit/drip Hot Water

Manual turn off

Figure 3: High and Low Steam Modes for various fabrics.

## Activating Steam

- Once the indicator light stops flashing (preheating complete), press the Steam Button.
- For **continuous steam**, press and hold the Steam Button for more than 3 seconds.
- For **bursting steam** (intermittent), quickly press the Steam Button twice.

## Steaming Techniques

The Oragerju BG573 supports both vertical and horizontal steaming.

# 2 in 1 Steaming

1200w Power, 15s Fast Heat-up



Figure 4: Vertical and Horizontal Steaming Methods.

- **Vertical Steaming:** Hang the garment on a hanger. Hold the steamer upright and move it slowly over the fabric, allowing the steam to penetrate.
- **Horizontal Steaming/Ironing:** Place the garment on a flat, heat-resistant surface. Use the steamer like an iron, pressing the soleplate gently against the fabric while emitting steam.

## Auto Shut-Off Feature

For safety, the steamer will automatically shut off if left idle for 8 minutes after preheating without the steam switch being activated. The red light will flash to indicate this state. Unplug the power supply when not in use.

## MAINTENANCE

---

### Cleaning

- Always unplug the steamer and allow it to cool completely before cleaning.

- Empty any remaining water from the tank after each use.
- Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- If mineral buildup occurs in the steam outlet, gently wipe with a cotton swab dampened with white vinegar, then wipe with a clean, damp cloth.

## Storage

- Ensure the steamer is completely cool and dry before storing.
- The handle can be folded for compact storage.
- Store the steamer in a cool, dry place, away from direct sunlight and moisture.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No steam or weak steam	Water tank empty; Not preheated; Mineral buildup; Water tank not properly seated.	Refill water tank; Wait for indicator light to become solid; Clean steam outlet; Reattach water tank securely.
Water leaking/spitting	Overfilled water tank; Steamer not fully preheated; Using tap water.	Do not overfill; Wait for indicator light to become solid; Use distilled or purified water.
Steamer not turning on	Not plugged in; Power outlet issue; Auto shut-off activated.	Check power connection; Try a different outlet; Press Power Button to reactivate.
Indicator light flashing red after 8 minutes	Auto shut-off engaged due to inactivity.	Unplug the unit. If you wish to continue steaming, press the Power Button to restart the preheating cycle.

## SPECIFICATIONS

- **Model:** BG573
- **Power:** 1200W
- **Voltage:** 120 Volts
- **Heat-up Time:** Approximately 15 seconds
- **Water Tank Capacity:** 170ml
- **Continuous Steaming Time:** Up to 18 minutes (Low Mode)
- **Product Dimensions:** 4.3"L x 2.1"W x 10"H
- **Item Weight:** 1.6 Pounds
- **Steam Modes:** Low (12g/min), High (20g/min)
- **Safety Features:** Auto Shut-Off

## WARRANTY AND SUPPORT

Oragerju provides a **1-year worry-free warranty** for this product. For any problems, suggestions, or support inquiries, please contact Oragerju customer service via email. A 24-hour email contact service is available to assist you. Please refer to your purchase documentation for specific contact details or visit the official Oragerju website.

## ENVIRONMENTAL PROTECTION

At the end of its service life, do not dispose of this appliance with normal household waste. Please take it to a designated collection point for the recycling of electrical and electronic equipment. This helps protect the environment.

