

[Manuals.plus](#) /

> [Kapbom](#) /

> Kapbom KA685 Wireless Keyboard and Mouse User Manual

Kapbom KA685

Kapbom KA685 Wireless Keyboard and Mouse User Manual

Model: KA685

INTRODUCTION

This manual provides instructions for the Kapbom KA685 Wireless Keyboard and Mouse combo. This slim, 2.4GHz wireless input device is designed for use with computers, laptops, and notebooks, offering a smooth, quiet, and fast typing experience.



Image: Close-up view of the Kapbom KA685 wireless keyboard, highlighting the slim, white keys on a silver base.

PACKAGE CONTENTS

- 1 x Wireless Keyboard
- 1 x Wireless Mouse
- 1 x USB Receiver

Note: Batteries are not included and must be purchased separately.

SETUP

1. Battery Installation

The keyboard requires 2 AAA batteries, and the mouse requires 1 AA battery. Ensure correct polarity when inserting batteries.

- **Keyboard:** Open the battery compartment located on the underside of the keyboard. Insert 2 AAA batteries.
- **Mouse:** Open the battery compartment on the underside of the mouse. Insert 1 AA battery.



Image: The underside of the Kapbom KA685 keyboard, illustrating the battery compartment for two AAA batteries and the storage slot for the USB receiver.

2. USB Receiver Connection

1. Locate the USB receiver, which is typically stored within the keyboard's battery compartment or a dedicated slot.
2. Plug the USB receiver into an available USB port on your computer.
3. The system should automatically detect and install the necessary drivers. No manual driver installation is usually required.

OPERATING INSTRUCTIONS

Once the batteries are installed and the USB receiver is connected, the keyboard and mouse should be ready for use.

- Ensure any power switches on the keyboard and mouse (if present, usually on the underside) are in the 'ON' position.
- The devices will automatically connect to your computer via the 2.4GHz wireless signal.
- Begin typing with the keyboard and navigating with the mouse.

FEATURES

2.4GHz Wireless Technology

The Kapbom KA685 utilizes advanced 2.4GHz wireless technology, providing a strong, reliable, and secure connection with an extended operating range and reduced interference from other wireless devices.

Slim Design Keyboard

The keyboard features a slim profile and thin keys, designed to provide a smooth, quiet, and efficient typing experience, enhancing comfort and speed.

Adjustable DPI Mouse

The optical mouse offers three adjustable DPI (Dots Per Inch) levels: 800, 1200, and 1600. This allows you to customize cursor sensitivity to suit different tasks, from precise work to faster navigation. Press the DPI button on the mouse to cycle through these settings.

Silent Click Mouse

The mouse is equipped with silent click buttons, significantly reducing clicking noise. This feature is beneficial for maintaining a quiet work environment, especially in shared spaces.



Image: An illustration detailing the Kapbom KA685 mouse's features, including three adjustable DPI settings (800, 1200, 1600) and its silent click mechanism, shown with a sleeping baby to emphasize quiet operation.

MAINTENANCE

Battery Replacement

When the keyboard or mouse performance degrades (e.g., delayed response, intermittent connection), it is time to replace the batteries. The keyboard can operate for up to 12 months on a fresh set of AAA batteries.

Cleaning

To clean the keyboard and mouse, use a soft, dry, lint-free cloth. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the device. Avoid harsh chemicals or abrasive materials.

TROUBLESHOOTING

- **No response from keyboard or mouse:**

Check if the batteries are correctly installed and have sufficient charge. Replace batteries if necessary. Ensure the USB receiver is securely plugged into a working USB port on your computer. Try plugging the receiver into a different USB port. Make sure any power switches on the devices are turned 'ON'.

- **Lagging or intermittent connection:**

Move the keyboard and mouse closer to the USB receiver. Avoid placing the receiver near large metal objects or other wireless devices (like Wi-Fi routers, cordless phones) that may cause interference.

- **Mouse cursor moves erratically:**

Ensure the mouse sensor is clean and free from debris. Use the mouse on a clean, non-reflective surface. Adjust the DPI setting to a lower value if the cursor is too sensitive.

SPECIFICATIONS

Model	KA685
Connectivity	2.4GHz Wireless
Keyboard Batteries	2 x AAA (not included)
Mouse Batteries	1 x AA (not included)
Mouse DPI Levels	800, 1200, 1600
Keyboard Dimensions (approx.)	28.5 cm (Length) x 13.5 cm (Width)
Mouse Dimensions (approx.)	11.5 cm (Length) x 2 cm (Height)
Manufacturer	Kapbom
ASIN	B0BK2Q3XM5



Image: Diagram showing the approximate dimensions of the Kapbom KA685 wireless keyboard (28.5cm x 13.5cm) and mouse (11.5cm x 2cm).

WARRANTY AND SUPPORT

This Kapbom KA685 Wireless Keyboard and Mouse combo comes with a **3-month warranty** provided by the supplier.

For warranty claims, technical assistance, or any product-related inquiries, please contact your original retailer or the supplier directly. Please retain your proof of purchase for warranty validation.

© 2023 Kapbom. All rights reserved.