

[Manuals.plus](#) /

› [Haofy](#) /

› Haofy Main Roller Brush Replacement for Dreame H11 and H11 Max Vacuum Cleaners Instruction Manual

Haofy Haofyubct5s8fw2

Haofy Main Roller Brush Replacement for Dreame H11 and H11 Max Vacuum Cleaners

Instruction Manual

1. INTRODUCTION

This document provides comprehensive instructions for the Haofy Main Roller Brush, a high-quality replacement component designed to restore and enhance the cleaning performance of your Dreame H11 or H11 Max vacuum cleaner.

Crafted from durable ABS material, this roller brush features a soft texture that effectively cleans floor surfaces without causing damage. Its precise design ensures a perfect fit and easy installation, contributing to a healthier indoor environment by reducing dust and pollen.

Compatibility

This roller brush is specifically designed for use with **Dreame H11** and **Dreame H11 Max** vacuum cleaner models.

Suitable for Dreame H11, H11 Max




Image 1: The Haofy Main Roller Brush shown with a compatible Dreame H11 Max vacuum cleaner, highlighting its suitability for these models.

2. SETUP: INSTALLATION INSTRUCTIONS

The Haofy Main Roller Brush is engineered for straightforward installation and removal, allowing users to easily replace worn or damaged brushes.

Installation Steps:

1. Ensure your Dreame H11 or H11 Max vacuum cleaner is powered off and unplugged before beginning any maintenance.
2. Locate the brush compartment on the underside of your vacuum cleaner. Refer to your vacuum cleaner's original manual for specific instructions on accessing this compartment.
3. Open the brush compartment cover. This usually involves releasing a latch or pressing a button.
4. Carefully remove the old roller brush. You may need to gently pull it out from its housing.
5. Insert the new Haofy Main Roller Brush into the compartment, aligning the ends with the designated slots. Ensure it clicks securely into place.
6. Close the brush compartment cover until it latches firmly.
7. Your vacuum cleaner is now ready for use with the new roller brush.




Image 2: A detailed view of the roller brush's end mechanism, illustrating how it connects to the vacuum cleaner's drive system for secure installation.

3. OPERATING: FUNCTIONALITY AND BENEFITS

Once installed, the Haofy Main Roller Brush operates as an integral part of your Dreame H11 or H11 Max vacuum cleaner's cleaning system.

Its soft texture is optimized for effective cleaning across various floor types, including hard floors and carpets, without causing scratches or damage. The brush efficiently agitates and collects debris, dust, and pet hair, directing them into the vacuum's suction path.

Regular use of a properly functioning roller brush is crucial for maintaining the vacuum cleaner's optimal cleaning efficiency and for reducing the presence of airborne allergens like dust and pollen in your home.



Soft texture, will not harm the floor surface

Improve the cleaning efficiency of the vacuum cleaner
Easy to remove and replace

Image 3: A user operating a Dreame H11 Max vacuum cleaner, demonstrating the roller brush's function during routine cleaning.

4. MAINTENANCE

To ensure the longevity and peak performance of your Haofy Main Roller Brush and vacuum cleaner, regular maintenance is recommended.

Cleaning the Brush:

1. Periodically remove the roller brush from the vacuum cleaner as described in the 'Setup' section.
2. Inspect the brush for tangled hair, threads, or accumulated debris. Use scissors or a brush cleaning tool (often supplied with vacuum cleaners) to carefully cut and remove any obstructions.
3. Wipe the brush and its housing with a damp cloth to remove dust and dirt. Ensure the brush is completely dry before re-installing it.
4. Do not submerge the roller brush in water unless specifically instructed by your vacuum cleaner's manual, as this may damage internal components.

Replacement:

The roller brush is a wear-and-tear component. Its lifespan depends on usage frequency and the types of surfaces cleaned. Replace the brush when you notice a decrease in cleaning performance, visible wear on the bristles, or if the brush becomes damaged. Refer to the 'Setup' section for instructions on how to replace the roller brush.





Image 4: A complete view of the Haofy Main Roller Brush, useful for visual inspection during cleaning and maintenance.

5. TROUBLESHOOTING

If you encounter issues after installing the Haofy Main Roller Brush, consider the following common troubleshooting steps:

Brush Not Spinning:

- Ensure the brush is correctly installed and securely latched into its compartment.
- Check for any obstructions (hair, debris) preventing the brush from rotating freely. Clean as per the 'Maintenance' section.
- Verify that the vacuum cleaner itself is functioning correctly and receiving power.

Reduced Cleaning Performance:

- Confirm the brush is clean and free of debris.
- Ensure the brush is not excessively worn. If bristles are flattened or missing, replacement may be necessary.
- Check other vacuum components, such as filters and dustbin, for blockages or fullness, as these can also affect suction.

Unusual Noise:

- Remove the brush and inspect it for any damage or foreign objects lodged within the brush or its bearings.
- Ensure the brush is installed correctly and not rubbing against any part of the vacuum housing.

6. SPECIFICATIONS

Attribute	Detail
Brand	Haofy

Model	Haofyubct5s8fw2
Material	ABS
Weight	Approximately 130 grams
Dimensions (Brush)	Approximately 246mm (length) x 48mm (diameter)
Compatibility	Dreame H11, Dreame H11 Max Vacuum Cleaners



Image 5: The Haofy Main Roller Brush with key dimensions (length 246mm, diameter 48mm) indicated for reference.

7. WARRANTY AND SUPPORT

Warranty Information:

Specific warranty details for this replacement part may vary. Please refer to the retailer's return policy or contact Haofy customer support for detailed warranty information.

Customer Support:

For any questions, concerns, or assistance regarding your Haofy Main Roller Brush, please contact Haofy customer service. We aim to provide a satisfactory response within 24 hours.

You can typically find contact information on the [Haofy brand store page](#) or through your purchase platform.