

[Manuals.plus](#) /

> [DiDimo](#) /

> DiDimo 1.5L Electric Hot Pot Instruction Manual (Model DZ11)

## DiDimo DZ11

# DiDimo 1.5L Electric Hot Pot Instruction Manual

Model: DZ11

---

## INTRODUCTION

---

Thank you for choosing the DiDimo 1.5L Electric Hot Pot. This versatile appliance is designed for convenient and efficient cooking of various meals, including ramen, pasta, eggs, soup, and oatmeal. Its compact and portable design makes it ideal for small kitchens, dormitories, offices, and travel. Please read this manual thoroughly before use to ensure safe and optimal operation.



*Image: The DiDimo 1.5L Electric Hot Pot, showcasing its compact design and a meal being prepared.*

## SAFETY INFORMATION

- **Electrical Safety:** Ensure the power plug is fully inserted into a grounded outlet. Do not immerse the main body of the hot pot in water or any other liquid to avoid electrical shock.
- **Overheat Protection:** The hot pot is equipped with automatic overheat protection, which will shut off the appliance if it detects excessive temperature.
- **Boil-Dry Protection:** The appliance also features boil-dry protection, automatically turning off if the water level is too low to prevent damage.
- **Handle with Care:** The exterior of the hot pot may become hot during operation. Always use the anti-scald handle when moving the appliance.
- **Supervision:** Do not leave the appliance unattended while in use, especially when cooking at high temperatures.



Image: Ensure the power plug is fully inserted for safe operation.



Image: The hot pot includes overheat and dry-boil protection for user safety.

## PRODUCT OVERVIEW

### Components:

- **Pot Body:** Stainless steel interior with a non-toxic coating.
- **Glass Upper Cover:** Transparent lid for monitoring cooking progress.
- **Anti-Scald Handle:** Ergonomically designed for safe handling.
- **Fire Knob (Control Dial):** For selecting power settings (OFF, 1, 2).
- **Steamed Egg Rack:** A BPA-free accessory for steaming eggs.
- **Power Cord:** Detachable power cord.



Image: Exploded view of the hot pot components.

## Power Settings:

- **Setting 1 (200W):** Low power for simmering, slow cooking, or keeping food warm. Ideal for soups, porridge, and eggs.
- **Setting 2 (600W):** High power for rapid boiling and quick cooking. Perfect for ramen, pasta, dumplings, and hot pot.




Image: The dual power settings allow for versatile cooking.

## SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Initial Cleaning:** Before first use, clean the interior of the pot body and the glass lid with warm, soapy water. Rinse thoroughly and dry. Do not immerse the main pot body in water.
3. **Placement:** Place the hot pot on a stable, flat, and heat-resistant surface.
4. **Connect Power:** Insert the power cord securely into the hot pot's power inlet, then plug the cord into a standard electrical outlet.

## OPERATING INSTRUCTIONS

### General Cooking Steps:

1. Add desired ingredients and liquid to the pot. Ensure the liquid level is between the MIN and MAX marks inside the pot.
2. Place the glass lid on the pot.
3. Turn the control dial to the desired power setting (1 for low, 2 for high). The indicator light will illuminate.
4. Once cooking is complete, turn the control dial to "OFF" and unplug the appliance.

### Cooking Eggs:

1. Place the egg rack inside the pot.
2. Carefully place eggs into the egg rack.
3. Add water to cover the eggs, ensuring it is between MIN and MAX levels.
4. Set the control dial to Setting 2 (600W) for boiling.
5. Once cooked to your preference, turn to "OFF" and carefully remove the egg rack using the handle.



Image: The hot pot is suitable for various environments, from dorms to travel.

Your browser does not support the video tag.

*Video: A demonstration of the DiDimo Electric Hot Pot in use, showing its functionality and ease of preparing meals like ramen.*

## MAINTENANCE

1. **Cleaning:** After each use, unplug the hot pot and allow it to cool completely. Wipe the interior with a soft sponge and mild dish soap. Rinse thoroughly with water, ensuring no water enters the electrical components. Wipe the exterior with a damp cloth.
2. **Drying:** Ensure all parts are completely dry before storing.
3. **Storage:** Store the hot pot in a dry, cool place when not in use for extended periods.



*Image: The 304 stainless steel interior is designed for healthy cooking and easy cleaning.*

## TROUBLESHOOTING

- **Appliance Not Turning On:**
  - Ensure the power cord is securely plugged into both the hot pot and the wall outlet.

- Check if the power outlet is functional by testing it with another appliance.
  - Verify the control dial is set to either Setting 1 or 2.
- **Food Not Heating:**
    - Confirm the power setting is appropriate for the desired cooking task.
    - Check for any activation of the overheat or boil-dry protection systems. If activated, allow the unit to cool before restarting.
- **Burning Smell:**
    - Immediately turn off and unplug the appliance.
    - Inspect the power cord and the hot pot's power inlet for any signs of damage or melting. If damage is observed, discontinue use and contact customer support.
    - Ensure the interior is clean and free of food debris that could burn.

## SPECIFICATIONS

Feature	Specification
Brand	DiDimo
Model Number	DZ11
Capacity	1.5 Liters (0.4 Gallons)
Material	Stainless Steel
Power Settings	200W (Low), 600W (High)
Item Weight	2.2 Pounds
Product Dimensions	6.7 x 6.7 x 8.2 inches
Safety Features	Overheat Protection, Boil-Dry Protection



*Image: Product dimensions for the DiDimo Electric Hot Pot.*

## SUPPORT

---

For any questions, concerns, or support needs regarding your DiDimo Electric Hot Pot, please contact our customer service team. Refer to the product packaging or our official website for the most current contact information.

---

© 2023 DiDimo. All rights reserved.