

[Manuals.plus](#) /

› [IFANNY](#) /

› IFANNY Wall Mounted Computer Desk (Model IF-CB10278) Instruction Manual

IFANNY IF-CB10278

IFANNY Wall Mounted Computer Desk (Model IF-CB10278) Instruction Manual

Model: IF-CB10278

INTRODUCTION

Thank you for purchasing the IFANNY Wall Mounted Computer Desk. This manual provides detailed instructions for the assembly, operation, and maintenance of your new desk. Please read this manual thoroughly before beginning assembly and retain it for future reference.



Image: The IFANNY Wall Mounted Computer Desk in an open configuration, showcasing its workspace and integrated shelving. A laptop is placed on the foldable desktop, surrounded by various decorative items and office supplies.

IMPORTANT SAFETY INFORMATION

Please observe the following safety guidelines to ensure safe use and prevent damage to the product or injury.

- Do not exceed the maximum weight recommendation of 11 pounds on the desktop or shelves.
- Ensure proper installation and anchoring to a sturdy wall to avoid tipping or detachment.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Always use appropriate tools and follow assembly instructions carefully.

Premium Wall-mounted Accessories Ensure Great Stability



Image: A visual representation of the IFANNY Wall Mounted Computer Desk highlighting the recommended maximum weight capacity of 11 lbs for the desktop and internal shelves.

PARTS LIST

Before assembly, verify that all components are present and undamaged. Refer to the assembly video for visual identification of parts.

- Wall-Mounted Desk Components (Engineered Wood, MDF)
- Assembly Hardware (screws, dowels, cam locks, hinges, pneumatic springs, magnetic catch, knobs)
- Instruction Manual

Video: An official IFANNY assembly video demonstrating the unboxing and identification of all desk components and hardware. This video serves as a visual guide for the parts list and initial setup steps.

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have a second person assist with mounting the desk to the wall. Refer to the assembly video for detailed visual guidance.

Tools Required:

- Phillips Head Screwdriver (included)
- Drill (for wall mounting)
- Level
- Measuring Tape
- Pencil

Assembly Steps:

1. Step 1: Assemble the Drawer.

Connect the drawer side panels (L, O, P, N) using the provided screws and dowels. Attach the handle to the front panel (M) and secure it to complete the drawer unit.



Image: Illustration of the initial assembly phase, focusing on connecting the base components of the drawer unit.

2. **Step 2: Construct Internal Shelf Structure.**

Assemble parts A, B, C, and D using screws and dowels to create the internal shelving compartments.

3. **Step 3: Prepare Side Boards.**

Install the pneumatic springs and cabinet hangers onto side boards F and G as indicated in the video.

4. **Step 4: Prepare Door Panel.**

Attach the magnetic catch plate, hinges, and handle to the door panel K.

5. **Step 5: Prepare Bottom Board.**

Install the magnetic catch plate onto the bottom board I.

6. **Step 6: Connect Internal Components.**

Join the internal shelf structure (from Step 2) with shelf E using the appropriate hardware.

7. **Step 7: Assemble Main Body Frame.**

Connect the prepared side boards (F & G) to the internal shelf structure. Carefully slide the back board H into its designated grooves.

8. **Step 8: Install Bottom and Top Boards.**

Securely attach the bottom board I and top board J to the main body of the desk using screws.

9. **Step 9: Attach Door Panel.**

Install the door panel K to the main body using the pre-installed hinges and screws. Connect the pneumatic springs to the door panel and the side boards for smooth operation.

10. **Step 10: Insert Drawer.**

Gently slide the assembled drawer into its designated slot at the bottom of the desk unit.

11. **Step 11: Finishing Touches.**

Apply the provided stickers over any visible screw holes for a clean and finished appearance.

12. **Step 12: Wall Mounting.**

Using the cabinet hangers, appropriate wall anchors (if not mounting into studs), and screws, securely mount the assembled desk to a sturdy wall. Use a level to ensure it is straight. It is crucial to anchor the desk into wall studs for maximum stability and safety.



Image: A detailed diagram illustrating the dimensions of the IFANNY Wall Mounted Computer Desk, including overall measurements and internal shelf spacing. This is useful for planning installation location.

OPERATING INSTRUCTIONS

Opening the Desk:

1. Gently pull the knob on the front panel of the desk.
2. The pneumatic springs will assist in lowering the desktop smoothly.
3. Ensure the desktop is fully extended and stable before placing items on it.

Closing the Desk:

1. Remove all items from the desktop surface.
2. Lift the desktop upwards until the magnetic catch engages, securing the panel in the closed position.

Using the Drawer and Shelves:

- The bottom drawer can be pulled out for enclosed storage of small items.
- The internal shelves provide open storage for books, decorative items, or office supplies.
- Do not overload the drawer or shelves beyond their weight capacity.



MORE DETAILS

Image: A close-up view of the IFANNY Wall Mounted Computer Desk's interior, highlighting the various storage partitions, a memo board, and the pull-out bottom drawer for organized storage.

MAINTENANCE

To maintain the appearance and functionality of your IFANNY Wall Mounted Computer Desk, follow these simple care instructions:

- **Cleaning:** Wipe the surface with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Tighten if necessary.
- **Pneumatic Springs:** Ensure the pneumatic springs operate smoothly. If they become stiff or noisy, a small amount of silicone lubricant can be applied to the moving parts.

TROUBLESHOOTING

If you encounter any issues with your IFANNY Wall Mounted Computer Desk, refer to the following common solutions:

- **Desk feels unstable after mounting:** Ensure the desk is securely anchored into wall studs. If only drywall anchors were used, consider relocating to a stud or using heavy-duty toggle bolts. Re-check all assembly screws for tightness.
- **Desktop does not open/close smoothly:** Check the pneumatic springs for proper installation and ensure no obstructions are present. A small amount of lubricant on the spring mechanism might help.
- **Drawer sticks or is difficult to open/close:** Verify that the drawer is correctly aligned within its runners. Check for any debris or obstructions in the drawer tracks.
- **Magnetic catch not holding the door closed:** Ensure the magnetic catch and its corresponding plate are properly aligned and securely fastened.

SPECIFICATIONS

Brand	IFANNY
Model Number	IF-CB10278
Product Dimensions (D x W x H)	6"D x 24"W x 22.5"H
Desktop Size (L x W)	22" x 16" (when open)
Material	Engineered Wood, MDF
Color	White
Item Weight	27.5 Pounds
Maximum Weight Recommendation	11 Pounds
Number of Drawers	1
Number of Shelves	6 (internal compartments)
Special Feature	Foldable, Wall Mount

— PRACTICAL STORAGE & DISPLAY FUNCTION —



Memo board



Different partitions



Bottom drawer

Image: A visual demonstrating the space-saving design of the IFANNY Wall Mounted Computer Desk, showing it both open as a desk with shelves and closed as a compact wall-mounted cabinet.

WARRANTY AND SUPPORT

For warranty information, technical support, or any questions regarding your IFANNY Wall Mounted Computer Desk, please contact IFANNY customer service. Refer to your purchase documentation or the IFANNY official website for contact details.

© 2023 IFANNY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BK983NMN>

More documents and user manuals: **<https://manuals.plus/>**