

[manuals.plus](#) /› [Formuler](#) /› [Formuler Z11 Pro Max 4K Android 11 OTT Streamer User Manual](#)

Formuler Z11 Pro Max

Formuler Z11 Pro Max 4K Android 11 OTT Streamer User Manual

Comprehensive instructions for setup, operation, and maintenance of your Formuler Z11 Pro Max device.

1. INTRODUCTION

The Formuler Z11 Pro Max is an advanced 4K Android 11 OTT multimedia streamer designed to deliver a high-definition entertainment experience. Featuring 4GB of RAM and 32GB of internal storage, it ensures smooth and rapid performance for all your streaming needs. This device supports 4K resolution and WiFi 6, providing stable and fast connectivity for high-resolution content. Its user-friendly interface and robust features make it an optimized solution for modern media consumption.

2. WHAT'S IN THE Box

Please verify that all items are present in the package:

- Formuler Z11 Pro Max Device
- Remote Control
- 12V Power Adapter
- Batteries (for remote control)
- HDMI Cable
- Installation Manual (this document)



Figure 1: Formuler Z11 Pro Max Device and Remote Control. The image displays the Formuler Z11 Pro Max streaming device, a compact black unit, alongside its accompanying remote control. The device features a sleek, angular design. The remote control is also black, with clearly visible buttons for navigation and control. The packaging indicates 4GB RAM and 32GB storage, 4K Ultra HD, and BT1 Edition.

3. SETUP GUIDE

- 1. Connect to TV:** Connect one end of the provided HDMI cable to the HDMI port on the Formuler Z11 Pro Max and the other end to an available HDMI input on your television or projector.
- 2. Power Connection:** Connect the 12V power adapter to the DC input port on the Formuler Z11 Pro Max. Plug the power adapter into a wall outlet.
- 3. Insert Batteries:** Open the battery compartment on the back of the remote control and insert the provided alkaline batteries, ensuring correct polarity.
- 4. Network Connection:**
 - **Wi-Fi:** Upon first boot, the device will prompt you to connect to a Wi-Fi network. Select your network and enter the password. The device supports Wi-Fi 6 for enhanced wireless performance.
 - **Ethernet:** For a wired connection, connect an Ethernet cable from your router to the Ethernet port on the Formuler Z11 Pro Max.
- 5. First Boot:** Turn on your television and select the correct HDMI input. The Formuler Z11 Pro Max will

power on automatically or can be powered on using the remote control. Follow the on-screen instructions for initial setup, including language selection and Google account login.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

Use the remote control's directional pad and OK button to navigate through the Android 11 interface. The Home button returns you to the main screen, while the Back button allows you to go back one step.

4.2 Streaming Services

The Formuler Z11 Pro Max supports various internet services, including Netflix, Hulu, Amazon Prime Video, and Disney+. Access these applications from the home screen or app drawer. Ensure a stable internet connection for optimal streaming quality.

4.3 MyTV Online 3

The device features MyTV Online 3, an integrated application for accessing OTT content. Refer to the in-app guide for specific instructions on configuring and using this service.

4.4 USB Recording (DVR)

To utilize the USB Recording (DVR) feature, connect a compatible USB storage device (e.g., USB flash drive or external hard drive) to one of the USB ports on the Formuler Z11 Pro Max. Follow the on-screen prompts within the media player or TV application to initiate recording of live content.

4.5 Dual Live Event Viewing

The device allows for viewing two live events simultaneously on your television screen. Consult the device's software settings or the MyTV Online 3 application for instructions on enabling and managing this feature.

5. MAINTENANCE

5.1 Cleaning

Wipe the device and remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surfaces.

5.2 Software Updates

Periodically check for software updates through the device's settings menu. Keeping the software updated ensures optimal performance, security, and access to new features. Updates are typically delivered over the internet.

5.3 Storage and Environment

Store the device in a cool, dry place away from direct sunlight, heat sources, and excessive moisture. Ensure adequate ventilation around the device during operation.

6. TROUBLESHOOTING

- No Power:** Ensure the power adapter is securely connected to both the device and a working wall outlet. Try a different outlet.

- **No Picture/Sound:** Verify the HDMI cable connections at both the device and the TV. Ensure the correct HDMI input is selected on your television.
- **Remote Control Unresponsive:** Check the remote control batteries and replace them if necessary. Ensure there are no obstructions between the remote and the device.
- **Buffering/Poor Streaming Quality:** Check your internet connection speed. For Wi-Fi, try moving the device closer to the router or connecting via Ethernet for a more stable connection. If using MyTV Online 3, disabling timeshift might resolve buffering issues.
- **Device Freezes/Slow Performance:** Restart the device by unplugging the power adapter for 10 seconds and then plugging it back in. Close unused applications to free up RAM.


7. SPECIFICATIONS

Brand	Formuler
Model Name	Z11 Pro Max
Operating System	Android 11
RAM	4GB
Storage	32GB
Resolution	4K
Connectivity Technology	Ethernet, HDMI, Wi-Fi (Wi-Fi 6)
Connector Type	HDMI, USB
Special Feature	USB Recording (DVR)
Compatible Devices	Television, Projector
Supported Internet Services	Netflix, Hulu, Amazon Prime Video, Disney+
Color	Black

8. WARRANTY AND SUPPORT

The Formuler Z11 Pro Max comes with a **2-year manufacturer's warranty**. For warranty claims or technical support, please refer to the contact information provided by your retailer or visit the official Formuler website. Keep your proof of purchase for warranty validation.

Related Documents - Z11 Pro Max

	<p>Formuler Z11 Pro Max Quick Setup Guide & Safety Information</p> <p>A comprehensive guide to setting up and safely operating your Formuler Z11 Pro Max set-top box, including installation steps, package contents, and important safety precautions.</p>
	<p>Formuler IR1 Remote: Basic Operations and App Guide</p> <p>Learn how to use your Formuler IR1 Remote for basic operations, programming TV control keys, and utilizing the Formuler Remote app for hotkey customization and system navigation.</p>
	<p>Formuler Z10 Pro (01) User Manual and Specifications</p> <p>Comprehensive user manual and technical specifications for the Formuler Z10 Pro (01) media receiver. Learn about features, setup, operation, and troubleshooting.</p>
	<p>Handleiding Formuler MYTV Online 2.0: Gebruikersgids voor IPTV en Apps</p> <p>Gedetailleerde handleiding voor de Formuler MYTV Online 2.0 app, inclusief functies, installatie van apps, afspeellijsten, portal URL's, afstandsbediening functies, software updates en WiFi instellingen. Leer hoe je je Formuler apparaat optimaal gebruikt.</p>
	<p>Handleiding Formuler MYTV Online 3.0 IPTV App</p> <p>Uitgebreide handleiding voor de Formuler MYTV Online 3.0 IPTV App, met details over functies, installatie en gebruik voor een verbeterde media-ervaring.</p>
	<p>FORMULER GTV Quick Setup Guide & Safety Information</p> <p>Comprehensive guide for setting up your FORMULER GTV Set Top Box, including installation steps, what's in the box, and essential safety information. Supports multiple languages.</p>