

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

### RCA RLEDV2488

# RCA 24" TV/DVD Combo User Manual

Model: RLEDV2488

## INTRODUCTION

This user manual provides comprehensive instructions for the setup, operation, and maintenance of your RCA 24" TV/DVD Combo (Model: RLEDV2488). Please read this manual thoroughly before using the product to ensure proper functionality and safety.



This image shows the RCA 24-inch TV/DVD Combo. The screen displays a bustling city scene, likely Times Square, with numerous billboards and buildings. A silver disc, representing a DVD, is partially visible on the right side, indicating the built-in DVD player functionality. The TV itself is black with two dark grey stand feet.

## IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using this product to reduce the risk of fire, electric shock, and injury to persons.

- Do not expose this appliance to rain or moisture.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the appliance.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this appliance during lightning storms or when unused for long periods of time.

## WHAT'S IN THE Box

---

Verify that all components are present before proceeding with setup:

- RCA 24" TV/DVD Combo Unit
- Power Cable
- Remote Control
- Stand (2 pieces)

## SETUP

---

### 1. Attaching the Stand

1. Carefully place the TV screen-down on a soft, clean surface to prevent scratches.
2. Align the stand pieces with the corresponding slots on the bottom of the TV.
3. Secure the stand using the provided screws. Do not overtighten.

### 2. Wall Mounting (Optional)

The RCA 24" TV/DVD Combo is designed to be wall mountable. The rear panel includes standard VESA mount screw holes. A VESA mount (not included) is required for wall installation. Refer to your VESA mount's instructions for proper installation.

### 3. Connecting Power

- Connect the power cable to the AC input on the back of the TV.
- Plug the other end of the power cable into a standard electrical outlet.

### 4. Connecting External Devices

The TV is equipped with various ports for connecting external devices.

- **HDMI Port:** For high-definition audio and video connections (e.g., gaming consoles, Blu-ray players, streaming devices).
- **VGA Port:** For connecting to a computer.
- **Antenna/Cable Input:** For connecting an antenna or cable TV source.

## OPERATING INSTRUCTIONS

---

### 1. Power On/Off

- Press the **POWER** button on the remote control or on the TV panel to turn the TV on or off.

## 2. Input Selection

- Press the **INPUT** or **SOURCE** button on the remote control to cycle through available input sources (TV, HDMI, VGA, DVD).

## 3. Using the Built-in DVD Player

The TV features a convenient slot-loading DVD player.

1. Insert a DVD disc into the slot on the side of the TV with the label facing up. The TV will automatically detect the disc.
2. If the TV does not automatically switch to DVD input, press the **INPUT** button on the remote control and select "DVD".
3. Use the remote control's playback buttons (**PLAY**, **PAUSE**, **STOP**, **SKIP**) to control DVD playback.

## 4. Adjusting Volume and Channels

- Use the **VOL +/-** buttons to adjust the volume level.
- Use the **CH +/-** buttons to change TV channels (when in TV input mode).

## MAINTENANCE

---

### 1. Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet. For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive cleaner specifically designed for electronics.
- Do not spray cleaners directly onto the screen or cabinet.

### 2. Cleaning the DVD Player

- To maintain optimal performance, keep discs clean and free of scratches.
- If playback issues occur, a DVD lens cleaner disc (not included) may be used. Follow the instructions provided with the cleaner disc.

### 3. Storage

- If storing the TV for an extended period, unplug it and store it in a cool, dry place, away from direct sunlight and extreme temperatures.
- It is recommended to store the TV in its original packaging to protect it from dust and physical damage.

## TROUBLESHOOTING

---

Before contacting customer support, try the following solutions for common issues:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No power	Power cable not connected; outlet not working.	Ensure power cable is securely connected. Test outlet with another device.
No picture	Incorrect input source selected; external device not powered on.	Press the <b>INPUT</b> button to select the correct source. Ensure external devices are powered on.
No sound or low sound	Volume too low; Mute function active; external speakers not connected properly.	Increase volume. Press <b>MUTE</b> button. Check external speaker connections if applicable. Note: Some users report sound quality may vary depending on room acoustics and mounting.
DVD not playing or loading	Disc is dirty or scratched; incorrect disc format; DVD player malfunction.	Clean the disc. Try a different disc. Ensure the disc is inserted correctly. If issues persist, the DVD player may require service.
Remote control not working	Batteries are dead or inserted incorrectly; obstruction between remote and TV.	Replace batteries. Ensure correct polarity. Remove any obstructions.

## SPECIFICATIONS

Feature	Detail
Brand	RCA
Model Number	RLEDV2488
Screen Size	24 Inches
Display Technology	LED
Resolution	720p
Refresh Rate	60 Hz
Aspect Ratio	16:9
Item Weight	8.43 pounds
Product Dimensions (D x W x H)	5 x 27 x 17 inches
Wattage	36 watts (On-mode power consumption)
Speaker Type	Built-In

Feature	Detail
Connectivity Technology	VGA, HDMI
Special Feature	Flat Screen

## WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the documentation included with your product or visit the official RCA website. You can also visit the [RCA Store on Amazon](#) for more product information and support resources.

Keep your purchase receipt as proof of purchase for warranty claims.

© 2025 RCA. All rights reserved.

## Related Documents

 <p>HDV5000 HD DVD Player</p> <p>True High Definition Video From an HD DVD Disc HD to DVD Conversion of Standard DVD Discs Fully Integrated 5.1 Channel Surround Sound Network Connection For Access to Internet Content 5.1 Channel Surround Sound Enhanced Picture and Sound Quality Enhanced Picture and Sound Quality in One Convenient Connection Enhanced Picture and Sound Quality Dual Picture and Sound Quality Single Remote and User Interactivity Play HD DVD / DVD Combination and Twin Format Discs with High Definition HD</p> <p><b>RCA</b></p>	<p><b><u>RCA HDV5000 HD DVD Player Technical Specifications and Features</u></b></p> <p>Detailed technical specifications and features for the RCA HDV5000 HD DVD Player, including compatible formats, playback capabilities, connectivity, and dimensions. Features HD DVD playback, HD up-conversion, and 5.1 channel surround sound.</p>
 <p><b>RCA</b></p> <p><b>INSTRUCTION MANUAL</b></p> <p>Before using the TV, please read this manual thoroughly, and retain it for future reference.</p> <p><b>TV/DVD COMBO</b></p>  <p>Model: RLEDV2488A-B</p> <p>UL</p> <p>Model: RLEDV2488A-B</p> <p>UL</p>	<p><b><u>RCA RLEDV2488A-B TV/DVD Combo Instruction Manual</u></b></p> <p>Comprehensive instruction manual for the RCA RLEDV2488A-B TV/DVD Combo, covering safety precautions, setup, operation, and troubleshooting.</p>
 <p>HD AV HDMI USB</p>	<p><b><u>RCA 24 Inch HD VIDAA Smart TV - Product Information</u></b></p> <p>Information about the RCA 24 Inch HD VIDAA Smart TV, including importer details, model number E32-RH1.Q1L, and compatibility with Dolby Audio and HDMI.</p>



### [RCA RS32H2-EU 32-Inch LED HD LCD TV User Manual](#)

Comprehensive user manual for the RCA RS32H2-EU 32-Inch LED HD LCD TV, covering safety instructions, setup, operation, specifications, and troubleshooting.