

[Manuals.plus](#) /

> [AREYZIN](#) /

> AREYZIN Multi-Grooming Kit (Model B0BKFBYMX5) Instruction Manual

AREYZIN B0BKFBYMX5

AREYZIN Multi-Grooming Kit (Model B0BKFBYMX5) Instruction Manual

Your complete guide to effective and comfortable grooming.

1. PRODUCT OVERVIEW

The AREYZIN Multi-Grooming Kit (Model B0BKFBYMX5) is a versatile personal grooming device designed for precision trimming of ear, nose, eyebrow, and body hair. This kit includes two main devices: the Nose & Ear Hair Trimmer (Model C330) and the Body Hair Trimmer (Model BG220), along with various attachments and accessories to meet diverse grooming needs. Both trimmers are rechargeable, waterproof, and feature high-quality stainless steel blades for a comfortable and efficient grooming experience.



Image 1: Overview of the AREYZIN Multi-Grooming Kit components.

2. PACKAGE CONTENTS

Upon opening your AREYZIN Multi-Grooming Kit, you should find the following items:

- 1 x Nose & Ear Hair Trimmer (Model C330)
- 1 x Body Hair Trimmer (Model BG220)
- 1 x Eyebrow Trimming Head (for Model C330)
- 1 x Sideburn Trimmer Head (for Model BG220)
- 1 x Length Guide Comb (for Eyebrow Trimming Head)
- 1 x USB Charging Cable
- 1 x Mini Cleaning Brush
- 1 x User Manual (this document)



Image 2: The Body Hair Trimmer (BG220) and its accessories.

3. SETUP

3.1 Initial Charging

Before first use, fully charge both trimmers. Connect the provided USB charging cable to the charging port on each device and plug the other end into a compatible USB power source (e.g., computer, adapter, power bank, car charger). The charging indicator will show the battery status. A full charge typically provides several months of typical usage.



Image 3: The Body Hair Trimmer (BG220) being charged via USB cable.

3.2 Attaching/Detaching Trimmer Heads

To change a trimmer head, gently twist the current head counter-clockwise to detach it from the main body. Align the desired head with the body and twist clockwise until it clicks securely into place. Ensure the device is turned off before changing heads.

Your browser does not support the video tag.

Video 1: This video demonstrates how to attach and detach the various trimming heads for the Kynor 3-in-1 Electric Nose, Eyebrow & Ear Hair Trimmer, showcasing the ease of switching between functions.

4. OPERATING INSTRUCTIONS

Each trimmer is designed for specific areas and hair types. Always ensure your skin is clean and dry before use for optimal results.

4.1 Nose & Ear Hair Trimmer (Model C330)

- **For Nose Hair:** Gently insert the nose trimming head into your nostril. Move the trimmer in a circular motion to trim unwanted hair. Do not insert too deeply.
- **For Ear Hair:** Carefully guide the nose trimming head around the outer and inner edges of your ear to remove visible hair.
- **For Eyebrows:** Attach the eyebrow trimming head. Use the length guide comb if desired to achieve an even trim. Gently comb through your eyebrows, trimming against the direction of hair growth.

MULTI-PURPOSE USE




Image 4: Visual guide for using the trimmer for various facial hair areas.

4.2 Body Hair Trimmer (Model BG220)

- Attach the sideburn trimmer head. This head is also suitable for general body grooming.
- For best results, hold the trimmer flat against the skin and move it slowly against the direction of hair growth.
- The R-angle design and ceramic blade ensure a safe and comfortable trim, minimizing nicks and irritation.



Whole Body Trimmer for Men




Image 5: The Body Hair Trimmer (BG220) in action for full body grooming.

Your browser does not support the video tag.

Video 2: This video demonstrates the use of a nose trimmer, showing how it effectively removes unwanted hair from the nose area.

5. MAINTENANCE

Regular cleaning ensures optimal performance and hygiene for your AREYZIN grooming kit.

- **Cleaning the Heads:** Both trimmers are waterproof. After each use, detach the trimming head and rinse it under running water. Use the mini cleaning brush to remove any trapped hairs.
- **Drying:** Allow the heads to air dry completely before reattaching them to the device or storing.
- **Storage:** Store the trimmers and all attachments in a dry place. Use the magnetic protective cap for the nose trimmer head to keep it clean and protected when not in use.



Image 6: The nose and ear trimmer head is washable for easy cleaning.

6. TROUBLESHOOTING

If you encounter any issues with your AREYZIN Multi-Grooming Kit, please refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. If the battery is low, connect it to the USB charging cable and allow it to charge.
- **Poor trimming performance:** Clean the trimming head thoroughly to remove any accumulated hair or debris. Ensure the blades are not dull or damaged. If necessary, replace the trimming head.
- **Excessive noise or vibration:** Check that the trimming head is securely attached to the device body. Ensure no foreign objects are obstructing the blades.

If the problem persists, please contact AREYZIN customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	AREYZIN
Model	B0BKFBYMX5 (Kit), C330 (Nose/Ear), BG220 (Body)
Power Source	Battery Powered, USB Cable
Material	Stainless Steel (Blades), Ceramic (Body Trimmer Blade)

Special Features	Cordless, Rechargeable, Waterproof (IPX7), 6500RPM Powerful Motor, Dual-Edge Blade, 360° Rotating Design, R-angle Design
Recommended Uses	Grooming, Trimming (Nose, Ear, Eyebrow, Body, Sideburns)



Image 7: Key safety and design features of the Body Hair Trimmer (BG220).

8. WARRANTY AND SUPPORT

The AREYZIN Multi-Grooming Kit comes with a standard manufacturer's warranty. For specific warranty details, registration, or technical support, please refer to the warranty card included in your package or visit the official AREYZIN website. Keep your purchase receipt as proof of purchase.