



Manuals.plus /

› OLEVS /

› OLEVS Women's Multifunction Chronograph Watch User Manual

## OLEVS OPK-US-L5523-JH

# OLEVS Women's Multifunction Chronograph Watch

MODEL: OPK-US-L5523-JH

User Instruction Manual

## 1. Introduction



This manual provides detailed instructions for the proper use and care of your OLEVS Women's Multifunction Chronograph Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.



Front view of the OLEVS Women's Multifunction Chronograph Watch, featuring a gold-tone case, black dial with diamond markers, and a brown leather strap.

## 2. Product Features

- **Elegant Design:** Features a unique creative personality with Roman numeral and diamond markers on the dial, suitable for business and formal occasions.
- **Analog Quartz Movement:** Equipped with a precise quartz movement for accurate timekeeping and stable performance.
- **Multifunction Dial:** The 32mm dial includes multiple sub-dials for chronograph functions and a date display.
- **Comfortable Leather Strap:** High-quality brown leather strap, designed to be soft, skin-friendly, comfortable, and breathable for extended wear.
- **Water Resistance:** Water resistant up to 100 feet (30 meters), suitable for splashes, hand washing, and brief immersion. Not recommended for swimming or hot showers.
- **Luminous Display:** High-definition luminous hands and markers absorb light energy, allowing for clear time visibility in low-light conditions.



Visual representation of key features including 30m water resistance, high-hardness coated glass, breathable leather strap, and luminous hands/markers.

## 3. Setup Instructions

### 3.1 Setting the Time

1. Pull the crown (B) out to position 2.
2. Rotate the crown to set the hour and minute hands to the correct time.
3. Push the crown back to position 0.

### 3.2 Setting the Date

1. Pull the crown (B) out to position 1.
2. Rotate the crown clockwise or counter-clockwise to set the correct date.
3. Push the crown back to position 0.

*Note: Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.*

### 3.3 Adjusting the Strap

The leather strap features a standard buckle closure. Adjust the strap length by selecting the appropriate hole for a comfortable and secure fit on your wrist. Ensure the watch is not too tight or too loose.



The OLEVS watch comfortably worn on a wrist, highlighting the fit of the brown leather strap.

## 4. Operating Instructions

### 4.1 Chronograph Function

Your OLEVS watch is equipped with a chronograph feature for measuring elapsed time. The sub-dials typically represent seconds, minutes, and a 24-hour indicator.

- **Start/Stop:** Press button (A) located above the crown to start and stop the chronograph.
- **Reset:** Press button (C) located below the crown to reset the chronograph hands to zero. Ensure the chronograph is stopped before resetting.

### 4.2 Luminous Display

The watch hands and markers are coated with a luminous material. For optimal glow in the dark, expose the watch

to a strong light source (natural or artificial) for a few minutes. The intensity and duration of the glow will depend on the exposure time and light intensity.

## 5. Maintenance

### 5.1 Cleaning the Watch

Wipe the watch case and crystal with a soft, dry cloth. For the leather strap, use a slightly damp cloth and mild soap if necessary, then wipe dry immediately. Avoid using harsh chemicals or abrasive materials.

### 5.2 Water Resistance Guidelines

The watch is rated for 30 meters (100 feet) of water resistance. This means it is suitable for daily use, such as hand washing, rain, or accidental splashes. It is **not** designed for:

- Swimming or diving.
- Showering or bathing, especially with hot water or steam, as temperature changes can affect seals.
- Operating the crown or pushers while the watch is wet or submerged.

Always ensure the crown is fully pushed in to maintain water resistance.

### 5.3 Strap Care

Leather straps can be affected by moisture, sweat, and direct sunlight. To prolong the life of your leather strap:

- Avoid prolonged exposure to water.
- Clean regularly to remove sweat and dirt.
- Allow the strap to air dry if it gets wet.

## 6. Troubleshooting

Problem	Possible Cause	Solution
Watch not running	Battery depleted or crown not pushed in.	Ensure crown is fully pushed in. If still not running, battery replacement may be required by a professional.
Date not changing	Date set during restricted hours (9 PM - 3 AM) or incorrect setting.	Reset the date outside of the restricted hours. If issue persists, consult support.
Luminous effect is weak	Insufficient exposure to light.	Expose the watch dial to a strong light source for several minutes to charge the luminous material.
Water inside watch	Crown/pushers operated underwater or seals compromised.	Immediately take the watch to a professional for inspection and repair to prevent further damage.

## 7. Specifications

- **Brand:** OLEVS
- **Model Number:** OPK-US-L5523-JH
- **Movement:** Analog Quartz
- **Case Material:** Alloy (Gold-tone)
- **Dial Diameter:** Approximately 32mm
- **Strap Material:** Brown Leather
- **Water Resistance Depth:** 30 Meters (100 Feet)
- **Features:** Chronograph, Date Display, Luminous Hands/Markers
- **Package Dimensions:** 5.91 x 2.6 x 0.87 inches
- **Item Weight:** 1.45 ounces
- **First Available:** October 25, 2022

## 8. Warranty and Support

OLEVS is committed to the quality of every watch. If you encounter any questions or issues during the use of your watch, please do not hesitate to contact our professional after-sales team. We are dedicated to providing a satisfactory resolution to your concerns.

For support, please refer to the contact information provided with your purchase or visit the official OLEVS website.