

[manuals.plus](#) /

› [innioasis](#) /

› [innioasis Crystal Clear Protective Case for G1/G3 MP3 Player Instruction Manual](#)

**innioasis G1, G3**

# innioasis Crystal Clear Protective Case for G1/G3 MP3 Player Instruction Manual

Model: G1, G3 Compatible

Brand: innioasis

## 1. INTRODUCTION

Thank you for choosing the innioasis Crystal Clear Protective Case. This case is specifically designed to provide robust protection for your innioasis G1 or G3 MP3 player, safeguarding it from daily wear and tear, scratches, and minor impacts. Its transparent design ensures the original aesthetic of your device remains visible while offering essential durability.



*Image: The innioasis Crystal Clear Protective Case, designed for G1/G3 MP3 players.*

## 2. KEY FEATURES

---

- **Perfect Fit:** Exclusively customized for innioasis G1 and G3 MP3 players, ensuring precise alignment with all ports and buttons.
- **Shock Absorbing:** Constructed from high-grade, shock-absorbing materials to protect your MP3 player from accidental drops and impacts.
- **Scratch Resistant:** Premium materials offer long-lasting protection against scratches and scuffs, maintaining the device's pristine condition.
- **Easy to Install:** Flexible design allows for simple installation and removal, providing convenience without compromising security.
- **Crystal Clear and Slim:** Transparent bumper case reveals and enhances the original color and design of your MP3 player, adding minimal bulk.

# Shockproof & Protective

Guards your player against life's little accidents



*Image: Visual representation of the case's shock-absorbing capabilities protecting the MP3 player.*



**Ultral clear**

Shows the original color  
of your player

*Image: The ultra-clear design of the case, allowing the original device color to show through.*



*Image: Side view of the MP3 player with the clear case, demonstrating its slim and lightweight design.*

### 3. COMPATIBILITY

This protective case is designed exclusively for the **innioasis G1** and **innioasis G3** MP3 players. It is not compatible with other MP3 player models due to variations in device dimensions and port/button layouts. Please verify your MP3 player model before installation.

### 4. INSTALLATION GUIDE

Follow these steps to properly install the innioasis Crystal Clear Protective Case on your G1 or G3 MP3 player:

- 1. Prepare Your Device:** Ensure your innioasis G1 or G3 MP3 player is clean and free of dust or debris. Use a soft, dry cloth to gently wipe the device surface.
- 2. Align the Case:** Hold the protective case and align the MP3 player with the case's openings for the screen, ports, and buttons.
- 3. Insert the Device:** Gently push the MP3 player into the case, starting from one side. Ensure all corners and edges are securely seated within the case. The flexible material allows for easy fitting.
- 4. Verify Fit:** Once installed, check that the case fits snugly around the device and that all buttons (power, volume) and ports (headphone jack, charging port, external speaker port) are accessible and functional.

# For innioasis G1 G3 mp3 player

## Perfect fit , innioasis Exclusive customization



*Image: innioasis G1/G3 MP3 player with the clear protective case installed, showcasing the device's screen and app icons.*

# User Friendly

Precise cutouts, easy-press buttons ensure your player stays fully functional and has a more comfortable feel



*Image: Close-up view of the innioasis G1/G3 MP3 player within the clear case, demonstrating the precise cutouts for easy access to buttons and ports.*

## 5. CARE AND MAINTENANCE

To ensure the longevity and clarity of your innioasis protective case, follow these maintenance tips:

- **Cleaning:** Wipe the case regularly with a soft, damp cloth to remove dust, fingerprints, and smudges. Avoid abrasive cleaners or harsh chemicals, as these can damage the material and clarity.
- **Avoid Extreme Temperatures:** Do not expose the case to extreme heat or cold, as this can affect its material integrity and flexibility.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight.

## 6. TROUBLESHOOTING


If you encounter any issues with your protective case, consider the following:

- **Case Not Fitting:** Ensure you have the correct model (innioasis G1 or G3). The case is specifically designed for these models and will not fit others.
- **Buttons Hard to Press:** Re-adjust the MP3 player within the case to ensure proper alignment. The case is designed with easy-press buttons, so misalignment might be the cause.

- **Discoloration:** Over time, clear TPU cases may show slight yellowing due to UV exposure. This is a natural characteristic of the material and does not affect its protective qualities. Regular cleaning can help maintain its appearance.

## 7. SPECIFICATIONS

Feature	Detail
<b>Product Dimensions</b>	4.41 x 2.56 x 0.43 inches
<b>Item Weight</b>	0.634 ounces
<b>Material</b>	Polyurethane (TPU)
<b>Color</b>	Crystal Clear
<b>Compatible Devices</b>	innioasis G1 MP3 Player, innioasis G3 MP3 Player
<b>Special Features</b>	Heavy Duty Protection, Lightweight, Scratch Resistant



*Noting: Designed specifically for innioasis G1 and G3 MP3 players. It is not compatible with other models due to other models have different button and port layouts.*

*Image: Detailed diagram illustrating the dimensions of the innioasis G1/G3 MP3 player with the clear case, highlighting port and button locations.*

## **8. WARRANTY AND SUPPORT**

For any questions regarding your innioasis Crystal Clear Protective Case, please refer to the product packaging or contact innioasis customer support. Specific warranty details may vary and are typically provided with your purchase documentation.

© 2023 innioasis. All rights reserved.