

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lexon](#) /

› [LEXON MINUT Digital Alarm Clock User Manual](#)

## Lexon LR154LP

# LEXON MINUT Digital Alarm Clock User Manual

Model: LR154LP

## INTRODUCTION

---

The Lexon MINUT is a compact and elegantly designed digital alarm clock, recognized for its minimalist aesthetic. It is ideal for bedrooms, nightstands, or as a travel companion due to its small size and long-lasting rechargeable battery. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your MINUT alarm clock.



Image: The Lexon MINUT Digital Alarm Clock, showcasing its compact, oval design and digital LCD display with the time 10:30 and an alarm icon visible. The clock is light pink with an aluminum finish.

## PACKAGE CONTENTS

---

- Lexon MINUT Digital Alarm Clock
- USB-C cable
- User Manual

## SETUP

---

### Charging the Device

The Lexon MINUT alarm clock is equipped with a rechargeable battery offering an autonomy of up to 6 months. For optimal performance, fully charge the device before its first use.

1. Connect the provided USB-C cable to the charging port located on the clock.
2. Connect the other end of the USB-C cable to a compatible USB power adapter (not included).
3. The display may show an indication of charging status. Allow sufficient time for the battery to reach full capacity.

## Initial Power On

Once adequately charged, the clock should power on automatically. If not, a gentle tap or movement of the device will activate the display.

## OPERATING INSTRUCTIONS

---

### Display Activation

The MINUT clock features a low-light option and a dimmable display. To temporarily activate the display and view the time, gently tap or move the clock. The display will illuminate for a short period.

### Setting the Time

Time setting is typically managed through intuitive touch controls. Refer to the small icons or indicators on the clock's surface for specific time adjustment modes. Generally, a series of taps or holds on designated areas will allow you to cycle through and set hours and minutes.

### Setting the Alarm

The alarm setup is designed for quick and simple operation using touch controls. Look for an alarm icon (bell symbol) or a specific area dedicated to alarm settings.

1. Activate the display by tapping the clock.
2. Locate the alarm setting control.
3. Adjust the desired alarm time using the designated controls (e.g., tapping specific areas to increment or decrement hours and minutes).
4. Confirm the alarm setting. A visible alarm icon on the display indicates that the alarm is active.

### Snooze Function

When the alarm sounds, a gentle tap on the clock will activate the snooze function. The alarm will pause and sound again after a predetermined interval.

### Adjusting Volume and Brightness

The MINUT allows for customization of both alarm volume and display brightness. These adjustments are typically performed via specific touch gestures or dedicated controls on the device.

- **Brightness:** The display is dimmable to suit your environment. Experiment with tapping or holding specific areas to cycle through available brightness levels.
- **Volume:** The alarm volume can be adjusted, including a high volume option suitable for heavy sleepers. Consult the device for indicators related to volume control.

## MAINTENANCE

---

### Cleaning

To clean your Lexon MINUT clock, use a soft, dry, lint-free cloth. Avoid using abrasive cleaners, solvents, or aerosol

sprays directly on the device, as these can damage the finish or internal components.

## Battery Care

The clock utilizes a rechargeable Lithium Metal battery. To maximize battery lifespan, avoid exposing the device to extreme temperatures. If storing the device for an extended period, ensure it has some charge remaining.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Display does not light up.	Battery is low or depleted; device is not activated.	Charge the device fully. Gently tap or move the clock to activate the display.
Alarm does not sound.	Alarm is not set or volume is too low.	Ensure the alarm is correctly set and the alarm icon is visible on the display. Increase the alarm volume.
Clock not charging.	Faulty cable or power adapter; charging port issue.	Try a different USB-C cable and power adapter. Ensure the cable is securely connected to both the clock and the power source.

## SPECIFICATIONS

- Brand:** Lexon
- Model:** LR154LP
- Display Type:** LCD
- Material:** Aluminum
- Power Source:** Electric (Rechargeable Battery)
- Product Dimensions:** 2.36"W x 0.79"H
- Item Weight:** 1.76 ounces (50 Grams)
- Battery:** 1 Lithium Metal battery (included)
- Battery Autonomy:** Up to 6 months
- Included Components:** USB-C cable
- Special Features:** Cordless, Touch Sensor, Adjustable Volume & Brightness, Low Light Option

## WARRANTY AND SUPPORT

The Lexon MINUT Digital Alarm Clock comes with a Limited Warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official Lexon website.

For technical support, troubleshooting assistance, or warranty claims, please contact Lexon customer service. Contact information can typically be found on the Lexon website or on the product packaging.

For additional information or to explore other Lexon products, you may visit the [Lexon Store on Amazon](#).

## Related Documents - LR154LP

	<a href="#">Lexon MINUT Mini Compact Alarm Clock User Manual and Quick Start Guide</a> User manual and quick start guide for the Lexon MINUT Mini Compact Alarm Clock (Model LR154-MINUT). Features VA LCD display, touch control, snooze, backlight, rechargeable battery, and aluminium finish.
---	--



LR154  
MINUT

Design by Manuela Simonelli & Andrea Quaglio

### [Lexon Minut LR154 Alarm Clock User Manual](#)

User manual for the Lexon Minut LR154 alarm clock, detailing setup, operation, charging, and safety information. Features include time and alarm setting, brightness adjustment, and a night mode.



### [Lexon Flip Classic Mint LR157 - Digital Alarm Clock User Manual](#)

Comprehensive user guide for the Lexon Flip Classic Mint LR157 digital alarm clock, covering setup, operation, features, specifications, and safety information.



### [Lexon Flip Premium LR152: User Manual and Features](#)

Comprehensive user guide for the Lexon Flip Premium LR152 digital alarm clock, covering setup, features, alarm settings, and safety information.



### [Lexon Flip Premium LR152 Alarm Clock User Manual](#)

User manual for the Lexon Flip Premium LR152 alarm clock, detailing features, setup, charging, alarm settings, safety information, and product specifications.



### [Lexon Flip+ Travel LR151 Digital Alarm Clock User Guide](#)

User guide for the Lexon Flip+ Travel LR151 digital alarm clock, featuring time setting, alarm functions, snooze, backlight, travel lock, and technical specifications. This compact travel clock offers a reversible design with ON/OFF faces and a touch-sensitive light.