

Home Hero Electric Salt and Pepper Grinder

Home Hero Electric Salt and Pepper Grinder Set Instruction Manual

INTRODUCTION

Thank you for choosing the Home Hero Electric Salt and Pepper Grinder Set. This manual provides essential information for the safe and efficient use, setup, and maintenance of your new electric grinders. Please read these instructions thoroughly before first use and retain them for future reference.



Image: The Home Hero Electric Salt and Pepper Grinder Set, showcasing both the black and white grinders, the charging base, USB cable, and two transparent measuring cups.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 2 x Home Hero Electric Grinders (one white, one black)
- 1 x USB Charging Stand
- 1 x USB Charging Cable
- 4 x AAA Rechargeable Batteries
- 2 x Measuring Cups (screw-on containers)
- 1 x Instruction Manual (this document)

SET. CHARGE. SAVOR!



Accessories included:

- USB charging cord
- Automatic charging stand
- 1 full charge lasts about 2 months
 - 4 AAA rechargeable batteries

* Do not use disposable batteries

156x80x194mm
70ml capacity

Image: An overhead view of all components included in the Home Hero Electric Salt and Pepper Grinder Set, laid out on a kitchen counter.

SETUP

1. Battery Installation

1. Locate the battery compartment on the grinder.
2. Insert the four included AAA rechargeable batteries, ensuring correct polarity (+/-).
3. Close the battery compartment securely.

2. Filling the Grinders

1. Twist the top section of the grinder counter-clockwise to separate it from the transparent spice chamber.
2. Fill the spice chamber with your desired spice (e.g., salt crystals, peppercorns). Do not overfill.
3. Align the top section with the spice chamber and twist clockwise to secure it.

GRINDING HAS NEVER BEEN EASY



1. Refill salt or pepper into container



2. Adjust coarseness



3. Press the button



4. Charge the grinder

Image: A four-panel image demonstrating the process of refilling the grinder with spices, adjusting the coarseness, pressing the button to grind, and placing the grinder on its charging base.

3. Initial Charging

1. Connect the USB charging cable to the charging stand and a suitable USB power source.
2. Place the grinders onto the charging stand. The blue LED light on the base of the grinders will illuminate to indicate charging.
3. Allow approximately 2-3 hours for a full charge. A full charge provides approximately two months of usage time.

OPERATING INSTRUCTIONS

1. Adjusting Coarseness

The grinders offer five coarseness options. To adjust:

1. Locate the adjustment knob on the top of the grinder.

2. Turn the knob to select your desired grind size: from extra coarse to extra fine.

FIND THE PERFECT GRIND SIZE



Image: A detailed view of the grinder's top, highlighting the adjustable knob for selecting grind coarseness from fine to coarse.

2. Grinding Spices

The grinders feature easy one-handed operation:

1. Hold the grinder over your food or dish.
2. Press and hold the button located on the side of the grinder. The blue LED light will illuminate, and the grinder will begin dispensing spices.
3. Release the button to stop grinding.

HOME HERO RECHARGEABLE SALT & PEPPER GRINDER & SHAKER



Spice up your favorite dish at the touch of a button

Image: A person holding the black electric pepper grinder over a fresh salad, demonstrating its use.

3. Using the Measuring Cups

The included screw-on measuring cups allow for precise spice dispensing and can also serve as no-spill shakers:

- Attach a measuring cup to the bottom of the grinder.
- Grind spices directly into the cup to measure exact amounts (e.g., 1 tsp, 1 tbsp, 2 tbsp, 1/5 cup).
- The cups can also be used as temporary storage or for serving at the table.

DESIGNED TO HELP YOU SEASON WITH PRECISION



Accurately
dispenses 1 tsp,
1 tbsp, 2 tbsp,
and 1/5th cup

Built-in LED blue
light for flawless
seasoning

Transparent
base showcases
your spices

Image: The white electric salt grinder with its blue LED light active, showing the transparent spice chamber and visible measurement markings on the attached cup.

MAINTENANCE AND CARE

Cleaning

- **Do not immerse the grinders in water or place them in a dishwasher.**
- Wipe the exterior of the grinders with a damp cloth.
- To clean the spice chamber, detach it from the grinder and rinse with warm water. Ensure it is completely dry before reattaching and refilling.
- Use a small brush (not included) to clean any spice residue from the grinding mechanism.

Storage

Store the grinders in a dry place when not in use. The charging stand provides a convenient storage solution.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Grinder does not operate.	Low battery or no power.	Charge the grinder using the USB charging stand. Ensure batteries are correctly inserted.
Grinder operates but no spice is dispensed.	Spice chamber is empty or grinding mechanism is clogged.	Refill the spice chamber. Clean the grinding mechanism of any residue.
Spice grind is inconsistent.	Coarseness setting is incorrect or grinding mechanism needs cleaning.	Adjust the coarseness knob. Clean the grinding mechanism.
Blue LED light does not illuminate during charging.	Grinder not properly seated on charging stand or charging cable/power source issue.	Ensure the grinder is correctly placed on the charging stand. Check USB cable connection and power source.

SPECIFICATIONS

- **Brand:** Home Hero
- **Model:** Electric Salt and Pepper Grinder
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Color:** White & Black
- **Product Dimensions:** 6.14"W x 7.64"H
- **Item Weight:** 1.72 Pounds (for the set)
- **Operation Mode:** Automatic
- **Power Source:** USB Rechargeable (4x AAA rechargeable batteries included)
- **Dishwasher Safe:** No

SAFETY INFORMATION

- Keep out of reach of children.
- Do not use disposable batteries; only use the provided rechargeable batteries or equivalent.
- Do not immerse the electronic components in water.
- Avoid contact with moving parts during operation.
- Use only for grinding dry spices such as salt crystals and peppercorns. Not suitable for wet or oily spices.
- If the product is damaged, discontinue use immediately and contact customer support.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Home Hero Electric Salt and Pepper Grinder Set, please refer to the contact information provided with your purchase or visit the official Home Hero website.



