**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**WINGBO SYCF7203**

# WINGBO 72" DC Ceiling Fan with Lights User Manual

Model: SYCF7203 | Brand: WINGBO

## Product Overview

The WINGBO 72-inch DC Ceiling Fan with Lights is designed to provide optimal air circulation and illumination for large indoor spaces such as living rooms, bedrooms, and even covered outdoor areas. Its sleek, contemporary, and industrial design seamlessly integrates into modern home aesthetics.

- **Minimalist Style:** Features 8 powerful plywood blades for effective air movement.
- **6-Speed Reversible DC Motor:** Offers six forward and reverse speeds, allowing for downdraft in summer to create a cooling effect and updraft in winter to circulate warm air.
- **Integrated LED Light Kit:** Includes a 24W LED light source with adjustable color temperatures (3000K Warm White, 4500K Natural White, 6000K Day White).
- **Remote Control:** Convenient handheld remote for easy adjustment of fan speeds, light settings, and direction.
- **Versatile Installation:** Comes with three downrods (4.5”, 12", and 24") to accommodate various ceiling heights and is suitable for angled ceilings up to 15 degrees.
- **Durable Construction:** Fan blades are crafted from high-quality compressed plywood for enhanced durability.



The WINGBO 72-inch DC Ceiling Fan with Lights in Brushed Nickel and Gray.




Close-up view of the fan's premium quality plywood blades.




The modern and sleek frosted glass lamp cover of the fan.

## Setup and Installation


Proper installation is crucial for the safe and efficient operation of your WINGBO ceiling fan. It is recommended that installation be performed by a qualified electrician.

### Before You Begin:

- Ensure the power is turned off at the circuit breaker before beginning any electrical work.
- Read all instructions carefully before proceeding.
- Gather all necessary tools and hardware.

### Mounting Options:

The fan supports both downrod (flat mount) and sloped mount installations. Three downrods of varying lengths (4.5", 12", and 24") are included to suit different ceiling heights. The fan can be installed on angled ceilings up to 15 degrees.




Fan dimensions and available mounting options.

## Installation Steps (General Guide):

1. Securely attach the mounting bracket to the ceiling junction box.
2. Assemble the downrod and canopy to the fan motor housing.
3. Carefully lift the fan assembly and hang it from the mounting bracket.
4. Complete the electrical wiring connections as per local electrical codes and the fan's wiring diagram.
5. Attach the fan blades to the motor housing.
6. Install the integrated LED light kit and frosted glass cover.
7. Secure the canopy to the ceiling.

**Remote Control Battery:** Please insert one 23A 12V alkaline battery (not included) into the remote control before first use.

## Operating Instructions

Your WINGBO ceiling fan is operated via the included handheld remote control, offering a range of functions for comfort and convenience.

### Remote Control Functions:




Functions of the remote control.

- **Power On/Off:** Activates or deactivates the fan and light.
- **Fan Speed Control:** Adjusts between 6 fan speeds.
- **Light Control:** Turns the LED light on/off and cycles through the three color temperatures (3000K, 4500K, 6000K).
- **Fan Direction (Reversible Motor):** Switches between forward (summer mode) and reverse (winter mode) rotation.
- **Timer Function:** Sets the fan to turn off automatically after a specified period.




Understanding Summer (Downdraft) and Winter (Updraft) Modes.






Adjustable LED light with three color temperature options.

## Official Product Video:

This video demonstrates the WINGBO Ceiling Fan with 8 Blades in Brushed Nickel, showcasing its operation and features.

## Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Dust the fan blades and motor housing periodically with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Tighten Fasteners:** Check all screws and fasteners on the fan and mounting hardware at least twice a year to ensure they are secure. Loose connections can cause noise or wobbling.
- **Blade Balance:** If the fan wobbles, ensure all blades are securely attached and that they are balanced. A blade balancing kit (not included) can be used if necessary.
- **Light Source:** The LED light source is integrated and designed for long life. If it requires replacement, please

contact the manufacturer for assistance.

## Troubleshooting

If you encounter issues with your WINGBO ceiling fan, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Fan does not start | No power to the fan; Remote control battery is dead; Loose wire connections. | Check circuit breaker and wall switch; Replace remote battery (23A 12V); Verify all wire connections are secure. |
| Light does not work | Light switch on remote is off; Loose wire connection to light kit; Integrated LED failure. | Press light button on remote; Check light kit wiring; Contact manufacturer if LED is faulty. |
| Fan wobbles | Loose blades or blade holder screws; Unbalanced blades; Loose mounting bracket. | Tighten all blade and blade holder screws; Use a blade balancing kit; Ensure mounting bracket is securely fastened to the ceiling. |
| Noisy operation | Loose screws; Motor issue; Blades hitting an obstruction. | Check and tighten all screws; Ensure no obstructions are near the blades; If noise persists, contact manufacturer. |
| Remote control not responding | Dead battery; Remote not paired; Interference. | Replace battery; Refer to pairing instructions (if applicable, usually automatic); Reduce interference from other devices. |

## Specifications

| Feature | Specification |
|---|---|
| Brand | WINGBO |
| Model Name | WINGBO (SYCF7203) |
| Color | Brushed Nickel and Gray |
| Electric Fan Design | Ceiling Fan |
| Power Source | DC |
| Style | Modern |
| Product Dimensions | 72"D x 72"W x 33"H |
| Room Type | Bedroom, Kitchen, Living Room (Indoor) |
| Special Feature | LED Light |
| Recommended Uses | Indoor |
| Wattage | 24 watts |
| Finish Type | Brushed |

| Feature | Specification |
|---|---|
| Number of Blades | 8 |
| Blade Length | 72 Inches |
| Voltage | 24 Volts (DC) |
| Switch Type | Pull Chain (Control Method: Remote) |
| Item Weight | 27.1 pounds (12.34 Kilograms) |
| Included Components | Remote |
| Blade Material | Engineered Wood |
| Number of Power Levels | 6 |
| Batteries Required? | No (for fan operation, but 23A 12V battery needed for remote) |
| Date First Available | October 26, 2022 |

## Warranty and Support

For warranty information, technical support, or to inquire about replacement parts, please contact WINGBO customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Extended protection plans may be available for purchase separately. Please refer to your retailer for details on available protection plans.

© 2025 WINGBO. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0BKKG2B22**

More documents and user manuals: **https://manuals.plus/**