

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VECELO](#) /

› [VECELO 16-Inch Full Metal Platform Bed Frame Instruction Manual](#)

VECELO LT-F04M

VECELO 16-Inch Full Metal Platform Bed Frame Instruction Manual

Brand: VECELO | Model: LT-F04M

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your VECELO 16-Inch Full Metal Platform Bed Frame. Please read all instructions carefully before assembly and use to ensure safe and proper functioning of the product.

SAFETY INFORMATION

- **Maximum Load Capacity:** Do not load more than 600 pounds (Full size). Refer to specifications for other sizes.
- Exercise caution around sharp edges during assembly and use.
- Follow all assembly instructions carefully to prevent instability or collapse of the bed frame.
- Ensure all screws and bolts are tightened securely and inspected regularly.
- Mattress is not included with the bed frame.

PACKAGE CONTENTS


Before beginning assembly, verify that all parts are present and undamaged. The package should contain:

- 1 x Bed Frame (components)
- 1 x Instruction Manual (this document)
- 1 x Assembly Kit (including screws and necessary tools)


SETUP AND ASSEMBLY

The VECELO platform bed frame is designed for easy assembly. Follow these steps for proper setup:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Initial Frame Assembly:** The bed frame features a foldable structure for convenience. Begin by unfolding the main sections of the frame.



Foldable Structure Help You Easy Assemble It



Reinforced Structure for Squeak Resistant

Image: Foldable structure of the bed frame, illustrating how it unfolds for assembly.

3. **Attach Legs:** Secure the support legs into their designated positions. Ensure they are fully extended and locked into place.
4. **Connect Frame Sections:** If your frame consists of multiple sections (e.g., for Queen size and larger), align them and connect them using the provided screws and tools.



Image: Fully assembled VECELO bed frame, ready for mattress placement.

5. **Tighten Screws:** Do not fully tighten screws until the entire frame is assembled. Once all parts are in place and aligned, securely tighten all screws and bolts.
6. **Verify Stability:** Gently shake the frame to ensure it is stable and all legs remain in firm contact with the ground.
7. **Headboard Attachment (Optional):** The bed frame includes two holes on each of the two bedhead legs, allowing for the attachment of a headboard (not included).

This platform bed frame does not require a box spring. Place your mattress directly onto the steel slats.

OPERATING INSTRUCTIONS

- **Mattress Placement:** Place your mattress directly on the steel slats. A box spring is not required.
- **Weight Distribution:** Ensure weight is distributed evenly across the bed frame to maintain stability and prevent damage. Refer to the 'Specifications' section for maximum load capacity.
- **Under-Bed Storage:** The 14.4-inch clearance under the frame provides ample space for storage boxes and other items, helping to maximize room utility.



Image: Under-bed clearance demonstrated with a storage basket.

- **Noise Reduction:** The upgraded square metal steel structure is designed to reduce friction with the mattress, minimizing noise.

MAINTENANCE

- **Regular Inspection:** Periodically check all screws and bolts to ensure they remain tightened. Re-tighten as necessary to maintain the frame's stability and prevent squeaking.
- **Cleaning:** Wipe the metal frame with a damp cloth and mild detergent. Avoid abrasive cleaners that may damage the finish.
- **Floor Protection:** The frame includes anti-scratch foot covers to protect your floor from damage. Ensure these covers are intact and in place.

TROUBLESHOOTING

If you encounter any issues with your VECELO bed frame, consider the following:

- **Squeaking Noises:**

- Ensure all bolts and screws are securely tightened. Loose connections are a common cause of squeaking.
- Verify that the mattress is properly seated on the slats and not shifting excessively.

- **Instability/Wobbling:**

- Re-check all connections to ensure they are tight.
- Confirm that the bed frame is on a level surface and all support legs are making full contact with the floor.

- **Difficulty Collapsing/Unfolding:**

- Ensure no obstructions are preventing the legs or frame sections from moving freely.
- Apply gentle, even pressure when folding or unfolding.

If problems persist, please contact VECELO customer support for assistance.

SPECIFICATIONS

Brand	VECELO
Model Number	LT-F04M
Material	Metal (Steel)
Color	Mattle Black
Product Dimensions (Full Size)	75"L x 54"W x 16"H
Under-Bed Clearance	14.4 inches
Maximum Load Capacity (Full Size)	600 lbs (272 kg)
Assembly Required	Yes
Special Features	Squeak Resistant, Foldable Structure, Headboard Compatible
UPC	810110788879



Image: Dimensional diagram of the VECELO bed frame.

WARRANTY AND CUSTOMER SUPPORT

VECELO is committed to providing quality products and excellent customer service.

- **Warranty:** The product includes a one-year free parts replacement warranty.
- **Return Policy:** A limited 30-Day Return Policy is applicable.
- **Contact Support:** If you encounter any issues with your bed frame or require assistance, please contact VECELO customer support. We aim to resolve your problem within 24 hours.
- For further information or to reach customer service, please visit the official VECELO store on Amazon: [VECELO Store](#).