

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [tectake](#) /

› [TecTake 801034 Rocking Chair User Manual](#)

tectake 801034

TecTake 801034 Rocking Chair User Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, safe operation, and proper maintenance of your TecTake 801034 Rocking Chair. Please read these instructions thoroughly before beginning assembly or using the chair, and retain this document for future reference.

SAFETY INSTRUCTIONS

- **Maximum Load Capacity:** Do not exceed the maximum weight limit of **150 kg (330 lbs)**. Exceeding this limit may cause damage to the chair or personal injury.
- **Stable Surface:** Always place the rocking chair on a flat, stable, and level surface to prevent tipping.
- **Assembly:** Keep children and pets away from the assembly area. Ensure all components are correctly installed and all fasteners are securely tightened before use.
- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Loose fasteners can compromise the chair's stability and safety.
- **Proper Use:** Use the chair only for its intended purpose as a rocking chair. Avoid standing on the chair or using it as a step stool.
- **Finger Safety:** Be mindful of pinch points during rocking motion, especially with children nearby.

PACKAGE CONTENTS

Before assembly, verify that all the following components are present in your package:

- Rocking chair frame components (birch wood)
- Mounting hardware (screws, nuts, washers, Allen key)
- Comfortable seat and back padding with integrated head cushion
- Assembly instructions (this manual)

SETUP AND ASSEMBLY

Assembly of the TecTake 801034 Rocking Chair is designed to be straightforward. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Identify all frame pieces, hardware, and cushions.
2. **Assemble the Frame:** Connect the main arched wooden frame pieces using the provided screws and Allen key. Ensure the pieces align correctly according to the diagrams in the included paper instructions. Do not fully tighten screws at this stage.
3. **Attach Crossbars:** Secure the horizontal crossbars between the rocking elements of the frame. These provide structural integrity.
4. **Install Rocking Base:** Attach the rocking base elements to the bottom of the frame. Ensure the felt pads are correctly positioned on the underside of the rocking base to protect your floor.
5. **Final Tightening:** Once all frame components are loosely assembled, place the chair upright on a level surface. Gradually tighten all screws evenly until secure. Do not overtighten.
6. **Position Cushions:** Place the seat and back padding onto the assembled frame. The head cushion is integrated into the back padding.



Underside view of the rocking chair frame, illustrating the assembly points and rocking base.



Fully assembled TecTake 801034 Rocking Chair with cushions in place.

OPERATING INSTRUCTIONS

The TecTake 801034 Rocking Chair is designed for comfortable relaxation. To use your chair:

- **Sitting:** Sit centrally on the seat cushion, ensuring your back is supported by the backrest.
- **Rocking Motion:** Initiate a gentle rocking motion with your feet. The chair's arched frame is designed for a smooth and pleasant movement.
- **Floor Protection:** The rocking chair is equipped with felt pads on its base to prevent scratches and damage to your flooring. Ensure these pads are intact and clean.



Detail of the felt pads on the rocking chair's base, designed to protect flooring.

MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your rocking chair:

- **Cushion Care:** The cushion cover is removable and made from 100% cotton. It can be machine washed. Refer to the care label on the cushion for specific washing instructions.
- **Frame Cleaning:** Wipe the wooden frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the varnished birch finish.
- **Fastener Check:** Periodically (e.g., monthly) inspect all screws and bolts. Due to the rocking motion, fasteners may loosen over time. Tighten them as necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the wood to fade or dry out, and the fabric to discolor.



Rear view of the rocking chair, highlighting the removable cushion cover with zipper.



Close-up of the cushion zipper, indicating the removable and washable cover.

TROUBLESHOOTING

- **Chair feels unstable or wobbly:**

Ensure all assembly screws are fully tightened. Check that the chair is placed on a completely flat and level surface.

- **Squeaking noise during rocking:**

Inspect all joints and connections for any loose screws. Tighten any loose fasteners. A small amount of silicone spray on the joints (avoiding the wood surface) may help if the noise persists.


- **Floor getting scratched:**

Verify that the felt pads on the rocking base are intact and properly attached. Replace any worn or missing pads. Ensure the floor surface is clean of debris that could cause scratches.

SPECIFICATIONS

Model Name	TecTake 801034
Total Dimensions (L x D x H)	Approx. 65 x 94 x 100 cm (25.59"D x 37.01"W x 39.37"H)
Seat Area (W x D)	Approx. 55 x 46 cm

Seat Height	Approx. 39 - 50.5 cm
Backrest Height	Approx. 74 cm
Head Cushion Dimensions (W x H)	Approx. 58 x 28 cm
Maximum Load Capacity	150 kg (330 lbs)
Item Weight	Approx. 7.8 kg (17.16 lbs)
Materials	Birch wood, Steel, Polyurethane, 100% Cotton
Color	Beige
Style	Scandinavian
Product Care	Machine wash (cushion cover)



Detailed dimensions of the TecTake 801034 Rocking Chair for reference.

For information regarding warranty coverage or technical support, please refer to the documentation provided at the time of purchase or contact tectake customer service directly. Contact details can typically be found on the manufacturer's official website or on your purchase receipt.