

TOHETO 01

TOHETO A4 Wireless LED Light Pad User Manual

Model: A4 Wireless Lightpad with Case, Innovative Stand and Top Clip (Black)

1. INTRODUCTION

Thank you for choosing the TOHETO A4 Wireless LED Light Pad. This light pad is designed to enhance your artistic and crafting projects, offering portability, adjustable brightness, and ergonomic features. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.

Please read this manual thoroughly before using the product and retain it for future reference.

2. PRODUCT FEATURES

- **Innovative Stand & Top Clip:** Features an integrated, adjustable stand for comfortable viewing angles and a top clip to securely hold paper or canvas.
- **Wireless & USB-C Powered:** Equipped with a built-in battery for cordless use (approx. 5 hours on full charge) and a Type-C port for charging and wired operation.
- **Adjustable Brightness:** Offers both 6-level brightness adjustments and stepless dimming (0-100%) to suit various lighting conditions and project requirements.
- **Eye-Protection Technology:** Designed with 3000-6500K color temperature to provide even, glare-free illumination, reducing eye strain during extended use.
- **Wide Application:** Ideal for drawing, tracing, sketching, animation, X-ray viewing, calligraphy, diamond painting, architectural design, sewing projects, fashion design, and industrial design.



Figure 2.1: Key features of the TOHETO A4 Wireless LED Light Pad, highlighting the fasten clip, Type-C port, and foldable stand.



Figure 2.2: Ergonomic design of the light pad's stand promotes a comfortable working posture, reducing strain.



Figure 2.3: The light pad incorporates eyesight-protected technology for comfortable and safe use.

3. PACKAGE CONTENTS

Upon opening your TOHETO A4 Wireless LED Light Pad package, please verify that all the following items are included:

- 1 x LED Light Drawing Pad (Black)
- 1 x Protective Carry Bag
- 1 x 6-foot Type-C USB Charging Cable (1.8m)
- 1 x Pencil
- 1 x Pencil Sharpener
- 1 x Eraser
- 10 x Tracing Papers
- 1 x User Manual (this document)



Figure 3.1: All items included in the TOHETO A4 Wireless LED Light Pad package.

4. SETUP

4.1 Charging the Light Pad

Before first use, fully charge the light pad. Connect the provided Type-C USB cable to the light pad's Type-C port and the other end to a USB-A power source (e.g., power bank, computer USB port, or USB wall adapter). A full charge takes approximately 1.5 hours and provides about 5 hours of wireless use at maximum brightness.

Note: Only USB-A to USB-C charging cables can be used. USB-C to USB-C charging cables are NOT compatible.



Battery & USB-C Powered

Wireless Using for about 5h at Max Brightness




Figure 4.1: The light pad can be powered and charged via its USB-C port using various USB-A power sources.

4.2 Adjusting the Integrated Stand

The light pad features an innovative foldable stand on its back. Gently pull out the stand to adjust the angle for a comfortable working position. This ergonomic design helps reduce neck and back strain during long periods of use.



Ergonomical Foldable Innovative Stand provides a comfortable crafting angle



Figure 4.2: The integrated stand can be adjusted to provide an optimal crafting angle.

4.3 Using the Top Clip

The light pad includes a fasten top clip designed to hold your paper, diamond painting canvas, or other materials securely in place. Simply slide your material under the clip to prevent shifting during your work.

The fasten clip is designed to hold paper & diamond painting canvas easily, also efficiently complete other projects without placing extra clips any more



Figure 4.3: The top clip ensures your work material remains stable.

5. OPERATION

5.1 Power On/Off


To turn the light pad on or off, locate the power button (U) on the side panel. A short press will toggle the power.

5.2 Adjusting Brightness

The light pad offers two methods for brightness adjustment:

- **6-Level Brightness Dimming:** Short press the '+' or '-' buttons to cycle through 6 preset brightness levels.
- **Stepless Brightness Dimming:** Long press the '+' or '-' buttons to smoothly adjust the brightness from 0% to 100%. Release the button when the desired brightness is reached.

6-Level Brightness + Stepless Dimming Brightness



Click the Button  to turn on or turn off

6 Levels Brightness Dimming Mode: Click the button   once

Stepless Brightness Dimming Mode: Long press the button  



Figure 5.1: Brightness control buttons and their functions.

6-level & stepless Brightness Control



Figure 5.2: Brightness levels ranging from minimum to maximum.

5.3 Applications

The TOHETO A4 Wireless LED Light Pad is versatile and can be used for a variety of creative and

professional tasks:

- **Drawing & Tracing:** Perfect for transferring designs, sketching, and detailed line work.
- **Animation:** Facilitates frame-by-frame animation by allowing visibility of multiple layers.
- **Diamond Painting:** Illuminates the canvas, making symbols clearer and reducing eye strain during intricate work.
- **X-ray Viewing:** Provides a consistent light source for examining X-ray films.
- **Calligraphy & Stenciling:** Aids in precise alignment and consistent strokes.
- **Architectural & Fashion Design:** Useful for drafting, pattern making, and design overlays.



Animation Design




Sketching



Calligraphy



Architectural Design



Watercolor Painting



Diamond Painting



X-Ray Viewing

Multifunction




Figure 5.3: Diverse applications of the TOHETO A4 Wireless LED Light Pad.

6. MAINTENANCE

6.1 Cleaning

To clean the light pad, gently wipe the surface with a soft, dry, or slightly damp cloth. Avoid using abrasive cleaners, solvents, or excessive moisture, as these can damage the surface or internal components.

6.2 Storage

When not in use, store the light pad in its protective carry bag to prevent scratches and dust accumulation. Store in a cool, dry place away from direct sunlight and extreme temperatures.

6.3 Battery Care

To prolong battery life, avoid fully discharging the light pad frequently. If storing for an extended period, charge the battery to about 50% every few months.

7. TROUBLESHOOTING

If you encounter any issues with your TOHETO A4 Wireless LED Light Pad, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Light pad does not turn on.	Low battery or no power connection.	Charge the light pad using the provided USB-A to Type-C cable. Ensure the power source is active.
Light pad is not charging.	Incorrect cable type or faulty cable/adaptor.	Ensure you are using a USB-A to Type-C cable. Try a different USB port or power adapter.
Brightness adjustment not working.	Buttons not pressed correctly or temporary software glitch.	Ensure you are short-pressing for 6 levels or long-pressing for stepless dimming. Try turning the device off and on again.
Light flickers or is uneven.	Low battery or unstable power source.	Charge the light pad fully. Ensure the power source provides stable output if operating wired.

If the problem persists after trying these solutions, please contact TOHETO customer support for further assistance.

8. SPECIFICATIONS

Attribute	Specification
Model Name	A4 Wireless Lightpad with Case, Innovative Stand and Top Clip (Black)
Item Model Number	01
Color	Black
Material	Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions	13.47 x 9.85 x 0.43 inches

Attribute	Specification
Item Weight	2.57 pounds (1.17 Kilograms)
Power Source	Battery Powered / USB Powered
Light Source Type	Light Emitting Diode (LED)
Brightness Control	Stepless (0-100%) and 6 Levels Adjustable
Color Temperature	3000-6500K
Battery Type	1 Lithium Polymer battery (included)
Charging Time	Approx. 1.5 hours (fully charged)
Operating Time (Wireless)	Approx. 5 hours (at max brightness)



Battery & USB-C Powered

Wireless Using for about 5h at Max Brightness




Figure 8.1: Dimensions of the TOHETO A4 Wireless LED Light Pad.

9. WARRANTY AND SUPPORT

TOHETO is committed to providing high-quality products and excellent customer service. Your A4 Wireless LED Light Pad comes with a satisfaction service. If you have any questions, concerns, or encounter any quality issues with your product, please do not hesitate to contact us.

Replacement is available if there is any quality issue with the product.

For support, please refer to the contact information provided on the product packaging or the official TOHETO website. When contacting support, please have your product model number (01) and purchase details ready.