



Manuals.plus /

› **CROSSNET /**

› CROSSNET Quick Assemble 4 Square Volleyball Game Set for Adults and Kids with Volleyball Net, Backpack and Ball for Outdoor Games Crossnet V1 Classic

CROSSNET CN-101

CROSSNET Quick Assemble 4 Square Volleyball Game Set

Brand: CROSSNET

Model: CN-101

PRODUCT OVERVIEW

The CROSSNET Quick Assemble 4 Square Volleyball Game Set is designed for dynamic outdoor play, combining elements of traditional volleyball and four square. This versatile game set is suitable for adults and kids, offering adjustable net heights and easy portability for various environments like grass or sand.




Figure 1: The CROSSNET game set, showcasing its use on both grass and sand, along with the product packaging.

WHAT'S INCLUDED

Your CROSSNET game set comes with all necessary components for immediate setup and play:

- Singles net (designed for 4 players)
- Steel uprights (poles)
- Travel backpack for convenient storage and transport
- Volleyball
- Ball pump
- Boundary lines to define the playing area
- Rule book for game instructions



HEIGHT ADJUSTABLE
MADE FOR EVERYONE

Figure 2: All components of the CROSSNET game set, neatly packed for portability.

CROSSNET™



**CROSSNET
PICKLEBALL**



**CROSSNET
SOCCER**



**CROSSNET
INFLATABLE H2O**



CROSSNET H2O

SHOW US YOUR SKILLS AND TAG: @CROSSNETGAME

FOLLOW US ON: f t i d y

Figure 3: Visual representation of all items included in the CROSSNET package.

KEY FEATURES

- **Quad Side Net:** Designed as a 4-way volleyball net, allowing for dynamic gameplay with four players per round.
- **Adjustable Net Height:** The net can be adjusted to different heights to accommodate various player groups:
 - 7'4" tall for traditional outdoor women's volleyball
 - 7'11" for men's volleyball
 - 5'6" for kids' play
- **Durable Construction:** Features a robust steel frame and high-quality cotton and nylon netting, ensuring longevity and consistent performance in both indoor and outdoor settings.
- **Portability:** Comes with a travel backpack, making it easy to transport and set up for games at the beach, park, or backyard.



Figure 4: Illustration of the adjustable net heights for different age and skill levels.



HOW TO PLAY




Figure 5: The CROSSNET game can be set up and played on various surfaces, including sand and grass.

SETUP INSTRUCTIONS

Setting up your CROSSNET game is designed to be quick and straightforward, typically taking around 5 minutes.

1. **Unpack Components:** Remove all items from the travel backpack.
2. **Assemble Poles:** Connect the steel upright poles. These are designed to snap together easily.
3. **Attach Net:** Slide the net onto the assembled poles. Ensure the net is properly aligned and secured at the top of each pole.
4. **Adjust Height:** Utilize the adjustable features on the poles to set the net to your desired height (Kids, Women's, or Men's).
5. **Lay Out Boundary Lines:** Place the four boundary lines to form the square playing area. Secure them into the ground using the provided stakes.
6. **Inflate Volleyball:** Use the included pump to inflate the volleyball to the recommended pressure.
7. **Secure Tension Strings:** Attach and tighten the tension strings from the poles to the ground stakes to ensure the net remains taut and stable during play.



Figure 6: The CROSSNET game set in the process of being assembled on a sandy beach.

[Setup Video Guide:](#)

Your browser does not support the video tag.

Video 1: Product Features Review - This video provides an overview of the product's features and demonstrates aspects of its setup and use.

OPERATING INSTRUCTIONS (HOW TO PLAY)

CROSSNET combines the classic game of four square with volleyball rules. The objective is to eliminate opponents by having the ball land in their square.

1. **Player Positioning:** Four players occupy each of the four squares. Squares are typically numbered 1 through 4.
2. **Serving:** The player in Square 4 serves the ball diagonally to the player in Square 2. The serve must be an underhand or overhand volleyball serve.
3. **Gameplay:** After the serve, players must hit the ball to an opponent's square. The ball must be hit over the net and land within the boundaries of an opponent's square. Players can use bumps, sets, or spikes.

4. **Elimination:** A player is eliminated (or rotates to Square 1 if playing with more than 4 people) if:
 - The ball lands out of bounds.
 - The ball hits the ground in their own square.
 - They hit the ball into the net.
 - They hit the ball more than once consecutively.
 - The ball is hit more than three times by a team before going over the net (if playing doubles within a square).
5. **Scoring:** Points are typically scored by the player in Square 4 when an opponent is eliminated. The game is usually played to 11 points, winning by 2.
6. **Rotation:** When a player is eliminated, all players rotate clockwise to fill the empty squares, and the eliminated player joins the back of the line to enter Square 1.

Refer to the included rule book for detailed rules and variations.



CROSSNET
**CROSSNET IS FOUR
SQUARE VOLLEYBALL!**

Figure 7: A visual guide to the basic rules of CROSSNET, including setup, serving, gameplay, and scoring.




Figure 8: Players engaged in a dynamic game of CROSSNET on the beach.

Gameplay Video:

Your browser does not support the video tag.

Video 2: CROSSNET 4 Square Volleyball - Demonstrates the fast-paced gameplay and rules of CROSSNET.

MAINTENANCE

Proper maintenance will extend the life of your CROSSNET game set:

- **Cleaning:** Wipe down poles and net with a damp cloth after use, especially if used in sand or muddy conditions. Allow all components to dry completely before storage.
- **Storage:** Disassemble the set and store all components in the provided travel backpack. Store in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Inspect for Wear:** Periodically check the net for any tears or loose stitching, and the poles for any bends or damage. Address minor issues promptly to prevent further damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Net sags or is not taut.	Tension strings are loose or not properly secured.	Ensure all tension strings are pulled tight and stakes are firmly in the ground. Re-adjust if necessary.
Poles appear unstable or bend.	Improper assembly or excessive force during play.	Verify all pole sections are securely snapped together. Avoid leaning on or applying excessive force to the poles during play.
Ball loses air quickly.	Valve issue or small puncture.	Check the ball's valve for proper seating. If a puncture is suspected, apply soapy water to locate the leak. Repair or replace the ball if necessary.

SPECIFICATIONS

- **Item Package Dimensions (L x W x H):** 25.59 x 9 x 7.5 inches
- **Package Weight:** 8.22 Kilograms
- **Item Weight:** 7.7 Kilograms
- **Brand Name:** CROSSNET
- **Color:** Black (Netting and Poles), Yellow (Net Trim and Branding)
- **Suggested Users:** Unisex
- **Manufacturer:** CROSSNET
- **Part Number:** CN-101
- **Style:** Crossnet V1 Classic
- **UPC:** 051497051662

WARRANTY AND SUPPORT

For specific warranty information, product support, or to inquire about replacement parts, please contact CROSSNET directly through their official website or customer service channels. Keep your purchase receipt as proof of purchase.