

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [iJoy](#) /

> [iJoy Mist Bluetooth Shower Speaker User Manual](#)

iJoy Mist

iJoy Mist Bluetooth Shower Speaker User Manual

Model: Mist

INTRODUCTION

Thank you for purchasing the iJoy Mist Bluetooth Shower Speaker. This manual provides essential information for the safe and efficient use of your device. The iJoy Mist is an IPX4 splash-proof wireless speaker designed for use in environments such as showers, poolsides, and hot tubs. It features a built-in microphone for hands-free calling and intuitive touch controls for media management.

WHAT'S IN THE BOX

- iJoy Mist Bluetooth Shower Speaker
- Charging Cable
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your iJoy Mist speaker.




Image: The back of the iJoy Mist speaker with labels pointing to its touch controls: Power On/Off, Previous Song, Skip Song, Pick up or Hang up Call, and Play/Pause Music.

Control Functions:

- **Power On/Off Button:** Located at the top. Press and hold to power on or off.
- **Play/Pause Button:** Located at the center. Press to play or pause music.
- **Previous Song Button:** Located on the left. Press to go to the previous track.
- **Skip Song Button:** Located on the right. Press to skip to the next track.
- **Call Button:** Located at the bottom. Press to pick up or hang up a phone call.

Suction Grip and Lanyard for Easy Hanging

Play your favorite music
in the shower



Image: The iJoy Mist speaker, light blue in color, hanging on a dark tiled shower wall using its integrated suction grip and lanyard. This illustrates the speaker's hanging capability.

The speaker includes a suction grip and lanyard for easy hanging on smooth surfaces like shower walls or tiles.

SETUP

1. Charging the Speaker

1. Connect the provided charging cable to the charging port on the speaker.
2. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The charging indicator light will illuminate. A full charge takes approximately 2.5 hours.
4. Once fully charged, the indicator light will change or turn off, depending on the model. Disconnect the charging cable.

2. Bluetooth Pairing




Image: A person's hands interacting with a smartphone, with the iJoy Mist speaker visible on a table. This image represents the effortless Bluetooth connection process.

1. Ensure the speaker is fully charged.
2. Press and hold the Power On/Off button to turn on the speaker. It will enter pairing mode, indicated by a flashing LED light.
3. On your Bluetooth-enabled device (smartphone, tablet, etc.), go to the Bluetooth settings.
4. Search for available devices and select "iJoy Mist" from the list.
5. Once paired, the speaker will emit an audible confirmation, and the LED light will stop flashing or change color.
6. The speaker has a Bluetooth range of up to 10 meters (30 feet). Maintain this distance for optimal connection.



Widely Compatibility

Work with all Bluetooth-enabled devices

0-10m Transmission Distance



Image: The iJoy Mist speaker positioned alongside a laptop, a tablet, and a smartphone, illustrating its wide compatibility with various Bluetooth-enabled devices.

OPERATING INSTRUCTIONS

Music Playback

- **Play/Pause:** Press the Play/Pause button once.
- **Next Track:** Press the Skip Song button once.
- **Previous Track:** Press the Previous Song button once.

Hands-Free Calling

With the built-in microphone, you can answer calls directly through the speaker.

- **Answer Call:** When a call comes in, press the Call button once.
- **End Call:** During a call, press the Call button once to hang up.
- **Reject Call:** When a call comes in, press and hold the Call button for a few seconds.

MAINTENANCE

To ensure the longevity and optimal performance of your iJoy Mist speaker, follow these maintenance guidelines:

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Water Resistance:** The speaker is IPX4 splash-proof, meaning it is resistant to splashing water from any direction. Do not submerge the speaker in water. Ensure the charging port cover is securely closed when using the speaker near water.



Image: The iJoy Mist speaker partially submerged in water with splashes, visually representing its IPX4 splash-proof capability.

- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, charge the speaker regularly, even if not in frequent use. Avoid fully depleting the battery for extended periods.

TROUBLESHOOTING

If you encounter issues with your iJoy Mist speaker, refer to the following common solutions:

- **Speaker does not turn on:**
 - Ensure the battery is charged. Connect the speaker to a power source using the charging cable.

- Press and hold the Power On/Off button for a few seconds.
- **No sound:**
 - Check if the speaker is paired correctly with your device.
 - Ensure the volume on both the speaker and your connected device is turned up.
 - Make sure the speaker is not muted.
- **Cannot pair with Bluetooth device:**
 - Ensure the speaker is in pairing mode (flashing LED).
 - Turn off and then on the Bluetooth function on your device.
 - Move the speaker closer to your device (within 10 meters).
 - If previously paired, try forgetting the device on your phone's Bluetooth settings and re-pairing.
 - Ensure no other devices are currently connected to the speaker.
- **Poor sound quality or disconnections:**
 - Ensure there are no obstructions between the speaker and your device.
 - Move away from other wireless devices that might cause interference.
 - Charge the speaker if the battery is low.

SPECIFICATIONS

Feature	Specification
Model Name	iJoy Mist Bluetooth Shower Speaker
Speaker Type	Component
Special Feature	Built-in Microphone
Recommended Uses	Waterproof Activities, Showering, Poolside, Hot Tub, Quarries, Gym
Compatible Devices	Bluetooth enabled devices
Product Dimensions	5.7"D x 2.7"W x 6.61"H
Item Weight	0.66 Pounds (10.6 ounces)
Water Resistance Level	IPX4 (Splash Resistant)
Maximum Bluetooth Range	10 Meters (30 Feet)
Control Method	Touch
Wireless Communication Technology	Bluetooth
Power Source	Battery Powered
Battery Capacity	300 Milliamp Hours
Charging Time	2.5 Hours
Frequency Response	180 Hz

Audio Output Mode	Stereo
Mounting Type	Wall Mount (Suction Grip)

WARRANTY AND SUPPORT

The iJoy Mist Bluetooth Shower Speaker comes with a **1 Year Limited Warranty**. Please retain your proof of purchase for warranty claims.

For technical support, warranty inquiries, or further assistance, please contact iJoy customer service. Refer to the product packaging or the official iJoy website for the most current contact information.

© 2023 iJoy. All rights reserved.