Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GXTrust Wezz 2.0

GXTrust Wezz 2.0 Gaming PC Speakers User Manual

Model: GXT 611 Wezz

1. Introduction

Thank you for purchasing the GXTrust Wezz 2.0 Gaming PC Speakers. These speakers are designed to enhance your audio experience for gaming, movies, and music with 12W peak power and dynamic RGB LED lighting. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new speakers.

2. Package Contents

Please check the box for the following items:

- Set of GXTrust Wezz 2.0 Speakers (Left and Right)
- Wired Control Knob (integrated)
- User Manual

3. Setup

Follow these steps to connect your GXTrust Wezz 2.0 speakers to your computer or other audio device:

1. **Placement:** Position the left and right speakers on either side of your monitor or listening area. Ensure they are placed on a stable, flat surface for optimal sound projection.
2. **Audio Connection:** Plug the 3.5mm audio jack from the speakers into the audio output port (headphone jack) of your computer, laptop, or other audio source.
3. **Power Connection:** Connect the USB-A cable from the speakers to an available USB port on your computer or a USB wall adapter (5V). The speakers will power on automatically once USB power is supplied.



Image: Connecting the 3.5mm audio jack and USB power cable to a laptop.

4. Operating Instructions

The GXTrust Wezz 2.0 speakers feature an integrated wired control knob for easy access to power, volume, and lighting functions.



Image: User interacting with the multi-function control knob.

4.1. Power On/Off

- The speakers power on automatically when connected to a USB power source.
- To turn off the speakers, rotate the control knob counter-clockwise until it clicks and the lights turn off.
- To turn on, rotate the control knob clockwise until it clicks.

4.2. Volume Control

- Rotate the control knob clockwise to increase the volume.
- Rotate the control knob counter-clockwise to decrease the volume.

4.3. RGB LED Lighting

The speakers feature dynamic RGB LED lighting with various modes.

- Press the button on the side of the control knob to cycle through different RGB lighting modes.

- Some modes may react to the audio playback.
- To turn off the RGB lighting while keeping the speakers on, cycle through the modes until the lights are off.



Image: Close-up view of the speakers showcasing their vibrant RGB LED illumination.

5. Maintenance

To ensure the longevity and optimal performance of your speakers, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the speaker surfaces. Do not use liquid cleaners or abrasive materials, as they may damage the finish or internal components.
- **Storage:** When not in use for extended periods, store the speakers in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Liquids:** Keep the speakers away from water and other liquids to prevent electrical damage.

6. Troubleshooting

If you encounter any issues with your GXTrust Wezz 2.0 speakers, please refer to the following common solutions:

Problem	Possible Solution
No sound from speakers	• Ensure the 3.5mm audio jack is fully inserted into both the speakers and the audio source. • Check if the USB power cable is securely connected and receiving power. • Verify the volume is turned up on both the speakers and your audio source (computer/device). • Confirm the audio output on your computer/device is set to the correct output (e.g., 'Speakers' or 'Headphones'). • Test with a different audio source or USB port.
RGB lights are not working	• Ensure the speakers are receiving USB power. • Press the light mode button on the control knob to cycle through modes; the lights might be turned off.
Distorted or poor sound quality	• Reduce the volume on both the speakers and your audio source to prevent clipping. • Ensure all cables are securely connected and not damaged. • Test with a different audio source to rule out issues with the original source.

7. Specifications

Feature	Detail
Model Name	GXT 611 Wezz
Speaker Type	Stereo 2.0
Peak Power	12W
RMS Power	6W
Connectivity	USB (Power), 3.5mm Audio Jack (Audio)
Frequency Response	20 Hz - 20 kHz (typical)
Input Voltage	5V (via USB)
Material	Metal (grilles)
Dimensions (each speaker)	9.5D x 8.7W x 16.5H cm
Total Weight	780 Grams
Control Method	Button Control (Wired Knob)
Features	USB Powered, RGB Pulsating Lights

8. Warranty and Support

8.1. Warranty Information

The GXTrust Wezz 2.0 Gaming PC Speakers come with a**2-year full warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets its specified performance. Please retain your proof of purchase for warranty claims.

8.2. Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official GXTrust website or contact their customer service department. You can find more information and support resources at the GXTrust Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BKQPRXC4

More documents and user manuals: **https://manuals.plus/**