

[Manuals.plus](#) /

› [BALAY](#) /

› BALAY 3CG5175N3 Built-in Microwave Oven User Manual

BALAY 3CG5175N3

BALAY 3CG5175N3 Built-in Microwave Oven User Manual

Model: 3CG5175N3

1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before installing and using your BALAY 3CG5175N3 microwave oven. Keep this manual for future reference.

- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Ensure the appliance is properly earthed.
- Liquids and other foods must not be heated in sealed containers since they are liable to explode.
- Only use utensils that are suitable for use in microwave ovens.
- When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.

2. PRODUCT OVERVIEW

The BALAY 3CG5175N3 is a 25-liter built-in microwave oven designed for seamless integration into your kitchen cabinetry. It features multiple power levels and an automatic cooking function for convenient meal preparation.



Figure 2.1: Front view of the BALAY 3CG5175N3 Built-in Microwave Oven. This image displays the sleek black finish, the digital display showing '12:15 min', and the control panel with various power settings (50w, 180w, 360w, 600w, 900w) and function icons.




Figure 2.2: Interior view of the BALAY 3CG5175N3 Microwave Oven with the door open. The image shows the stainless steel interior, the glass turntable, and the internal rack, highlighting the spacious 25-liter capacity.

3. INSTALLATION

This microwave oven is designed for built-in installation. Proper installation is crucial for safe and efficient operation. Consult a qualified technician if you are unsure about any steps.


Ensure your kitchen cabinet meets the specified dimensions for proper ventilation and fit.



- The appliance must be connected to a properly earthed electrical outlet.
- Ensure the voltage and frequency match the specifications on the rating plate of the appliance.
- Do not use extension cords or multiple adapters.

If installing in a corner cabinet, ensure adequate clearance as shown in the diagram below.

Microwave, corner installation



Measurements in mm

Figure 3.2: Diagram illustrating the minimum clearance required for corner installation of the microwave. It shows a minimum gap of 3mm from the adjacent wall or cabinet to allow for proper door opening and ventilation.

4. OPERATING INSTRUCTIONS

This section provides guidance on how to operate your BALAY 3CG5175N3 microwave oven.

4.1 Basic Operation

1. Place food in a microwave-safe container on the turntable.
2. Close the oven door securely.
3. Select the desired power level using the control panel buttons (e.g., 900W for high power, 50W for defrosting).
4. Set the cooking time using the timer controls.
5. Press the Start button to begin cooking.

4.2 Automatic Cooking Function

The microwave features an automatic cooking function for various food types. Refer to the specific symbols on the

control panel for available programs. To use:

1. Place the food in the oven.
2. Select the appropriate automatic program.
3. The oven will automatically set the cooking time and power level based on the program.
4. Press Start.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your microwave oven.

5.1 Interior Cleaning

- Clean the oven cavity immediately after use to prevent food spills from drying and hardening.
- Use a damp cloth with mild detergent. Do not use abrasive cleaners or metal brushes.
- For stubborn stains, place a bowl of water with lemon juice inside and heat for a few minutes to loosen residue.

5.2 Exterior Cleaning

- Wipe the exterior surfaces with a soft, damp cloth.
- Avoid spraying cleaners directly onto the control panel. Apply cleaner to a cloth first.

5.3 Turntable Care

- The glass turntable and roller ring can be removed for cleaning. Wash them in warm, soapy water or in a dishwasher.
- Ensure they are completely dry before placing them back in the oven.

6. TROUBLESHOOTING

If you encounter issues with your microwave, refer to the following common problems and solutions before contacting service.

Problem	Possible Cause	Solution
Oven does not start	Door not closed properly; Power cord unplugged; Blown fuse/tripped circuit breaker.	Ensure door is firmly closed; Check power cord connection; Check household fuse/circuit breaker.
Food not heating	Incorrect power level/cooking time; Microwave-safe dish not used.	Adjust power level and time; Use appropriate microwave-safe cookware.
Light not working	Bulb needs replacement.	Contact qualified service personnel for bulb replacement.
Unusual noise during operation	Turntable not correctly placed; Foreign object in cavity.	Ensure turntable and roller ring are correctly seated; Remove any foreign objects.

7. SPECIFICATIONS

Key technical specifications for the BALAY 3CG5175N3 Built-in Microwave Oven.

Feature	Specification
Brand	Balay
Model Number	3CG5175N3
Color	Black
Capacity	25 Litres
Power Output	900 Watts
Installation Type	Integrated (Built-in)
Special Feature	Automatic Cooking
Product Dimensions (D x W x H)	38.8 cm x 59.4 cm x 38.2 cm
Manufacturer	BALAY
Country of Origin	China

8. WARRANTY AND SUPPORT

This BALAY appliance comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, service requests, or to purchase spare parts, please contact BALAY customer support. Contact information can typically be found on the official BALAY website or in the documentation provided with your appliance.

- Keep your proof of purchase (receipt or invoice) as it will be required for warranty claims.
- Do not attempt to repair the appliance yourself, as this may void the warranty and pose safety risks.

© 2023 BALAY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BKQW7GT5>

More documents and user manuals: <https://manuals.plus/>