**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**GOUYESHO MD31018**

# GOUYESHO RC1208 Replacement Remote Control User Manual

This manual provides detailed instructions for the setup, operation, and maintenance of your GOUYESHO RC1208 replacement remote control.

## Introduction

The GOUYESHO RC1208 is a high-quality replacement remote control designed for seamless compatibility with a range of Medion LCD LED HD TVs. Constructed from durable ABS plastic with soft silicone buttons, it offers a comfortable and reliable user experience. This remote operates using infrared (IR) technology, providing a stable connection to your television.

Before using your new remote control, please read this manual thoroughly to ensure proper setup and operation.

## Setup

### 1. Battery Installation

The GOUYESHO RC1208 remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote and must be purchased separately.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.




Figure 1: Battery installation for the GOUYESHO RC1208 remote control. Ensure correct polarity when inserting AAA batteries.

## 2. Initial Use - No Programming Required

This replacement remote control is designed for immediate use with compatible Medion TVs. No complex signal settings, programming, or pairing procedures are required. Simply install the batteries, and the remote is ready to operate your television.





Figure 2: The GOUYESHO RC1208 remote control is ready to use right out of the box after battery insertion.

## Operating Instructions

### Basic Operation

The GOUYESHO RC1208 remote control utilizes infrared (IR) communication. For optimal performance, ensure there is a clear line of sight between the remote's IR emitter (located at the top of the remote) and the IR receiver on your Medion TV. The effective operating range is approximately 8 meters (26 feet), though this can vary based on environmental conditions and the specific TV model.




Figure 3: The remote offers long-distance precise control using infrared technology, effective up to 10 meters (33 feet).

## Button Functions

The remote features large, easy-to-use buttons with clearly distributed characters for comfortable operation. Below is a general overview of common button functions. Please note that some functionalities may not be available depending on your specific Medion TV model.






Figure 4: Front view of the GOUYESHO RC1208 remote control, showing its layout and button labels.

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel selection.
- **Volume Up/Down (+/-):** Adjusts the audio volume.
- **Channel Up/Down (P+/-):** Changes the TV channel.
- **Mute Button:** Mutes or unmutes the TV audio.

- **Navigation Buttons (Up, Down, Left, Right, OK):** For navigating menus and confirming selections.
- **Menu Button:** Accesses the TV's main menu.
- **Source/Input Button:** Switches between different input sources (HDMI, AV, etc.).
- **Exit Button:** Exits current menu or function.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Skip):** For controlling media playback.
- **Color Buttons (Red, Green, Yellow, Blue):** Often used for specific functions within TV menus or interactive services.

For a complete understanding of all button functionalities, please refer to your Medion TV's original user manual.

## Maintenance

### Battery Replacement

The typical battery life for the GOUYESHO RC1208 remote control is approximately one year, though this can vary significantly based on usage frequency. When the remote's performance degrades (e.g., reduced range, unresponsive buttons), it is likely time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section to replace the two AAA batteries.

### Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the remote. Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the remote's finish or internal components.

## Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the proper polarity.
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote and the TV's IR receiver.
  - Ensure you are within the effective operating range (approx. 8 meters).
- **Certain buttons do not work:**
  - This remote is designed to replicate the functions of the original Medion TV remote. Functions or buttons that were not present on your original remote will not be operable with this replacement.
  - Verify that your TV model is listed in the compatible devices section.
- **Remote only works intermittently:**
  - This product is designed for devices with infrared remote control. It cannot be used if the remote control connected to your device is wireless (RF or Bluetooth).
  - Weak batteries can cause intermittent operation. Replace them.

If you continue to experience issues after following these steps, please refer to the "Warranty and Support" section for further assistance.

## Specifications

| Feature | Detail |
| --- | --- |

| | |
|---|---|
| Brand | GOUYESHO |
| Model Number | MD31018 (Replacement for RC1208) |
| Color | Black |
| Communication Method | Infrared (IR) |
| Power Source | 2 x AAA Batteries (DC3V, not included) |
| Approximate Battery Life | 1 year (varies with usage) |
| Main Material | ABS Plastic + Silicone Buttons |
| Operating Range | Approx. 8 meters (26 feet) / Up to 10 meters (33 feet) |
| Weight | 84g (main unit only) |

Note: Technical specifications and design are subject to change without prior notice. Minor measurement errors may occur due to manual measurement.

## Compatible Medion TV Models

The GOUYESHO RC1208 replacement remote control is compatible with the following Medion LCD LED HD TV models and original remote control numbers:

- RC1208
- 40038764
- LIFEP12030
- LIFEP15024
- LIFEP15081
- MD21085
- MD31018
- MD30588
- MD31153
- MD30814
- MD30889
- P15024
- P15218
- P16045
- P17098
- P17127

*Please verify your device's compatibility before purchase. This remote is specifically for infrared-controlled devices.*

## Warranty and Support

We conduct thorough quality inspections before shipping our products. However, in the unlikely event that your product arrives damaged or develops a fault during use, we offer a reliable guarantee for refunds and exchanges.

For any issues, questions, or support needs, please do not hesitate to contact us. Our customer service team is dedicated to assisting you and ensuring your satisfaction.

Contact information for support is typically available through your purchase platform (e.g., Amazon seller contact) or on the product packaging.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0BKSG53KV**

More documents and user manuals: **https://manuals.plus/**