

Easytry16035

Generic Remote Control Instruction Manual

For Lifesmart Space Heaters

Models: LS-4W1500-X, LS-6DMIQH-X, LS-8WIQH-LB-IN, LS-LCHT1142US, LS-ZCHT1056US, LS-ZCHT1097US, LS-IF1500-DOFP

INTRODUCTION

This instruction manual provides essential information for the proper setup, operation, and maintenance of your Generic replacement remote control. This remote is designed as a direct replacement for specific Lifesmart electric infrared quartz space heater models. Please ensure your original remote matches the appearance of this replacement unit for proper functionality. No setup or programming codes are required for this remote control.

SETUP

Battery Installation

The remote control requires two (2) AAA batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Slide the cover back into place until it clicks securely.



Image: Back of the remote control with the battery compartment open, showing the slots for two AAA batteries.



Image: Back of the remote control with the battery compartment cover removed, illustrating how to access the battery slots.

OPERATION

This remote control operates your Lifesmart space heater without requiring any programming. Point the remote directly at the heater's infrared receiver for optimal performance.

Button Functions



Image: Front view of the remote control, displaying all operational buttons including Power, Temperature Adjustment, Mode Selection, Timer, and Eco functions.

- **Power Button ():** Turns the heater ON or OFF.
- **Temperature Up/Down Buttons (▲ / ▼):** Adjusts the desired temperature setting.
- **Mode/Function Buttons (◀ / ▶):** Cycles through different operating modes or fan speeds.
- **Timer Button (⌚):** Sets the heater's automatic shut-off timer.
- **Settings/Gear Button (⚙️):** Accesses additional settings or functions.
- **Eco Mode Button (♻️):** Activates or deactivates energy-saving mode.

MAINTENANCE

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's operational range decreases or it stops responding consistently. Always replace both batteries simultaneously with new AAA batteries of the same type. Do not mix old and new batteries or different battery types.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent potential leakage and damage to the device.

TROUBLESHOOTING

Remote Control Not Responding

- **Check Battery Polarity:** Ensure the AAA batteries are inserted with the correct positive (+) and negative (-) orientation.

- **Replace Batteries:** Install two fresh AAA batteries. Weak or depleted batteries are a common cause of remote control malfunction.
- **Remove Obstructions:** Ensure there are no objects blocking the line of sight between the remote control and the infrared receiver on your Lifesmart heater.
- **Verify Compatibility:** Confirm that this remote control is compatible with your specific Lifesmart heater model. Refer to the list of compatible models in the introduction.

SPECIFICATIONS

Model Number	Easytry16035
Compatible Heater Models	Lifesmart LS-4W1500-X, LS-6DMIQH-X, LS-8WIQH-LB-IN, LS-LCHT1142US, LS-ZCHT1056US, LS-ZCHT1097US, LS-IF1500-DOFP
Power Source	2 x AAA batteries (not included)
Dimensions (Approximate)	4 x 1 x 1 inches
Weight (Approximate)	1.6 ounces
Color	Black

WARRANTY AND RETURN POLICY

This product is typically covered by a 30-day return or replacement policy from the date of purchase. For specific details regarding returns, replacements, or warranty claims, please refer to the retailer's or seller's official return policy where the product was purchased.

CUSTOMER SUPPORT

For further assistance, compatibility questions, or if you encounter issues not covered in this manual, please contact the seller directly through your purchase platform. You may also refer to your original Lifesmart heater's instruction manual for specific operational details related to the heater itself.