

PHILIPS PHI55PFL57

Philips 55-Inch 4K UHD LED Android Smart TV

Model: PHI55PFL57 | **Brand:** PHILIPS

1. INTRODUCTION

Welcome to the user manual for your new Philips 55-Inch 4K UHD LED Android Smart TV. This television is designed to provide an immersive entertainment experience with advanced features and intuitive controls. This manual will guide you through the setup, operation, and maintenance of your TV, ensuring you get the most out of its capabilities.

Key features include:

- **4K Ultra HD Resolution:** Four times the resolution of Full HD for stunning clarity.
- **HDR10 Technology:** Delivers more detail, deeper blacks, brighter whites, and vivid colors.
- **Android TV:** Access to over 700,000+ movies and shows from various streaming services.
- **Google Assistant:** Voice control for your TV, content recommendations, and smart home device management.
- **Chromecast Built-in:** Easily cast content from your mobile devices to the TV.
- **Bluetooth Connectivity:** Wirelessly connect headphones or soundbars for enhanced audio.

2. WHAT'S IN THE BOX

Before you begin, please ensure all components are present and undamaged.

- Philips 55-Inch 4K UHD LED Android Smart TV
- Remote Control
- TV Stand (2 pieces)
- Stand Screws
- 2 AAA Batteries (for remote control)
- Instruction Sheets (this manual)

4K UltraHD



4x the resolution of Full HD brings your viewing experience to a whole new level.



Screen images simulated.

Figure 2.1: Included accessories and components in the Philips TV packaging.

3. SETUP

3.1 Unpacking and Placement

Carefully remove the TV from its packaging. It is recommended to have two people for this process due to the size and weight of the television. Place the TV on a stable, flat surface or prepare for wall mounting.



Figure 3.1: Philips TV on a media console, demonstrating typical placement.

3.2 Attaching the Stand

1. Place the TV face down on a soft, clean surface to prevent screen damage.
2. Align each stand piece with the corresponding screw holes on the bottom of the TV.
3. Secure the stands using the provided screws. Ensure they are tightened firmly but do not overtighten.

3.3 Connecting Power and Initial Setup

1. Connect the power cord to the TV's power input and then to a wall outlet.
2. Press the power button on the TV or the remote control to turn on the TV.
3. Follow the on-screen instructions to complete the initial setup, including language selection, network connection (Wi-Fi or Ethernet), and Google account sign-in.

4. OPERATING INSTRUCTIONS

4.1 Android TV Interface

Your Philips TV runs on Android TV, providing a user-friendly interface for accessing content and apps. The home screen offers personalized recommendations and quick access to your favorite streaming services.



Figure 4.1: The intuitive Android TV home screen.


4.2 Voice Remote and Google Assistant

The included voice remote allows for convenient control of your TV using Google Assistant. Simply press the Google Assistant button on your remote and speak your command.

- **Search Content:** Ask Google to find movies, TV shows, or videos.
- **Control TV Functions:** Change channels, adjust volume, or switch inputs.
- **Smart Home Integration:** Control compatible smart home devices, such as dimming lights.



Put your small screen on your big screen. Simply use your mobile device to cast your favorite shows, movies, music, sports, games, and more on your TV.



Control games with your smart phone

Figure 4.2: Philips Voice Remote with Google Assistant.

4.3 Chromecast Built-in

Cast your favorite content from your smartphone, tablet, or computer directly to your TV using Chromecast built-in. This feature allows you to enjoy videos, music, photos, and more on the big screen.

PHILIPS 55" 5766 series TV



What's in the box.

- Instruction sheets
- Table top stand
- Remote control
- Batteries
- Stand screws



Figure 4.3: Chromecast built-in functionality.

4.4 Bluetooth Connectivity

Connect your Bluetooth-enabled headphones or soundbars wirelessly to the TV for a personalized audio experience without disturbing others. This provides a cleaner setup by eliminating extra cables.

PHILIPS

Remote control

Press the Google Assistant button on your remote to do more on your TV with your voice. Ask Google to search for the latest blockbuster, stream shows, or open multiplayer games. Have it dim the lights by connecting compatible smart home devices. Manage tasks and see your calendar. Or ask it questions and see the answers on your TV.

Microphone

Google Assistant button




Figure 4.4: Bluetooth connectivity for audio devices.

5. MAINTENANCE

Proper care and maintenance will extend the life of your Philips TV.

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid harsh chemicals or abrasive materials.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked to prevent overheating.
- **Power Cord:** Regularly check the power cord for any damage. If damaged, contact qualified service personnel for replacement.

6. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No Power	Power cord disconnected; outlet issue.	Ensure power cord is securely connected. Test the outlet with another device.
No Picture/Sound	Incorrect input source; external device issue.	Verify correct input source. Check connections to external devices.
Wi-Fi Connectivity Issues	Weak signal; router issue; TV software glitch.	Move router closer or use Ethernet. Restart router. Restart TV. Check for software updates.
Screen Goes Blank/LED Flashing	Internal error; power cycle needed.	Unplug the TV from the power outlet for 30 seconds, then plug it back in. If issue persists, contact support.
Slow Performance/Unresponsive Android TV	Too many apps running; low memory; software issue.	Close unused apps. Clear cache. Perform a factory reset if necessary (note: this will erase all data).

7. SPECIFICATIONS

Detailed technical specifications for your Philips 55-Inch 4K UHD LED Android Smart TV:

Feature	Specification
Brand	PHILIPS
Model Number	PHI55PFL57
Screen Size	55 Inches
Display Technology	LED
Resolution	4K Ultra HD (3840 x 2160)
Refresh Rate	60 Hz
HDR Support	HDR10
Operating System	Android TV
Voice Assistant	Google Assistant
Casting	Chromecast Built-in
Wireless Connectivity	Wi-Fi, Bluetooth
Product Dimensions (D x W x H)	3" x 49.2" x 28.5"

Feature	Specification
Item Weight	23.59 Pounds
Included Components	Stand, Remote Control

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Philips support website. You can also find additional resources and FAQs online.

For further assistance, please contact Philips customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question