Corbett Lighting 423-23-VB

Corbett Lighting Sena 423-23-VB LED Wall Sconce Instruction Manual

Model: 423-23-VB

1. Important Safety Information

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be hazardous or fatal. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

- **WARNING:** Risk of electric shock. Disconnect power at the circuit breaker or fuse box before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).
- Consult a qualified electrician if you have any electrical questions.
- This fixture is rated for damp locations. Do not install in areas exposed to direct water spray.
- **Proposition 65 Warning:** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

2. Package Contents

Verify that all components are present before beginning installation. If any part is missing or damaged, do not attempt to assemble, install, or operate the product. Contact customer service for replacement parts.

- Sena Wall Sconce Fixture (Model 423-23-VB)
- Instruction Manual
- Mounting Hardware (typically includes mounting plate, screws, wire nuts)

Note: Specific hardware may vary. Refer to the included hardware bag for exact contents.

3. Setup and Installation

Professional installation by a qualified electrician is recommended for this product.

1. **Prepare for Installation:**
   - Turn off power at the main circuit breaker or fuse box.
   - Ensure the wall surface is clean, dry, and structurally sound to support the fixture's weight (16.3 pounds).
   - Unpack the fixture and its components carefully.
2. **Mounting Plate Installation:**
   Attach the mounting plate to the junction box using the provided screws. Ensure the plate is securely fastened and level.



Image: Illustration of a mounting plate being secured to a standard electrical junction box on a wall.

3. **Electrical Connections:**
   Connect the fixture's wires to the house wiring according to the following:
   - Connect the fixture's black wire (Live) to the house's black wire (Live).
   - Connect the fixture's white wire (Neutral) to the house's white wire (Neutral).
   - Connect the fixture's ground wire (bare copper or green) to the house's ground wire.
   - Secure all connections with approved wire nuts and wrap with electrical tape for added safety.
4. **Fixture Attachment:**
   Carefully align the fixture with the mounting plate and secure it using the provided screws or nuts. Ensure the fixture is flush against the wall and stable.



Image: The Corbett Lighting Sena Wall Sconce, model 423-23-VB, shown fully installed on a wall, displaying its vintage brass finish and geometric design.

5. **Final Check:**
   Once the fixture is securely mounted and wired, restore power at the circuit breaker. Test the light fixture to ensure proper operation.

4. Operating Instructions

The Corbett Lighting Sena Wall Sconce operates via a standard wall switch (not included). Ensure the wall switch connected to the fixture is in the "ON" position for the light to function.

- To turn the light ON, flip the connected wall switch to the ON position.
- To turn the light OFF, flip the connected wall switch to the OFF position.

Note: This fixture uses an integrated LED light source and does not require bulb replacement.

5. Maintenance

Regular maintenance will help preserve the appearance and functionality of your wall sconce.

- **Cleaning:** Disconnect power before cleaning. Use a soft, dry, or slightly damp cloth to wipe the fixture. Avoid abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Inspection:** Periodically check all electrical connections and mounting hardware for tightness.
- **LED Care:** The integrated LED light source is designed for long life and does not require replacement. Do not attempt to disassemble the LED module.

6. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	• Power is off at the circuit breaker. • Loose wire connections. • Faulty wall switch.	• Check the circuit breaker and ensure it is ON. • Turn off power, then check and secure all wire connections. • Test the wall switch or consult an electrician.
Light flickers.	• Loose wire connections. • Incompatible dimmer switch (if applicable).	• Turn off power, then check and secure all wire connections. • Ensure any dimmer switch used is compatible with LED fixtures.

If troubleshooting steps do not resolve the issue, contact a qualified electrician or Corbett Lighting customer support.

7. Specifications

- **Model:** 423-23-VB
- **Brand:** Corbett Lighting
- **Finish Color:** Vintage Brass
- **Material:** Steel, Brass, Glass (Shade)
- **Dimensions (L x W x H):** 5" x 4" x 23.25"
- **Backplate Dimensions (W x L):** 5" x 23.25"
- **Light Source:** Integrated LED
- **Number of Light Sources:** 1
- **Wattage:** 10 Watts
- **Color Temperature:** 3000 Kelvin
- **Lumens:** 195
- **CRI:** 90

- **Voltage:** 120 Volts
- **Moisture Rating:** Damp Rated (Indoor Usage)
- **Item Weight:** 16.3 Pounds
- **Assembly Required:** Yes
- **Mounting Type:** Wall Mount
- **Lighting Method:** Up/Down Light
- **Style:** Modern

8. Warranty and Support

This Corbett Lighting product is covered by a**Manufacturer Warranty**. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official Corbett Lighting website.
For technical assistance, replacement parts, or warranty claims, please contact Corbett Lighting customer support. Contact information can typically be found on the manufacturer's website or on the product packaging.
You can visit the Corbett Lighting store on Amazon for more information:Corbett Lighting Store

© 2024 Corbett Lighting. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question