

[Manuals.plus](#) /

> [SOKANY](#) /

> SOKANY SK-YD-2094 Steam Iron User Manual

## SOKANY SK-YD-2094

# SOKANY SK-YD-2094 Steam Iron User Manual

Model: SK-YD-2094 | Brand: SOKANY

## INTRODUCTION

Thank you for purchasing the SOKANY SK-YD-2094 Steam Iron. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and retain them for future reference.



Image: The SOKANY SK-YD-2094 Steam Iron packaging, showing the product and its features.

## IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury. Read all instructions before using this iron.

- Always ensure the voltage indicated on the rating label corresponds to your mains voltage.
- Do not immerse the iron, power cord, or plug in water or other liquids.
- Unplug the iron from the electrical outlet when filling with water, emptying, or when not in use.
- Do not leave the iron unattended while it is switched on or connected to the power supply.
- Keep the iron and its cord out of reach of children.
- The soleplate and steam vents become very hot during use. Avoid contact with hot surfaces.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged.
- Use the iron only for its intended purpose, which is ironing garments.
- Always place the iron on a stable, heat-resistant surface when resting.

## PRODUCT OVERVIEW

---

The SOKANY SK-YD-2094 Steam Iron is designed for efficient garment care, offering dry, steam, and spray functions. Familiarize yourself with its components for optimal use.



Image: The SOKANY SK-YD-2094 Steam Iron, showcasing its design and separate base.

### Key Components:

- **Ceramic Soleplate:** Provides smooth gliding and even heat distribution.

- **Water Tank (230ml capacity):** For steam and spray functions.
- **Temperature Control Dial:** Adjusts heat settings for different fabric types.
- **Steam Button:** Activates steam output.
- **Spray Nozzle & Button:** For misting garments.
- **360-degree Swivel Power Cord:** Offers flexibility and ease of movement.
- **Indicator Light:** Shows heating status.




Image: Close-up views of the iron's features, including the comfortable grip handle, multi-position rotary button, and smooth ceramic soleplate.

## SETUP

1. **Unpacking:** Carefully remove the iron and all accessories from the packaging. Retain packaging for storage or in case of return.
2. **First Use Preparation:** Before first use, wipe the soleplate with a soft, damp cloth to remove any manufacturing residues.
3. **Filling the Water Tank:** Ensure the iron is unplugged. Open the water tank cover and fill the 230ml tank with clean tap water. Do not overfill. Close the water tank cover securely.
4. **Power Connection:** Plug the power cord into a suitable electrical outlet (230V, 50Hz).

## OPERATING INSTRUCTIONS

The SOKANY SK-YD-2094 offers versatile ironing options for various fabrics.

### 1. Dry Ironing

1. Ensure the water tank is empty or the steam setting is off.
2. Plug in the iron.
3. Set the temperature control dial to the desired fabric setting (e.g., silk, wool, cotton, linen). The indicator light will illuminate.
4. Wait for the indicator light to turn off, indicating the iron has reached the set temperature.
5. Begin ironing.

## 2. Steam Ironing

1. Fill the water tank as described in the Setup section.
2. Plug in the iron.
3. Set the temperature control dial to a steam-appropriate setting (usually between wool and linen, indicated on the dial). The indicator light will illuminate.
4. Wait for the indicator light to turn off.
5. Press the steam button to release steam while ironing. For continuous steam, some models may have a lock feature or a specific steam setting on the dial.



Image: The SOKANY SK-YD-2094 Steam Iron actively producing steam, illustrating its steam function.

## 3. Spray Function

1. Ensure the water tank is filled.
2. Point the spray nozzle towards the garment.
3. Press the spray button to release a fine mist onto the fabric, which helps to dampen stubborn

wrinkles.




Image: A visual comparison showing a wrinkled shirt before ironing and a smooth shirt after ironing, demonstrating the iron's effectiveness.

## MAINTENANCE

---

Proper maintenance ensures the longevity and performance of your iron.

### Cleaning the Soleplate

- Always unplug the iron and allow it to cool completely before cleaning.
- Wipe the soleplate with a soft, damp cloth. For stubborn stains, use a mild, non-abrasive cleaner specifically designed for iron soleplates.
- Do not use abrasive scouring pads or harsh chemicals, as these can damage the ceramic coating.

### Draining the Water Tank

- After each use, or before storing, ensure the water tank is emptied.
- Unplug the iron and let it cool. Open the water tank cover and invert the iron over a sink to drain any remaining water.

### Storage

- Once the iron is completely cool and dry, store it upright on its heel rest to protect the soleplate.
- Wrap the power cord loosely around the base or use the cord clip if provided.

- Store in a dry, safe place, away from direct sunlight and moisture.

## TROUBLESHOOTING

---

If you encounter issues with your iron, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outage; temperature dial set to 'OFF' or too low.	Check power connection; ensure power supply; set temperature dial to desired heat.
No steam output.	Water tank empty; temperature too low for steam; steam button not pressed.	Fill water tank; set temperature to steam range; press steam button.
Water leaks from soleplate.	Temperature too low for steam; water tank overfilled.	Increase temperature to steam range; do not overfill water tank.
Soleplate is dirty.	Residue from fabrics or starch.	Clean soleplate as per Maintenance section.

## SPECIFICATIONS

---

Detailed technical specifications for the SOKANY SK-YD-2094 Steam Iron:

- **Brand Name:** SOKANY
- **Model Number:** SK-YD-2094
- **Color:** Silver
- **Wattage:** 220 Watts
- **Voltage:** 230 Volts
- **Frequency:** 50 Hz
- **Water Tank Capacity:** 230 ml
- **Base Material:** Ceramic
- **Item Weight:** 900 grams
- **Special Features:** Temperature Control
- **Recommended Uses:** General Ironing
- **Included Components:** Clothes Iron

## WARRANTY AND SUPPORT

---

For warranty information and customer support, please refer to the warranty card included with your product or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

