

Beyution 45FNT004

Beyution 45FNT004 Replacement Remote Control User Manual

For Magnavox TV and DVD Players

INTRODUCTION

Welcome to the user manual for your Beyution 45FNT004 Replacement Remote Control. This remote is designed to provide seamless control for various Magnavox TV and DVD player models without the need for programming or pairing. It serves as a direct replacement for your original remote, offering reliable performance and ease of use.

PRODUCT OVERVIEW

This section provides a general overview of the 45FNT004 remote control, highlighting its design and key features.





Image: Front view of the Beyution 45FNT004 Replacement Remote Control, showing all buttons and its ergonomic shape.

The Beyution 45FNT004 remote control features a standard layout with clearly labeled buttons for intuitive operation. Its ergonomic design ensures a comfortable grip, and the durable construction is built for long-lasting use.

Key Features

- **No Programming or Pairing Required:** Ready to use right out of the box with compatible models.

- **Infrared Connectivity:** Standard infrared technology for reliable communication with your device.
- **Ergonomic and Lightweight Design:** Comfortable to hold and easy to handle.
- **Durable Construction:** Made from high-quality ABS plastic and soft rubber, with printing designed to resist wear.
- **Effective Operating Distance:** Functions effectively up to approximately 10 meters (33 feet).

SETUP

Battery Installation

The 45FNT004 remote control requires two AAA batteries (not included) for operation. Please follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image: Back view of the remote control with the battery compartment open, showing where to insert the AAA batteries.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.

OPERATING INSTRUCTIONS

This remote control is designed for immediate use with compatible Magnavox TV and DVD player models without any complex setup. Simply point the remote at your device and press the desired button.

Basic Operation

- **Power Button:** Turns the TV/DVD player on or off.
- **Number Buttons (0-9, +10):** Directly select channels or input numerical values.
- **Volume Up/Down (VOL +/-):** Adjusts the audio volume.
- **Channel Up/Down (CH +/-):** Changes the television channel.

- **Mute Button:** Mutes or unmutes the audio.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate menus and confirm selections.
- **Disc/Title/Menu/Audio/SAP/Clear:** Specific controls for DVD player functions.
- **Mode/Play/Pause/Stop/Rewind/Fast Forward:** Media playback controls for DVD functions.
- **PIC/SOUND MODE:** Adjusts picture and sound modes on the TV.
- **SLEEP:** Sets a sleep timer for the TV.
- **INFO:** Displays program or device information.
- **PREV.CH:** Returns to the previously viewed channel.
- **BACK:** Returns to the previous menu or screen.
- **SOURCE:** Selects input sources (e.g., HDMI, AV, Component).
- **PICTURE SIZE:** Adjusts the screen aspect ratio.
- **TV MENU:** Accesses the television's main menu.
- **DVD SETUP:** Accesses the DVD player's setup menu.

Compatible Models

This remote control is compatible with a wide range of Magnavox TV and DVD player models. The following is a list of some compatible models:

- 28MD304V
- 28MD403V
- 29MD403V/F7
- 32MD304V/F7
- 28MD304
- 28MD304V/F7
- 28MD304VF7
- 28MD403
- 28MD403V/F7
- 28MD403VF7
- 32MD304
- 32MD304V
- URMT45FNT004
- 45FNT004
- RTNH407UP
- NH407UP
- 29MD403V

If your model is not listed, but your original remote was a 45FNT004 or similar, this replacement remote may still be compatible.

MAINTENANCE

Proper care and maintenance will extend the life of your remote control.

- Clean the remote control regularly with a soft, dry cloth. Do not use liquid cleaners, solvents, or abrasive materials, as these can damage the surface or internal components.
- Avoid exposing the remote to extreme temperatures, direct sunlight, or high humidity.
- If the remote will not be used for an extended period (e.g., several weeks or months), remove the batteries to prevent potential leakage and damage.
- Do not drop or subject the remote to strong impacts, as this can damage the internal circuitry.

TROUBLESHOOTING

If you encounter any issues with your remote control, please refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Remote not responding	Dead or weak batteries	Replace batteries with new ones, ensuring correct polarity.
Remote not responding	Obstruction between remote and device	Ensure a clear line of sight between the remote's infrared emitter and the device's receiver. Remove any objects blocking the path.
Remote not responding	Device is off or unplugged	Ensure the TV/DVD player is powered on and properly connected to a power source.
Limited operating range	Weak batteries	Replace batteries.
Limited operating range	Infrared interference	Move away from strong light sources (e.g., direct sunlight, fluorescent lights) or other electronic devices that might cause interference.
Buttons are sticky or unresponsive	Dirt or debris accumulation	Gently clean around the buttons with a soft, dry cloth or a cotton swab. Do not use liquids.

SPECIFICATIONS

Detailed technical specifications for the Beyution 45FNT004 Replacement Remote Control:

Feature	Detail
Model Number	45FNT004 (Internal Model: WY-MBE992-US)

Feature	Detail
Connectivity Technology	Infrared (IR)
Material	ABS Plastic, Soft Rubber
Color	Black
Power Source	2 x AAA Batteries (not included)
Maximum Operating Distance	Approximately 10 meters (33 feet)
Product Dimensions (L x W x H)	6.3 x 1.57 x 0.39 inches (16 x 4 x 1 cm)
Item Weight	2.39 ounces (67.7 grams)
Manufacturer	Beyution Factory
Date First Available	October 31, 2022

WARRANTY AND SUPPORT

This product is designed for reliability and durability. For any questions, concerns, or support inquiries regarding your Beyution 45FNT004 Replacement Remote Control, please contact the manufacturer or seller directly through the platform where the purchase was made.

Note: Specific warranty terms may vary based on the retailer and region. Please refer to your purchase documentation for detailed warranty information.

© 2023 Beyution. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BKZ1BS2C>

More documents and user manuals: <https://manuals.plus/>